

FARMTRAC

TRACTORS EUROPE

FARMTRAC 9100 DT V

FARMTRAC 9105 DT V

FARMTRAC 9120 DT V

FARMTRAC 9125 DT V

FARMTRAC 9130 DT V

OPERATOR'S MANUAL

FARMTRAC TRACTORS EUROPE Sp. z o.o.

11-700 Mrągowo, ul. Przemysłowa 11, POLAND

www.farmtrac.pl

FARMTRAC 9100 DT V

FARMTRAC 9105 DT V

FARMTRAC 9120 DT V

FARMTRAC 9125 DT V

FARMTRAC 9130 DT V

Operator's Manual

Publication: 216
Mrągowo 2024

Contents

Page

INTRODUCTION	4
SAFETY SYMBOLS	4
1. GENERAL INFORMATION	7
1.1. Identification data	7
1.2. Safety precautions	9
1.3. Fire precautions	11
1.4. Warranty	12
1.5. Tractor delivery to purchaser	13
2. TECHNICAL SPECIFICATION	15
2.1. Engine	15
2.3. Transmission	15
2.4. Hydraulic lift system	18
2.5. Three-point linkage	18
2.6. Coupling devices	18
2.7. Steering system	18
2.8. Wheels & axles	19
2.9. Braking system	19
2.10. Tractor weight	20
2.11. Tractor dimensions	20
3. INSTRUMENT PANEL AND CONTROL DEVICES	21
3.1. Instrument Panel	21
3.2. Control levers and pedals	28
3.3. Tractor cab	30
3.4. Air conditioning control panel	32
3.5. Operator's seat adjustments	33
3.6. Passenger seat - option	34
4. OPERATION	35
4.1. Tractor running in	35
4.2. Starting and stopping the engine	35
4.3. Driving the tractor	37
4.3.1. Regeneration procedure of DPF filter	40
4.3.2. AdBlue/DEF tank filling	42
4.4. Power take-off (PTO)	43
4.5. Tractor hydraulic system	45
4.5.1. Hydraulic lift system	45
Control Panel Basics	45
Automatic Mode Screens	46
Manual Mode	49
Navigating the Menu's	49
Troubleshooting	52
4.5.2. External hydraulics control	54
4.6. Equipment attaching on three-point linkage	56
4.7. Attaching trailed machines and implements	58
4.8. Tractor weighing	58
4.9. Jacking Up Tractor	59
4.10. Engine bonnet opening	59

5. MAINTENANCE AND ADJUSTMENT.....	60
5.1. Periodic maintenance chart.....	60
5.2. Lubrication / Fluid application.....	62
5.2.1. Oils.....	62
5.2.2 . Reservoir filling.....	62
5.2.3. Greases.....	62
5.3. Engine.....	64
5.3.1. Engine lubrication system.....	64
5.3.2. Fuel system.....	65
5.3.3. Dry air cleaner.....	66
5.3.4. Cooling system.....	66
5.4. Electrical system.....	67
5.4.1 Alternator maintenance.....	67
5.4.2. Starter motor maintenance.....	67
5.4.3. Battery maintenance.....	68
5.4.4. Spot lamps adjustment.....	68
5.4.5. Bulb and fuse - replacement.....	68
5.5. Hydrostatic steering system.....	71
5.6. Front axle.....	71
5.7. Wheels.....	72
5.7.1. Front wheel track adjustment.....	72
5.7.2. Front wheels toe-in.....	72
5.7.3. Rear wheel track adjustment.....	73
5.7.4. Tyres use & maintenance.....	73
5.7.5. Wheel bearings greasing.....	73
5.8. Clutch.....	74
5.9. Transmission & rear axle maintenance.....	74
5.10. Three-point linkage.....	75
5.11. Cab and operator's seat.....	75
5.12. Braking system.....	75
5.12.1. Service break adjustment.....	76
5.12.2. Parking brake.....	76
5.13. Air braking system.....	77
5.14. Hydraulic lift.....	79
6. TRACTOR STORAGE.....	80


INTRODUCTION




This symbol warn of necessity of particularly careful due to possible risk for people and tractor damage.

Read this Manual carefully and familiarize yourself with all the controls before attempting to operate the tractor and observe the included rules.

Safety symbols




Read the operator's manual carefully.




Always start the engine from the operator's seat.



Stay clear of draft link lifting range while operating rockshaft controls.



Keep your hands away from moving parts.



Stop the engine and remove the key before you start maintenance or repair operations



Wait until all machine components have completely stopped before touching them.



Do not open or remove safety shields while engine is running.



Stay clear of articulation area while engine is running.



Do not open or remove safety shields while engine is running.



Do not ride on platform or ladder.



Stay clear of hot surfaces
- Burns to fingers or hands.



Nie usuwaj osłon ochronnych podczas pracy silnika- na osłonie wentylatora.



Stay clear of tractor while on moving



Never reach into the crushing area.

Thank you for purchasing new Farmtrac tractor.

The operator's manual complies with the requirements set out in ISO 3600:1996 standard.

This Manual has been prepared to assist you in the correct procedure for running-in, driving and operating your new tractor and to assist you in the correct method of maintenance to keep it in peak condition.

Farmtrac series of tractors have been designed and build to give maximum performance, economy and ease of operation under a wide variety of operating conditions.

Prior to delivery, your tractor was carefully inspected, both at the factory and by your Authorized Dealer to ensure that it reaches you in optimum condition. To maintain this condition and ensure trouble-free operation, it is important that the routine services, as specified in this manual, are carried out at the recommended intervals.

The vehicle reference serial number should always be quoted to the Dealer whenever tractor requires service.

Read this manual carefully and keep it at a convenient place for future reference. This manual must be considered as an integral part of your tractor. If at any time you require service or advice concerning your tractor, do not hesitate to contact your Authorized Dealer.

He has trained personnel, genuine parts and the necessary equipment to carry out all your service requirements.

When replacement parts are required, it is important that only genuine or approved service parts be used. Extensive damage may occur as a result of fitment of parts of inferior quality.

All data given in this book is subject to production variations. Dimension and weights are approximate only and the illustrations do not necessarily show tractors in standard condition. Some of the equipment / accessories described in the text may also not be fitted on your tractor. For exact information about any particular tractor, please consult your Authorized Dealer.

1. GENERAL INFORMATION

1.1. Identification data.

- Tractor identification data is located:
 - on tractor identification plate, located on the left hand side on the rear wall of Cabin and affixed with rivets, (Fig. 1a),
The plate contains tractor serial number, certificate number, etc.
- The chassis (tractor) serial number is punctured on the front axle support on right hand side of the tractor (Fig. 1b).
- The engine identification data:
 - Serial number - stuck on engine right hand side – under alternator (Fig. 1c)
 - Engine identification plate, stuck on engine left hand side - rear to hydraulic pump (Fig. 1d).
- Cabin identification data - on identification plate on R.H. side rear pillar of cabin frame (inside cabin, Fig. 1e).
- Front axle identification data - on identification plate on R.H. side of the axle housing (Fig. 1f).
- Front three point linkage identification data - on identification plate on L.H. side of the three point linkage housing (Fig. 1g).
- Clevis type mechanical coupling identification data - on identification plate on L.H. side of the Clevis (Fig. 1h).
- Mounting Frame identification data - on identification plate on L.H. side of the Frame (Fig. 1i).
- Towing Pin identification data - on identification plate on L.H. side of the Towing Pin (Fig. 1j).
- Draw Beam identification data - on identification plate on L.H. side of the Draw Beam (Fig. 1k).




Fig. 1a



Fig. 1b



Fig. 1c



Fig. 1d



Fig. 1e



Fig. 1f



Fig. 1g




Fig. 1h




Fig. 1i



Fig. 1j




Fig. 1k

Noise Statement:

External sound level:

Moving: 84.0 dB (A)

Stationary: 83.0 dB (A)

Driver exposure to noise level: 85,7 dB (A)

Vibration statement:

Vibrations felt on the operator's seat:

Load 60 Kg - $a_{wS}^* = 1,22 \text{ m/s}^2$

Load 98 Kg - $a_{wS}^* = 1,06 \text{ m/s}^2$

NOTE: Burning rate of cab interior material such as the seat covering, wall, floor and headliner coverings not exceeding 150 mm/min in accordance with ISO 3795:1989.

1.2. Safety precautions.

A careful operator is the best operator. Most accidents can be avoided by observing certain precautions to prevent the possibility of injury or damage. The following precautions should be taken to help prevent accidents. Read these carefully before operating your new Farmtrac tractor.



Important !

1. Read this Manual carefully and familiarize yourself with all the controls before attempting to operate the tractor. Working with unfamiliar equipment or lack of operating knowledge may lead to accidents.
2. Carrying of passenger is permissible only in approved passenger seat.
3. Use the foot steps and assist handles when getting on or off the tractor. It is recommended that you face the tractor when mounting or dismounting. Keep steps and platform clear of mud and debris.
4. Replace any warning sign on the tractor that becomes damaged or is painted over. Replace all missing, illegible or damaged safety decals.

Operating the tractor

1. Never start the engine while standing beside the tractor. Always sit on the tractor seat. Fasten seat belt and ensure that the Cab/ Roll Over Protective Structure (ROPS) (if fitted) is in place before starting the engine.
2. Apply the parking brake, place the PTO selection lever in the "Neutral" position, external hydraulics control lever in the "Neutral" position, the lift control levers in the down position and the transmission in neutral before starting the tractor.
3. Do not bypass the safety starter switch. Consult your Dealer if your safety start control is not operating correctly.
4. Stop the engine, bring PTO selection lever in neutral position and apply the parking brake.
5. Do not engage the parking brake while the tractor is in motion.
6. Never get off the tractor while it is in motion.
7. Never park the tractor on a steep incline.
8. To provide maximum lateral stability, add liquid ballast to tyres and cast iron wheel weights and set front and rear wheels to maximum tread width commensurate with the operation being performed.
9. Do not tie ropes, chains, or cables to the axle or other parts of the chassis. Always hitch the load to the tractor's drawbar in the lowest possible position, except when pulling implements are specifically designed and properly attached to the three point hitch.
10. If the front tends to rise with heavy implements at the rear, install front end wafer weights.
11. Ensure that an implement coupled to the three-point linkage does not collide any part of the cab (applicable to tractors fitted with cab).
12. Ensure to stay clear from the area of the three-point linkage and of the pick-up hitch when controlling them.
13. Ensure to stay clear from the area between tractor and trailed vehicle.
14. Never leave equipment in raised position. Mounted machinery must be lowered to the ground before leaving the tractor.
15. If the engine or power steering ceases operating, stop the tractor immediately.
16. Always engage Position Control when attaching equipment, transporting equipment and when no equipment is attached. Be sure hydraulic couplers are properly mounted and will disconnect safely in case of accidental detachment of the implement.
17. Ensure any attached equipment or accessories are correctly installed, are approved for use with the tractor, do not overload the tractor and are operated and maintained in accordance with the instructions issued by the equipment or accessory manufacturer.
16. Remember that your tractor, if abused or incorrectly used, can be dangerous and become a hazard both to the operator and to bystanders. Do not overload or operate with attached equipment which is unsafe, not designed for the particular task or is poorly maintained.

**WARNING:**

Hearing protection must be applied when operating this tractor if a safety cab is not fitted.

Driving the tractor

1. Before you start driving always blow the horn to warn the people operating the machine attached to your tractor, bystanders and especially children.
2. Always drive the tractor with care and at speeds compatible with safety, especially when operating over rough ground, crossing ditches or slopes, or when turning, to avoid overturning the tractor.
3. Never allow the tractor to over-run when going downhill, particularly with trailed equipment attached. Keep the tractor in the same gear when going downhill as used when going uphill. Do not coast or free-wheel down hills. Use extreme caution while operating on steep slopes and use a low gear to maintain control with minimum braking.
4. Keep the brake pedals latched together at all times unless independent braking is required. This may be used to assist turning when traveling very slowly and on headlands.
5. Reduce speed before turning or applying the brakes. Brake both the wheels simultaneously when making an emergency stop.
6. Do not engage the differential lock when turning the tractor. When engaged, the lock will prevent the tractor taking the turn and may result in overturning of the tractor.
7. If the tractor drive wheels are stuck, shift to reverse gear and back out, to prevent from lifting the front wheels off the ground and possibly rolling the tractor over backwards.
8. Slow moving vehicles on highways are dangerous. Use a slow moving (SMV) sign in conjunction with headlamps, tail lamps and flashing warning lamps.
9. Keep extreme caution and avoid hard application of the tractor brakes when towing heavy loads. Any towed vehicle whose total weight exceeds that of the tractor must be equipped with pneumatic brakes for safe operations.
10. Watch where you are going especially at row ends, on roads, around trees and any low hanging obstacle.
11. Avoid stability degradation when using heavy attached implements at height.
12. Dip the tractor lights when meeting a vehicle at night. Ensure the lights are adjusted to avoid blinding the driver of an oncoming vehicle.
13. Always check overhead clearance, especially when working in confined spaces.
14. Engage the clutch slowly when driving out of a ditch, gully or up a steep hillside. Disengage the clutch promptly if the front wheels rise off the ground.
15. Whenever possible avoid driving the tractor across slopes. Preferably drive up and down sloping fields. If it is necessary to work across slopes, proceed as follows:
 - use the widest wheel track setting compatible with the implement being used,
 - always turn uphill at the end of each run,
 - raise the implement to the height sufficient for making a turn only, or raise the implement using Position Control,
 - ensure that the rear tyre pressures are equal,
 - reduce the speed to a minimum on headlands,
 - when using a reversible plough, start at the top of the slope to reduce the tractor inclination angle by making the top wheels run in the furrow.
16. Service Tires Safely.

Explosive separation of a tire and rim parts can cause serious injury or death. Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job. Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion.

Operating the PTO

1. Ensure the PTO guard is always installed and replace the PTO shaft cap when the PTO is not being used.
2. Disengage the independent PTO clutch prior the selection of PTO. Before stopping the engine, bring the PTO selection lever in neutral position and wait for the PTO shaft to stop turning before getting off the tractor to connect or disconnect PTO driven equipment.
3. Apply the parking brake and block the rear wheels, front and rear, when operating stationary PTO driven equipment.
4. To avoid injury, never clean, unclog, adjust or service PTO driven equipment while PTO is engaged.
5. Never wear loose clothing when operating the PTO or when near equipment that is rotating.
6. Before operating implements, study the implement manufacturer's handbook. Certain implements require special operating techniques.

Servicing the tractor

1. Keep the tractor and equipment, particularly brakes and steering, maintained in a reliable and satisfactory condition to ensure your safety and comply with legal requirements.
2. Stop the engine and disconnect battery terminals before performing any service on the tractor.
3. To prevent fire or explosion, keep open flames away from the battery. To prevent sparks which could cause explosion, use jumper cables according to instructions.
4. The fuel oil in the injection system and fluid in the hydraulic system are under high pressure and can penetrate the skin. Unqualified and unauthorized persons should not remove or attempt to adjust a pump, injector, nozzle or any other part of the fuel infection system. This also may be unlawful under certain circumstances. Failure to follow these instructions can result in serious injury.
5. Do not use your hand to check for leaks. Use a piece of cardboard or paper to search for leaks.
6. Stop the engine and relieve pressure before connecting or disconnecting hydraulic or fuel lines.
7. Tighten all connections before starting the engine or pressurizing lines.
8. If fluid is injected into the skin, obtain medical attention immediately.
9. The cooling system is operated under pressure which is controlled by the radiator cap. It is dangerous to remove the cap while the system is hot. Allow the engine to cool, then turn the cap slowly to the first stop and allow the pressure to escape before removing the cap entirely.
10. Continuous long term contact with used engine oil may cause skin cancer. Avoid prolonged contact with used engine oil. Wash skin promptly with soap and water.
11. Do not run the tractor engine in a closed building without adequate ventilation as exhaust fumes may suffocate you.
12. Do not modify, or alter, or permit anyone else to modify, or alter the tractor, or any of its components, or any tractor function without first consulting your Authorized Dealer.
13. Tractor wheels are heavy. Handle them with care and ensure that, when stored, they cannot topple and cause injury.
14. Discard the used lubricating oils and filter canisters in accordance with local regulations.

1.3. Fire precautions.

1. Under no circumstances should gasoline, alcohol or blended fuels be added to fuel oil. These combinations can create an increased fire or explosive hazard. In a closed container, such as a fuel tank, these blends are more explosive than pure gasoline. **Do not use these blends.**
2. Never remove the fuel cap or refuel with the engine running or hot.
3. Do not smoke or allow an open flame near the fuel tank or while re-fuelling the tractor. Wait for the engine to cool before re-fuelling.
4. Maintain control on the fuel filler pipe nozzle when filling the tank.
5. Do not fill the fuel tank to its capacity. Allow room for expansion.
6. Wipe up spilled fuel immediately.
7. Always tighten the fuel tank cap securely.
8. If the original fuel tank cap is lost, replace it with an approved cap. A non-approved cap may not be safe.
9. Keep equipment clean and properly maintained.

10. Do not drive equipment near open fires.
11. Should the fuel catch fire, extinguish fire covering it tightly with asbestos blanket, canvas sheet or rags, or else by pouring sand or soil over the fire. Never use water to extinguish burning fuel or lubricants as this makes the fire to spread even faster. A fire extinguisher should be carried with the tractor.
12. Precautions should be taken to ensure that stored fuel is kept free of dirt, water, etc.
13. Fuel should be stored in black iron tanks, not galvanized tanks, as the galvanized coating will react with the fuel and form compounds that will contaminate the injection pump and injectors.
14. Bulk storage tanks should be installed away from direct sunlight and angled slightly so that the outlet pipe is at the higher end. In this way sediment in the tank will settle away from the outlet pipe.
15. To facilitate moisture and sediment removal, a drain plug should be provided at the lowest point (at the opposite end to the outlet pipe). If there is no filter on the outlet pipe, then a funnel with a fine mesh screen should be used when filling the tractor fuel tank.

	<p>WARNING: The fuel oil in the injecting system is pressurized and can penetrate human skin with fatal results. Adjustment of fuel injection equipment should not be carried out by unqualified persons.</p>
---	--

Safety frame or roll bar (where fitted)

Your tractor is equipped with a CAB/ROPS which must be maintained in a serviceable condition. Be careful when driving through doorways or working in confined spaces with low headroom.

Do not:

- I) Modify, drill, weld or alter the CAB/ROPS in any way. Doing so could render you liable to legal prosecution in some counties.
- II) Attempt to straighten or weld any part of the CAB/ROPS or retaining brackets which have suffered damage. By doing so you may weaken the structure and endanger your safety.
- III) Secure any parts on the CAB/ROPS or attach it with other than special high tensile bolts and nuts specified.
- IV) Attach chains or ropes to the CAB/ROPS for pulling purposes.
- V) Take unnecessary risks even though your CAB/ROPS affords you the maximum protection possible.

1.4. Warranty.

FARMTRAC TRACTORS EUROPE, when selling tractors to its Authorized Dealers, gives a warranty which, subject to certain conditions guarantees that tractors are free from defects in material and workmanship.

Each FARMTRAC TRACTORS EUROPE Authorized Dealer is required to give a similar warranty for the benefit of the first retail purchaser of a new tractor supplied by FARMTRAC TRACTORS EUROPE.

Under the terms of warranty the purchaser is entitled to a specified, service inspections and repairs including parts replacement, if the manufacturer is responsible for the defect.

NOTE:	FARMTRAC TRACTORS EUROPE will not accept responsibility for any claim resulting from the fitment of non-approved parts or attachments, or unauthorized modification or alteration.
--------------	--

NOTE:	Repairs of parts protected with seals can be carried out by an Authorized Dealer only. Arbitrary removal or breaking of the seal may lead to warranty invalidation.
--------------	---

1.5. Tractor delivery to purchaser.

The Dealer is required to carry out certain activities when supplying a new Farmtrac tractor.

This consist of a full pre-delivery inspection to ensure that the tractor supplied is ready for immediate use and full instructions in the basic principles of operation and maintenance of the tractor. These instructions will cover instruments and controls, routine maintenance and safety precautions. All persons who will be concerned with the operation and maintenance of the machine should be present for these instructions.

The following check list items should be covered by the Dealer during the tractor handing over:

- all safety points and decals on the tractor and in the Operator's Manual,
- location and significance of tractor and engine serial numbers,
- use of all instruments and controls,
- running in procedure,
- engine starting and stopping procedure, when hot and cold,
- driving the tractor, starting and stopping,
- gear selection for the particular operation to be performed,
- towing of the tractor,
- use and adjustment of clutches,
- brakes, latched and unlatched, method of adjustment,
- differential lock, its engagement, disengagement and adjustment,
- use of power take-off,
- how to use the hydraulic lift system, attach/detach implements and use of stabilizers.
- use of external hydraulics,
- four-wheel drive, its engagement and disengagement,
- the method of making the wheel track adjustments, front wheel alignment and use of correct tyre pressure,
- cooling system, frost precautions and fan belt adjustment.
- maintenance of the engine air cleaner,
- fuel system and how to remove the air,
- electrical system maintenance,
- bolts and nuts fastening,
- grease points,
- oil changes and location of drain plugs, filler plugs and dipsticks,
- filter replacement and cleaning,
- transport and storage of fuel,
- warranty entitlement and the services due during the warranty period.

Pre-delivery inspection

The following items must be checked, and where necessary, corrected by the Dealer before delivery:

1. Verify serial numbers of the tractor and engine.
2. Assemble parts removed for transport.
3. Check the tractor against its specification.
4. Examine the condition of factory seals.
5. Remove water and impurities from water trap and bleed the fuel system.
6. Check the liquid level in the cooling system and in screen washer system.
7. Check the oil level in all system.
8. Check the battery electrolyte level and electrolyte concentration.
9. Lubricate all grease points, if necessary.
10. Check for tightness and locking all external nuts, bolts, screw, plugs, connections, and clamping bands (special attention should be paid to air intake and cooling system hose and pipe connections).
11. Ensure that pipes, hoses and wiring are not fouling exhaust system or sharp edges.
12. Check the fan and air compressor (if fitted) V-belt tension.
13. Check clutch pedal free travel.
14. Check tyre pressure.
15. Check front wheel alignment and hub bearings for play.
16. Check the safety start switch function.
17. Check the headlight setting.
18. Road test the tractor checking all instruments, controls and services for correct function.
19. After road test, check for leaks.

2. TECHNICAL SPECIFICATION.

Specification / Tractor model	FT 9100 DT V	FT 9105 DT V	FT 9120 DT V	FT 9125 DT V	FT 9130 DT V
-------------------------------	-----------------	-----------------	-----------------	-----------------	-----------------

2.1. Engine.

Engine model	PERKINS Engine 904J-E36TADDS				
Engine type	four stroke, water-cooled, turbocharged, direct injection diesel, exhaust after-treatment system				
Number of cylinders	4, vertical, in-line				
Bore / stroke	98 / 120 [mm]				
Capacity	3621 [cm ³]				
Compression ratio	16.77:1+0.55/-0.51				
Engine rated power	70,0 [kW]	74,4 [kW]	82,0 [kW]	85,9 [kW]	90,0 [kW]
Engine rated speed	2200 [rpm]				
Maximum engine torque	410 [Nm]	430 [Nm]	450 [Nm]	500 [Nm]	500 [Nm]
	at 1500 rpm				
Low idle speed, rpm	900-110/+310 [rpm]				
Valve clearances (on cold engine)	As per engine manufacturer				
- inlet valve					
- exhaust valve					

Fuel System

Fuel Feed pump	Electrical
Recommended fuel:	Diesel fuel
- summer	B w/g PN-EN 590+A1:2017
- interim period	D w/g PN-EN 590+A1:2017
- winter	F w/g PN-EN 590+A1:2017
Fuel tank capacity	160 [dm ³]

Lubrication System

Type	Full flow, force feed and splash
Pump type	Eccentric
Oil pressure engine at 2400 rpm speed and oil rated temperature	400 kPa
Oil filter type	Spin on, throw away type
Lubricating system capacity	10 dm ³
Recommended oil	API CK-4 (CJ-4)

Cooling System

Type	Pressurised recirculation, by pass with radiator, fan, thermostat
Cooling system capacity, litres	17,0 dm ³
Recommended coolant	see coolant specification

Air cleaner

Type	dry type, two-stage, in front of radiator
------	---

2.2. Electrical System.

Type	single line, 12V with negative to ground
Alternator	14V, 120A
Battery	12V, 170 Ah, 1000A EN
Starter motor	12V/3,2 kW
Starting aid	glow plug
Electrical socket	Seven pin socket, 12N

2.3. Transmission.

Clutch.

Type	friction type, dry, two-disc clutch with independent control of PTO clutch
Pedal free travel (Transmission clutch)	25 ÷ 35 mm
Actuation	Transmission clutch – foot pedal, PTO clutch – hydraulic

Gearbox with range lever

Type	CARRARO mechanical, with constant mesh gears	
Gearbox	24x24	12x12
Number of gears in gearbox	4 + 4R	
Number of reduction gears	3	
Number of speed ranges	2	-
Total number of forward/reverse gears	24 F; 24 R	12 F; 12 R
Gearbox control	manual by means of four levers	manual by means of three levers
Oil capacity	See rear axle	

Rear Axle

Type	CARRARO, bevel tooth crown wheel and pinion	
Recommended oil	API GL-4 10W-40	
Oil capacity: gear box, rear axle, hydraulic system	52,0 dm ³	
Other	safety start	

Front axle

Type	CARRARO, crown wheel and pinion	
Differential - differential lock	automatic	
Final reduction gears - oil capacity	2 x 0,8 dm ³	
Axle housing oil capacity	6.0 dm ³	
Recommended oil	API GL-4 80W-90	

Power Take-Off - PTO

Type	independent and ground
PTO clutch control	hydraulic
PTO shaft end	Type 1 per PN-86/R-36101 - 6 (ISO 500)
Height above ground	695 mm
Independent PTO shaft speed	540 rpm at 1938 rpm 540E at 1648 rpm (option) 1000 rpm at 1961 rpm
Engine – PTO ratio	at 540 rpm. - 3,588 at 540E - 3,053 (option) at 1000 rpm - 1,961
Rotation	rightwards, from tractor end

FARMTRAC 9120 DTN - CALCULATED SPEED																									
TRANSMISSION 24x24 - SPEED IN KM/H AT ENGINE RATED RPM -2200																									
Forward speeds																									
Tyre size	Gear	1LL	1LH	2LL	2LH	3LL	3LH	4LL	4LH	1ML	1MH	2ML	2MH	3ML	3MH	4ML	4MH	1HL	1HH	2HL	2HH	3HL	3HH	4HL	4HH
230/95R36	5 deep	0,49	0,58	0,72	0,84	1,04	1,22	1,50	1,76	2,12	2,49	3,10	3,63	4,48	5,25	6,49	7,61	8,72	10,22	12,72	14,92	18,40	21,58	26,63	31,24
420/85R34		0,55	0,65	0,81	0,95	1,17	1,37	1,69	1,98	2,39	2,81	3,49	4,09	5,05	5,92	7,31	8,57	9,82	11,52	14,33	16,81	20,73	24,32	30,02	35,21
16.9R34		0,56	0,66	0,82	0,96	1,18	1,38	1,71	2,00	2,42	2,83	3,53	4,13	5,10	5,98	7,38	8,66	9,92	11,64	14,48	16,98	20,94	24,56	30,31	35,55
480/70R34		0,56	0,66	0,82	0,96	1,18	1,39	1,71	2,01	2,42	2,84	3,53	4,14	5,10	5,99	7,39	8,67	9,93	11,65	14,49	16,99	20,95	24,58	30,34	35,58
540/65R34	0,57	0,66	0,83	0,97	1,19	1,40	1,73	2,03	2,44	2,87	3,57	4,18	5,16	6,05	7,47	8,76	10,04	11,78	14,65	17,18	21,19	24,85	30,68	35,98	
18.4R34	0,58	0,68	0,85	1,00	1,23	1,44	1,78	2,09	2,52	2,96	3,68	4,31	5,32	6,24	7,70	9,04	10,35	12,14	15,11	17,72	21,85	25,63	31,63	37,10	
Reverse speeds																									
Tyre size	Gear	1LL	1LH	2LL	2LH	3LL	3LH	4LL	4LH	1ML	1MH	2ML	2MH	3ML	3MH	4ML	4MH	1HL	1HH	2HL	2HH	3HL	3HH	4HL	4HH
230/95R36	5 deep	-0,46	-0,54	-0,68	-0,80	-0,98	-1,15	-1,44	-1,69	-2,01	-2,35	-2,93	-3,44	-4,23	-4,96	-6,21	-7,28	-8,24	-9,66	-12,05	-14,13	-17,37	-20,37	-25,50	-29,91
420/85R34		-0,52	-0,61	-0,77	-0,90	-1,10	-1,29	-1,62	-1,90	-2,26	-2,65	-3,31	-3,88	-4,77	-5,59	-7,00	-8,21	-9,28	-10,89	-13,58	-15,92	-19,58	-22,96	-28,74	-33,71
16.9R34		-0,53	-0,62	-0,77	-0,91	-1,11	-1,31	-1,64	-1,92	-2,28	-2,68	-3,34	-3,92	-4,81	-5,65	-7,07	-8,29	-9,37	-11,00	-13,71	-16,08	-19,77	-23,19	-29,02	-34,04
480/70R34		-0,53	-0,62	-0,77	-0,91	-1,12	-1,31	-1,64	-1,92	-2,28	-2,68	-3,34	-3,92	-4,82	-5,65	-7,07	-8,30	-9,38	-11,01	-13,72	-16,09	-19,79	-23,21	-29,05	-34,07
540/65R34	-0,53	-0,63	-0,78	-0,92	-1,13	-1,32	-1,66	-1,94	-2,31	-2,71	-3,38	-3,96	-4,87	-5,71	-7,15	-8,39	-9,49	-11,13	-13,87	-16,27	-20,01	-23,47	-29,37	-34,45	
18.4R34	-0,55	-0,65	-0,81	-0,95	-1,16	-1,36	-1,71	-2,00	-2,38	-2,79	-3,48	-4,09	-5,02	-5,89	-7,38	-8,65	-9,78	-11,47	-14,31	-16,78	-20,63	-24,20	-30,29	-35,52	

2.4. Hydraulic lift system.

Type	piston type with position & draft control
Hydraulic pump type	gear
Hydraulic pump capacity- at 2200 rpm	50 dm ³ /min
Nominal Pressure	17 - 19 MPa
Number of quick couplings for external hydraulics	6
Quick couplings type	ISO 12.5
Oil filter	on the suction side of the pump
External hydraulics	control of three double acting or six single acting ram cylinders
Temporary oil rate flow taken from transmission	8 l

2.5. Three-point linkage.

Type	lever type, accordant to PN-88/R-36110
Category	2 per ISO 730-1:1994
Lifting capacity at the ends of lower links in horizontal position	4500 kg

2.6. Coupling devices.

Type			Clevis type mechanical coupling	Pin (piton) type mechanical coupling	Tractor drawbar
Manufacturer's type designation:			3200	563301	1306
Maximum horizontal load:			89.3 kN	89.3 kN	86 kN
Towable mass :			16 t	16 t	16 t
Maximum permissible vertical load on coupling point:			20 kN	30 kN	800 kg
Position of coupling point	height above ground	min.	417 mm	409 mm	377 mm
		max.	865 mm	484 mm	452 mm
	distance from vertical plane through axis of rear axle	min.	624 mm	597 mm	895 mm
		max.	624 mm	597 mm	895 mm

2.7. Steering system.

Type	hydrostatic
Steering wheel diameter	380 mm
Number of steering wheel revolutions from lock to lock	3,5

2.8. Wheels & axles.

Front axle type	rigid, swivel pin mounted, driven
Rear wheels: Rim size Tire size - standard Wheel track Recommended inflation pressures:	W15Lx34 480/70 R34 1908 mm 160 kPa (480/70 R34)
Front wheels: Toe-in Rim size Tire size - standard Wheel track Recommended inflation pressures:	0 ÷ -8 mm W12x24 340/85 R24 1920 mm 160 kPa (340/85 R24)

2.9. Braking system.

Service brake: Type Control Acting on	wet, disc type hydraulic, foot control, with possibility of left & right wheel independent braking rear axle 2 wheels
Emergency brake:	function fulfilled by parking and service brake
Parking brake Type Control Acting on	wet, disc type mechanical, hand lever operated rear axle wheels
Trailer air braking system. Air reservoir capacity Standard air pressure Pressure drop at warning lamp on	over-pressured, single-line or triple-line type 15 dm ³ 810 ^{±20} kPa 450 ^{±50} kPa

2.10. Tractor weight.

Weight of tractor in running order, kg	3903÷4090 kg
Weight distribution on axle, kg: front rear	1414÷1480 kg 2610÷2489 kg
Maximum permissible weight of tractor,	6000 kg
Maximum permissible load on axle kg: front rear	2500 kg 3500 kg
Technically permissible tractor towable mass: Unbraked Inertia braked Hydraulic or pneumatic braked	1500 kg 5000 kg 16000 kg
Total technically permissible mass of the combination of tractor with a towed vehicle: Unbraked Inertia braked Hydraulic or pneumatic braked	7500 kg 9500 kg 20500 kg
Ballast weights	
Front axle	$10 \times 22 + 1 \times 40 = 260$ kg
Rear axle	$2 \times 39 + 4 \times 32 = 206$ kg

2.11. Tractor dimensions.

Overall length, mm	3684÷4567 mm
Overall width, mm	2000÷2400 mm
Overall height, mm	2610÷2773 mm
Wheelbase, mm	2470 mm
Ground clearance, mm	314÷477 mm
Minimum turning circle without independent braking to the left/right, mm:	9354 mm

3. INSTRUMENT PANEL AND CONTROL DEVICES

3.1. Instrument Panel.

The following text describes the various gauges, switches, warning lamps and control levers situated on the instrument panel, or close to it (Fig 3.1).



Fig. 3.1 Instrument panel and control devices, see description below.

Description of elements shown on Fig 3.1

1. Instrument panel

Description on following pages.

2. Lever for steering column inclination angle adjustment

In order to adjust steering column inclination angle turn the adjustment lever counter clockwise and set the steering wheel is in desired position. After so, turn the lever clockwise to lock the steering column movement.

3. Engine bonnet electric lock release button

4. Shuttle lever (described in chapter 3.2)

5. Steering column combined switch

Steering column combined switch is operational when the ignition is on:

- Downward: left direction indicator,
- Upwards: right direction indicator,
- Push-in: horn,
- First step by rotation: parking lamps,
- Second step by rotation: dimmed beams,
- Push backward: long beams.

6. Hand throttle

This lever is used to selected engine speed. Pull the lever backwards to progressively increase the engine speed. Push the throttle lever forwards to decrease the engine speed.

When traveling on the road, the foot throttle should be used, and the hand throttle lever should be brought to the closed position.

10. Ignition starter switch

Four positions Ignition starter switch. By turning the key clockwise, the positions are:

0. OFF

1. Through 30° - Switches on electrical consumers when the engine is not running.

2. Key turned for next 30° - In this position the glow plugs are energized for cold engine starting.

3. Key turned for next 30° - In this position starter motor is turned on. When the key is released, the key returns automatically to the 2 position.

By turning the key back to position 0 the engine is switched off.

12. Front PTO switch – optional

13. Differential lock switch

14. PTO clutch switch

This is used to engage or disengage the drive to the PTO shaft. When the warning lamp on the switch button is on, the PTO drive is engaged. To disengage the PTO drive, push the switch button and the warning lamp will get off showing the PTO drive is disengaged.

NOTE: Set the PTO clutch switch to disengaged position (PTO drive warning lamp is off) while shifting the PTO selector lever to engaged or neutral position.

15. Front wheel drive switch

This is used to engage the front drive.

The front drive should only be used when operating in field conditions. Do not operate the tractor in four wheel drive on the road (with the exception of uphill driving) as this may lead to premature wear of front tyres and excessive fuel consumption.

Before engage / disengage front drive, push clutch pedal.

17. Hazard warning lamps switch

By pressing on the switch the hazard warning lamps are turned on. All direction indicators flash simultaneously. Hazard warning indicators operate in any position of the starter switch.

18. Fuse box cover

To gain access remove screw shown with the arrow.

19. External hydraulics control levers

For detailed operating instructions, see section 4.5.2.

20. Range lever

The range lever is used to select road (HI) or field (LO) gear train. The shift pattern is placed on the top of the lever knob. When shifting, the clutch pedal must be pressed.

21. EHR Hitch Control Panel

For detailed operating instructions, see section 4.5.1.

23. Air conditioning control panel - optional

Tractors are optionally equipped with an air-conditioned cabin.

Air conditioning ensures optimal temperature and low humidity in the cabin.

For a detailed description, see section 3.3.

24. Radio player

25. Roof LH flasher lamp switch

26. Roof RH flasher lamp switch

27. Front roof work lamps switch

28. Rear roof work lamps switch

29. Front windscreen wiper switch

The switch has 3 position:

0 – Wiper and washer off

1 – Wiper on

2 – Wiper and washer on

30. Rear window wiper switch

31. 3 pin 12 Volt socket

32. 12 Volt socket

Instrument panel – indicators









Fig. 3.2. Instrument panel - indicators

Instrument panel - indicator lamps description (1 - Fig. 3.1)

1.		Turn indicator left lamp green
2.		Dipped beam indicator lamp green This lamp illuminates as soon as the dipped beam headlamps are switched on.
3.		Main beam indicator lamp blue This lamp illuminates when the headlamps are switched to main beam.

4.	-	Not applicable
5.	-	Not applicable
6.		Engine pre-heat indicator lamp yellow This lamp illuminates when the start switch is in PRE-HEAT position and the glow plugs are activated.
7.		Hazard warning lamp red This lamp flashes simultaneously with the direction indicators
8.		Interior directed illumination lamp green
9.		Position lamps; side lamps This lamp indicate the status of the position lamps or side lamps.
10.		Engine coolant temperature indicator lamp yellow This lamp indicate that the engine coolant may be overheating or fails outside of specified parameters.
11.		Engine oil pressure warning lamp yellow This lamp illuminates if the pressure in the engine lubrication system is too low. If the lamp illuminates during engine operation, check the engine oil level.
12.		Fuel level indicator lamp yellow This lamp illuminates if there is approximately 17 litres of fuel left in the reservoir.
13.		Battery charging warning lamp red It must shut down when the engine is running. Alternator warning lamp illuminates if there is a fault in the battery charging system. When possible investigate the cause of the fault, otherwise the battery will be fully discharged.
14.		Turn indicator right lamp green
15.		Parking brake warning lamp red This lamp illuminates when parking brake is applied.
16.		Transmission failure/malfunction indicator lamp yellow This lamp illuminates to indicate that the transmission has failed or is malfunctioning
17.		Hydraulic oil temperature indicator lamp yellow This lamp illuminates when the oil temperature in the hydraulic system is excessively high.
18.		Engine intake temperature indicator lamp yellow This lamp illuminates when the intake air temperature is excessively high.
19.		The warning lamp improper operation of the engine yellow When the lamp illuminates while engine is running, find the cause of system malfunction or contact your authorized service centre.
20.		Engine lubricating oil pressure indicator lamp yellow This lamp illuminates when the oil pressure in the engine lubrication system is low.
21.		Engine failure warning lamp red When the engine is started, the lamp should go off. If during engine operation lamp is on, stop engine immediately and contact an authorized service centre.
22.		Hydraulic oil pressure warning lamp red This lamp illuminates to indicate the oil pressure in the hydraulic system is low.
23.		Tyre failure/malfunction indicator lamp yellow This lamp illuminates to indicate that tyre pressure is outside of normal operating parameters.
24.	-	Not applicable

26.		Engine intake air filter; engine combustion air filter yellow This lamp illuminates to indicate that the engine intake air filter is clogged
27.		Hydraulic oil filter contamination indicator lamp yellow This lamp illuminates when the hydraulic filter is excessively contaminated. In this case, the filter element must be checked and replaced if necessary
28.		Differential lock indicator lamp yellow This lamp illuminates if the rear differential lock is applied. Never use the differential lock on dry road and during sharp cornering. Differential lock must be switched off as soon as possible.
29.		High degree of soot accumulation in DPF filter indicator lamp yellow This lamp illuminates when soot level accumulation in DPF filter exceeds 130%
30.		Active regeneration process interruption indicator lamp yellow This lamp illuminates when active regeneration of the DPF has been interrupted.
31.		Steering system malfunction warning lamp red This lamp illuminates in case of hydrostatic steering system failure
32.		LCD central display software version
33.		Exhaust system high temperature indicator lamp yellow This lamp illuminates during active regeneration process of DPF filter indicating the high temperature of exhaust system. During DPF filter active regeneration fuel consumption increases
34.		Four wheel drive indicator lamp yellow Four wheel indicator lamp illuminates if the four wheel drive is engaged. Four wheel drive is engaged by use of the four wheel drive engagement switch or by pressing of both brake pedals. The indicator lamp illuminates also if the oil pressure in control circuit drops (for example if the engine is switched off).
35.		Rotation beacon lamp indicator lamp yellow This illuminates when rotation beacon lamp on the roof is on
36.		PTO clutch indicator lamp yellow This lamp illuminates when PTO clutch is engaged (PTO drive is not transferred). The PTO clutch switch can be used for short time (PTO drive disengaged). Keeping PTO clutch disengaged for longer may cause the clutch failure).
37.	-	Not applicable
38.		Air pressure warning light red This lamp illuminates when the air pressure in trailer brake system falls too low.
39.		Engine malfunction indicator lamp yellow This lamp illuminates to indicate that the engine has failed or is malfunctioning or is not operating within the specified range of parameters. Find the cause of system malfunction or contact your authorized service centre.
40.		Engine pre-heat indicator lamp yellow This lamp illuminates when the start switch is in PRE-HEAT position and the glow plugs are activated.
41.		Engine oil pressure warning lamp red This lamp illuminates if the pressure in the engine lubrication system is too low. If the lamp illuminates during engine operation, immediately stop the engine and check the engine oil level. It must shut down when the engine is started.
42.		Selective catalytic reduction (SCR) fluid indicator lamp blue This lamp illuminates when the fluid used to reduce emissions from the engine operation by means of selective catalytic reaction level is low.
43.		Engine current load indicator Indicates the current engine load in the range of 0 to 100%
44.		Engine coolant high temperature indicator lamp red This lamp illuminates to indicate that the engine coolant may be overheating or fails outside of specified parameters.

45.		Engine oil low level warning lamp - yellow This lamp illuminates to indicate engine oil level is low. If the lamp is on when the engine is running, check the engine oil level.
46.		Front PTO speed indicator Indicates PTO shaft current speed in rev/min. If PTO drive is in neutral position, the field is blank
47.		Rear PTO speed indicator Indicates PTO shaft current speed in rev/min. If PTO drive is in neutral position, the field is blank.
50.		Engine revolutions counter / Driving speed indicator Indicates current engine rpm. / Indicates current vehicle speed
51.		Selective catalytic reduction (SCR) fluid level indicator This lamp illuminates the fluid used to reduce emissions from operation of the diesel engine by means of selective catalytic reaction low level.
52.		Engine coolant temperature indicator Indicates temperature of engine coolant.
53.		Fuel level indicator Indicates the current fuel level. Red area shows 0÷17 litres of fuel in the tank.
54.		Air system pressure indicator Indicates current pressure in tractor pneumatic system in kPa
55.		Menu Enabling enter additional screen - optional
56.		Voltmeter Indicates the current battery voltage

NOTE: The front drive should only be used when operating in field conditions. Do not operate the tractor in four wheel drive on the road (with the exception of uphill driving) as this may lead to premature wear of front tires and excessive fuel consumption.
Before engage / disengage front drive, push clutch pedal.

WARNING:  Disengage PTO clutch only for time needed to switch the control levers position! The PTO clutch switch can be used for short time (PTO drive disengaged – control lamp on).
Keeping PTO clutch disengaged for longer may cause the clutch failure.

3.2. Control levers and pedals (Fig. 3.3).




Fig. 3.4 Control levers and pedals, see description below

1. Clutch pedal

When this pedal is fully pressed, the drive to the wheels will be disengaged. Clutch pedal must be depressed fully every time any of the three gear levers (main, range or shuttle) is operated.

2, 3. Service brake pedals

The service brake system is mechanically actuated. The two brake pedals can either be used independently (to aid turning in confined spaces) or locked together using latch to provide a master pedal for normal braking. For independent braking, disengage the latch (5). Then the inner pedal (2) actuates the brake of rear L.H. wheel and the outer pedal (3) – the brake of rear R.H. wheel.

4. Foot throttle pedal orange

Operation of the foot throttle overrides the hand throttle (6 fig. 3.1) setting when increasing the engine speed. When the foot throttle is released, the engine returns to the speed set by the hand throttle. When foot throttle is used the hand throttle should be brought to the closed position.

5. Brake pedals locking latch

11. Electric ground switch

The ground switch should be off at least 2 minutes after the engine is shutdown. Early engine shutdown may damage the engine control module and the selective catalytic reduction system (AdBlue).

12. Parking brake lever

Parking brake is used to lock the tractor rear wheels for parking and/or stationary operation. To engage the parking brake, latch the service brakes together and press them down. Then pull the hand lever up.

To release the parking brake, press the service brake pedals down, then press the button on the end of the lever and push the lever down.

13. PTO selector lever yellow


This lever has three positions as shown on the decal situated by the lever:

- 1 - upper position – engine speed PTO engaged,
- 2 - centre position – neutral,
- 3 - bottom position – ground speed PTO engaged.

When moving the lever, always disengage the PTO clutch with switch (14 fig. 3.1).

NOTE: Keep the PTO clutch always in engaged condition irrespective of whether the PTO is in use or not.
Press the transmission clutch for shifting the PTO selector lever from neutral to ground speed PTO and vice-versa.

Position of gear selection levers.



14. Main gear lever orange

The main gear lever is used to select the gearbox ratio and has four positions. When shifting, the clutch pedal must be pressed.

15. Reduction lever orange

The range lever is used to select high (H), medium (M) or low (L) gear train. The shift pattern is placed on the top of the lever knob. Select the range according to the load and speed requirement. When shifting, the clutch pedal must be pressed

Shuttle lever (4 - Fig. 3.1) orange

The shift pattern is given on the top of the lever knob. The lever has three positions:

- F - Forwards,
- Centre - Neutral,
- R - Backwards.

When shifting, the clutch pedal must be pressed

Range lever (20 - Fig. 3.1) orange

The range lever is used to select road (HI) or field (LO) gear train. The shift pattern is placed on the top of the lever knob. When shifting, the clutch pedal must be pressed.

WARNING:

1. The shuttle control is linked to the safety start switch. Set the shuttle lever in the center position before operating the starter switch key.
2. There is a lock provided between the shuttle lever and the clutch mechanism. Whenever the shuttle lever is operated always stop the tractor and press the clutch pedal, otherwise the shuttle control mechanism may get damaged.

PTO 1000 rpm or 540 engagement lever yellow

In case of need of operation with PTO high rotation (1000 rpm or 540) implements, shift forward the lever placed above PTO shaft end (9 - Fig. 4.6.1).

WARNING: Shift the PTO rpm lever only at PTO clutch (14 - Fig. 3.1) disengaged and PTO lever at neutral position (13 - Fig. 3.4).

**3.3. Tractor cab**

The safety type cab (fig. 3.5) protects the operator against adverse weather conditions and serious injuries in case of the tractor overturning. The cab has two doors which can be blocked in open position.

Ventilation of the cab interior is possible through deflectable side and rear windows, roof hatch and forced air circulation.

The window panes are made of a safety type glass. The R.H. side door is opened by means of key. To open, insert the key, turn it through 90°, remove the key and press the button. The other door is locked by means of latch located at the bottom of the lock.

To open the roof hatch (9), press the button on the hatch handle (10) and push the hatch upwards.

To open the rear hatch (16):

- press the button on rear hatch handle (17),
- push the rear hatch backwards.

The opening angle of the rear hatch is maintained automatically due to the action of two damper.

**WARNING:**

In emergency, when leaving the cab through the door is impossible, the tailgate can be used as emergency exit. To open it fully, push sharply on the handle to disengage the dampers from their sockets.

Standard equipment of the cab comprises:

- led work lamps - 2 pcs. at the front (1) and at the rear of the cab roof (7).
- adjustable side rear view mirrors (2),
- wipers of windscreen (3) and rear window (6),
- windscreen washer,
- air filter (5),
- heating and ventilation system (warm or cold air is blown through roof nozzles (11)
- Internal lamp (12),
- sun visor (14) with unlock on RH side (15),

Upon request, radio (24 – fig. 3.1) and loudspeakers (13) can be fitted.




Fig. 3.5. Tractor cab.



WARNING:

To prevent falling while entering and leaving the tractor, use the handrail and steps. Remove of mud, snow, ice and debris from the steps.



WARNING:

Cabin does not satisfies the requirements of the prevention of exposure to hazardous substances in accordance with EN 15695-1: 2009. In order to protect observe the principles of protection specified for the product. Besides using appropriate filters, you should also use personal protective equipment.



WARNING:

Tractor in this version is not suitable for forestry work, therefore, the requirements of ISO 8084: 2003 for operator protection structure (OPS) are not met.

NOTE: Cabin complies with OECD Code 10 (Falling Objects) (FOPS)

NOTE: Burning rate of cab interior material such as the seat covering, wall, floor and headliner coverings not exceeding 150 mm/min in accordance with ISO 3795:1989.

3.4. Air conditioning control panel



Fig. 3.6. Air conditioning control panel.

To start the air conditioning with the engine running, switch on the blower 1, select the desired ventilation range 2. Then start the air conditioner 3, the lamp 4 indicates the condition of the air conditioner. Set the desired temperature level with the control buttons 5 and 6. The set temperature value will be displayed on the display 7.
8 - function not supported.



WARNING:

The closed circuit of the air conditioning system is filled with a refrigerant R134a under pressure.
In no case should the tractor's air conditioning system be opened.
In case of damage (leaks, valve failures, etc.), please contact the Authorized Service.
Do not let the working medium into the atmosphere!

3.5. Operator's seat adjustments

Suspended seat, with a gradual, horizontal and vertical shift and smooth amortization stiffness regulation, depending on the operator weight.

Seat position adjustment elements are shown in Fig. 3.7

Adjustment of seat suspension hardness to operator weight (50 ÷ 130 kg) is adjusted when the engine is running - pull lever 1 upwards shortly. The seat adjusts automatically to the weight of the operator.

Note: To avoid damage to the compressor use adjustment once for no longer than 1 minute.

Height adjustment can be done by turning the knob 2 to the left or right depending on your needs. Movement of the seat forward / reverse is blocked with the lever 3 in the forward position - the suspension does not move, the lever to backward position - suspension moves forward / backward. To move the seat horizontally, unlock the latch with lever 4 and move the seat to the desired position, then release the latch.

The level of armrests 7 inclination is adjusted using the knob 6 at the bottom of the armrest.

The height of the headrest 8 can be adapted to individual requirements by pulling or inserting. To remove the headrest, strongly jerk up against the resistance of the latch limiting maximum extension.

To change inclination of the backrest is used the lever 12.

The seat has the ability to turn. To do this, pull the lever 5.

The function of rotation can only be used during tractor stay in order to facilitate entering the cabin. The lap a safety belt should be fastened to the holes on either side of the seat.




Fig. 3.7. Operator 's seat.

3.6. Passenger seat - option.

The tractor can optionally be equipped with a folding passenger seat located in the cab left side (fig. 3.8).

To unfold the seat, unlock the latch with the lever 1 and move the seat to the vertical position, then turn it by 90 ° counterclockwise and move it to the horizontal position and block the pin in the hole 2. After the passenger is seated, fasten the lap belt 3.



Rys. 3.8. Passenger seat - option.

4. OPERATION.

4.1. Tractor running in.

Your new tractor will provide long and dependable service if given proper care during the first 50 hours running in period and if serviced at the recommended intervals. Therefore, the following precaution should be taken during the running-in period:

- after reaching the operating temperatures, engage the tractor in work which will load the engine as near as possible to full load conditions,
- avoid prolonged operation without a load on engine,
- avoid overloading of the engine. Operating in too high gear under heavy load may cause excessive engine overloading. Overloading occurs when the engine will not respond to a throttle increase,
- to ensure proper clutch life, during the first 15 hours of operation keep careful watch on the clutch pedal free travel. If its decrease is found, adjust it immediately,
- frequently and regularly check the tightness of all external bolts, nuts. This is especially true of wheel retaining bolts/nuts,
- check the instruments frequently and keep the radiator and various oil reservoirs filled to the recommended levels.

After first 50 hours of operation, i.e. when the running in period is completed, first technical inspection should be carried out according to the list given in the Periodic Maintenance Chart – see Table 4, Section 5.1.

4.2. Starting and stopping the engine.

Before starting

Prior to daily start-up of the tractor, carry out the Daily Maintenance as described in Periodic Maintenance Chart (every 10 hours of operation) and particularly:

- make sure all safety shields are in place and secured properly,
- check coolant and engine oil levels and replenish as necessary,
- check the tension of belts and adjust as required,
- ensure the grill and the radiator are clear of debris to provide adequate engine cooling,
- switch on the ground switch (11 – Fig. 3.4.)
- check operation of clutch, brake and throttle controls. All controls must operate freely and be adjusted correctly,
- carry out general inspection of tyres, tyre pressure and wheel nuts/bolts tightness. Observe for external signs of leakage and correct before operating the tractor,
- ensure that there is sufficient fuel in the tank and the fuel tap is open.
- check operation of lamps and warning flashers. If tractor is to be driven on public roads, ensure the mirrors and slow moving vehicle emblem are in place,
- make sure the brake pedals are latched together and apply the parking brake
- make sure the main gear lever and range lever are in neutral position,
- set the hydraulic controls to “DOWN-LOWERING” position and the PTO selector lever is in neutral position

NOTE:	Tractor is fitted with safety switch device. Only the range lever center position enables engine starting. In any other range lever position the safety start switch automatically disconnects the starter motor.
--------------	---

NOTE:	The control levers of upper and lower couplers of the external hydraulics, when moved to operating position, will be kept there by the lock. To release the lever, move it by hand to the neutral position.
--------------	---

**WARNING:**

Do not leave this lever s in operating position, front or reverse, if not needed, otherwise the hydraulic pump may get damaged.

**WARNING:**

Start the tractor only from the operator's seat

Starting the engine**Normal starting procedure** (at the ambient temperatures above 5°C)

To start the engine, proceed as follows:

- engage clutch pressing clutch pedal,
- turn the starter switch ignition key (10–Fig. 3.1.) fully to 3 position to engage the starter motor,
- release the key the moment the engine starts, allowing it to return to 2 position,
- release the clutch pedal slowly and adjust the engine speed control to get an even idle speed.

NOTE:

Do not crank the motor for more than 5 seconds. Allow the starter to cool (at least 30 seconds) between intervals of cranking.

Cold weather starting procedure (at ambient temperatures below 5°C)

Press the clutch pedal and turn the ignition key (10 - Fig. 3.1) to position 2, the glow plug indicator lamp is on (6 - Fig. 3.2).

Wait until the warning lamp goes out.

Turn the key in the same direction to crank the engine (position 3).

After engine start release the ignition key, which automatically return to the position 2.

NOTE:

Be sure to use the right fuel at a specific ambient temperature.

Stopping the engine

To stop the engine, turn the starter switch ignition key (10–Fig. 3.1.) to 0 position.

NOTE:

If the engine has been operating at high rpm and/or high loads, run at low idle for at least three minutes to reduce and stabilize internal engine temperature before stopping the engine.
Stopping the engine immediately after it has been working under load can result in overheating and accelerated wear of the engine components.

Avoiding hot engine shutdowns will maximize turbocharger shaft and bearing life.

**WARNING:**

Before leaving the tractor cab remove the key from the ignition.

**WARNING:**

Do not to stop the engine by turning off the battery electric ground switch.
The ground switch should be off at least 2 minutes after the engine is shutdown. Early engine shutdown may damage the engine control module and the selective catalytic reduction system (AdBlue).



Fig. 4.2.1. Ignition starter switch 4 position.

0. OFF

1. Switches on electrical consumers when the engine is not running.

2. In this position the glow plugs are energized for cold engine starting.

3. In this position starter motor is turned on. When the key is released, the key returns automatically to the 2 position.

By turning the key back to position 0 the engine is switched off.

4.3. Driving the tractor.

WARNING: Prior to commencing work, the operator should be familiar with the function and operation of all control levers and indicators.



After starting the engine:

- depress the clutch pedal, then select the desired speed range, gear and direction gear,
- release the parking brake lever,
- increase the engine speed slowly and simultaneously release the clutch pedal slowly,
- release the clutch pedal fully and slowly operate the throttle until desired engine speed is reached.

Selecting the correct gear

Select the gear which will give the best fuel consumption without overloading the engine or transmission. Also remember that ground conditions in the same field may vary almost every few meters, therefore select the gear in which the engine will operate satisfactorily at about three-quarters of its maximum power.

Never work the tractor by slipping and re-engaging the clutch and at all times avoid riding the clutch pedal which can cause overheating, and will lead to clutch failure.

WARNING:



1. Avoid pressing the clutch pedal all the time.
2. Do not move the gear lever, the range selector lever, unless the clutch pedal is pressed, when the tractor is moving.
3. Never move down on slopes with the tractor in gear and the clutch disengaged.
4. For road work, take hand throttle to minimum position and use the foot throttle only.
5. When tractor is towed, the engine must run (due to hydrostatic steering system) and the gear lever place in neutral position.

Recommendations aimed at tractor operating efficiency and fuel saving.

1. Match the attached implement size so that the engine could operate at over 75% of its power.
2. Avoid unnecessary tractor idling and reduce the time spent on headland turns and travels to the field.
3. Use correct tyre pressure for a given work.
4. Use the ballast weights reasonably.
5. Match the trailer load capacity correctly and utilize it to the highest extent possible.
6. For field transport make use of single axle trailer preferably.
7. Make use of Draft Control for controlling the working depth of mounted soil engaging implement to the highest extent
8. Look after the efficiency of the fuel system and carry out the maintenance and adjustments as stated in this book.
9. Use recommended fuels and lubricants only.

Towing

For towing tractor use the towing hitch (Fig. 4.3.1). If possible, use towing beam. Observe the local rules referring to towing.

Before towing the tractor, move the PTO lever, the range selector lever and the main gear lever into neutral. The tractor must be towed at safe speed using a rigid bar.

	WARNING: When the engine is stopped the hydraulic power assistance to the steering does not operate. The tractor can then be steered manually. In this situation the tractor must move slowly with extreme caution. It is not allowed to use towing hitch for other application than tractor towing.
---	--

	WARNING: When towing the tractor, set all levers and gears to neutral position. Gear reduction lever should be in "HI" position. Otherwise transmission assemblies may be damaged during towing.
---	---



Fig. 4.3.1. Tractor towing hitch. (A – tractor fitted with front three point linkage / PTO – optional)

Braking system

	WARNING: <ol style="list-style-type: none">1. Before driving on the road, always latch the brake pedals together.2. Independent braking may only be used to assist turning on headlands of a tractor with mounted implements.3. When the tractor is operated for stationary work, even if only for short periods always engage the parking brake
---	---

When attaching a trailer, or trailed machines to the tractor, ensure that the trailer air braking system is connected.

To connect the trailer braking system to the tractor braking system, proceed as follows:

- engage the parking brake (this will cause the air pressure in the hose drop down to the atmospheric pressure,
- couple the trailer and tractor air couplers,
- release the parking brake.

	WARNING: Never start towing of a trailer with the air pressure gauge pointer in red zone. Allow time for the compressor to fill the air reservoir. Insufficient air pressure in the system is then also indicated by air pressure drop warning lamp which illuminates red.
---	---

Front drive axle

The drive to the front wheels is transmitted from the drop box by the drive shaft, crown wheel and pinion and differential mechanism to the front axle final reduction units. As a standard equipment the "limited slip" type of differential is fitted (self-locking).

WARNING: Operation in four wheel drive is intended for field work only. Do not use the tractor in four wheel drive on roads or dry land.



Rear differential lock

If during the field work one of the rear wheels starts to slip (there is a small difference in rotational speed) engage the differential lock by pressing the differential lock switch (13 - Fig.3.1).

Disengage the differential lock when driving on roads or dry land.

WARNING:

- 1. Do not engage the differential lock with one wheel rotate and the other stopped.**
- 2. Do not turn the tractor with the differential lock engaged.**
- 3. Operation with differential lock engaged is intended for field work only.**
- 4. Do not use the tractor with differential lock engaged on roads or dry land.**



4.3.1. Regeneration procedure of DPF filter

Diesel particulate filter was applied in an exhaust system for exhaust gas purification. Particulates (soot) generated during the engine working are collected and burnt in a diesel particulate filter.



Fig. 4.3.1. DPF filter regeneration control switch.

A - Access to regeneration control switches.

To access the switches, touch the Selective Catalytic Reduction (AdBlue) fluid level indicator (51 - fig.3.2.)

B - DPF regeneration control switches

1- Switch to force DPF filter active regeneration.

2- Switch to postpone DPF filter active regeneration.

In a typical engine working cycle occurs passive regeneration of the exhaust gas.

Under conditions when engine working cycle doesn't provide sufficient exhaust gas temperature occurs an increase accumulation of soot in the filter.

After reaching level 90 – 130 % starts up active regeneration signaled by control lamp of high

temperature exhaust system with symbol  decreasing the level of soot to approx. 20%. Active regeneration will start when the engine runs at a speed above 1200 rpm / min. Then, the engine speed may drop below 1200 rpm / min. But not less than 950 rpm / min. Idle speed will be temporarily increased to 950 rpm / min.

During the automatic regeneration normal tractor working can be carried out.

If you can't carry out active regeneration at a given moment, press the switch DPF filter regeneration

control for at least 2 seconds on the side of symbol .

If the active regeneration is not occurred in the range of 90 - 130% soot accumulation, turns on a

control lamp of high degree accumulation of soot in the filter DPF with symbol . This situation can occur in the absence of conditions to start active regeneration, or when the user postpones active regeneration. In such a situation, it is recommended to manually extort active regeneration.

The tractor should be stopped, apply the handbrake and press the switch DPF filter regeneration

control for at least 2 seconds on the side of symbol .

The warning lamp needs of active regeneration lights up until the completion of process of active regeneration.

If the active regeneration is still postponed or manually not extorted the active regeneration, the accumulation of soot in the filter increases to the level of 170%, warning lamp comes on about

improper engine working with symbol  and control lamp of high degree accumulation of soot in the filter DPF  will continue to lights up. The control system will reduce engine power by 25%. **Under these conditions, the engine control system disconnects the automatic regeneration and only manually extortion of regeneration is possible.**

In case when accumulation of soot in the filter reaches the level of 230%, engine must be stopped.

Warning lamp comes on about engine failure  **STOP**, The control system will reduce engine power by 55%. Service actions must be carried out to restore proper conditions of engine working.

WARNING:  Flashing indicator lamp  (19 - Fig. 3.2) with indicator light on  (29 - Fig. 3.2) showing the active regeneration must be completed to avoid accelerated wear of DPF filter.

WARNING:  Repeated manual postpone of the active regeneration process may cause damage the DPF and the necessity of its replacement.

4.3.2. AdBlue/DEF tank filling

When the AdBlue level reaches 5% or less, the AdBlue lamp (42 - Fig.3.2) lights on, the engine control system slowly reduce torque and maximum engine rpm..

When the AdBlue level has reached approximately 0% and keep the level for about an hour, the engine control system engine decreases engine rpm to idling speed and the torque is limited significantly. This is to ensure that the exhaust fume emissions remain in the allowable limits.

Fill up the AdBlue/DEF tank in relevant time as excessively low AdBlue level is to be specified with service codes. This can happen especially when operated in high-temperatures.

WARNING: Disconnect the main ground switch before filling up the AdBlue/DEF tank.



NOTE: Carefully clean the AdBlue/DEF tank cap and the area around the cap before filling up. Wipe off any spills after filling up.




Fig. 4.3.2. Tank caps.

- 1- Fuel tank filler cap.
- 2- AdBlue/DEF tank filler cap.
- 3- AdBlue/DEF tank drain plug.

AdBlue/DEF tank filling (Fig. 4.3.2)

1. Open the AdBlue/DEF tank cap (2 - Fig. 4.3.2)
2. Fill the tank.
3. Close the AdBlue/DEF tank cap.

As the AdBlue fluid is very corrosive, if the tractor is splashed with fluid, wipe off and wash with water. If an electrical connector is splashed with AdBlue fluid, it must be replaced.

In case of spilling the AdBlue fluid on the vehicle wash immediately with water any crystals of AdBlue/DEF.

WARNING:



- Never put fuel in the AdBlue/DEF tank. Even small amounts of fuel in the AdBlue/DEF tank may damage the gaskets of the selective catalytic reduction (SCR) system.
- Never put AdBlue/DEF in the fuel tank, as the engine and fuel system may become damaged.
- If the AdBlue/DEF additive is modified or replaced by a fluid which does not comply with the ISO 22241 (DIN 70070) standard, the DPF system will be damaged.
- Do not start the engine if the tank has been filled with a wrong type of additive. If filled with a wrong additive, the tank must be carefully emptied and washed before starting the engine.

4.4 Power take-off (PTO).

Power take-off shaft is placed in the rear axle housing and its end rotates to the right (from rear of the tractor), diameter 35 mm with 6 splines as per PN-77/R-36101 standard with ring groove for safety attachment of the driven implement telescopic-articulated shaft.

PTO shaft is covered with the PTO guard (4 - Fig.4.6.2).

NOTE:	<ol style="list-style-type: none">1. After attaching mounted implement carefully raise and lower it using Position Control lever. Check clearance and the drive shaft slide range/articulation.2. When attaching trailed implements ensure the drawbar is correctly set.3. Check all four wheels when carrying out stationary PTO work.
--------------	---

WARNING: 	<p>Before operating the tractor with PTO driven implements, familiarize yourself with the safety precautions given below and strictly observe them:</p> <ol style="list-style-type: none">1. Before connecting, disconnecting, cleaning or adjusting the PTO driven implements, disengage the PTO drive, stop the engine, remove the key, apply the hand brake and make sure that the PTO drive line has stopped.2. Do not operate the PTO driven implements without the master shield fitted.3. Make certain the implement drive shaft is securely locked on the tractor PTO shaft before starting the engine.4. After locking the drive shaft on the tractor PTO shaft, attach the drive shaft guard safety chains to the master shields.5. Fit the removable cap when the PTO drive line is not in use.
--	--

Operating the rear PTO

To enable PTO drive press the PTO clutch switch (14 - Fig. 3.1). PTO - indicator lamp lights up, the PTO clutch is engaged on.

WARNING: 	When connecting the drive shaft to the tractor and to the implement, this should be carried out strictly in accordance with the drive shaft or implement manufacturer operating instructions.
--	---

If PTO driven implements is attached to the drawbar, then the drawbar should be set to the position which ensures that the horizontal distance between the end of the PTO shaft and the pin hole in the end of the drawbar is at least 400 mm.

WARNING: 	<p>After completion of the work with the PTO operation, disconnect PTO clutch – indicating lamp is off.</p> <p>Prior to select the PTO type, disconnect PTO clutch pressing PTO clutch switch (14 - Fig. 3.1).</p> <p>When operator is not present on the seat for more than 5 seconds, the PTO clutch disengages automatically.</p>
--	--

To select PTO speed move the PTO selector lever (13 – Fig. 3.4). There are three positions as shown on sticker beside the lever:

- | | | |
|-----------------------------|---|--------------------|
| 1 - independent PTO engaged | - | Independent |
| 2 - neutral | - | N |
| 3 - ground PTO engaged | - | Ground |

Before shifting the lever to engage position set the PTO clutch switch (14 - Fig 3.1) to disengaged position (PTO drive warning lamp is off).

When shifting the lever to the ground PTO engaged, there is obtained PTO speed depending on tractor speed.

WARNING: To avoid inadvertent movement of the implement, keep the PTO selector lever in neutral after each use (13 – Fig. 3.4).



Independent PTO drive means that the PTO shaft rotates proportionally to engine rotation. There is possibility to select two speeds: 1000 rpm and 540E or 540 rpm and 540E.

If required to drive implements of higher PTO speed (1000/540E), select forward position of the lever (9 - Fig. 4.6.1) placed above PTO shaft end. When 1000 rpm PTO is engaged the relevant indication occurs on the LCD central display (47- Fig.3.2).



WARNING: When 1000 rpm /540E PTO is engaged don't use implements adapted to low PTO rotation to avoid damage of the implement

Operating the front PTO (optional)

Front PTO (optional) is placed in the front of tractor and rotates counter clockwise (from front of the tractor). To enable PTO drive press the PTO clutch switch (12 - Fig. 3.1). PTO - indicator lamp lights on, the PTO is engaged.

WARNING: When connecting the drive shaft to the tractor and to the implement, this should be carried out strictly in accordance with the drive shaft or implement manufacturer operating instructions.



Fig. 4.4. Front Power take-off (PTO), direction of rotation, counter clockwise.

4.5. Tractor hydraulic system.

Your tractor is equipped with a hydraulic system providing accurate and sensitive control over a wide range of operating conditions.

4.5.1. Hydraulic lift system.

The hitch control system is an innovative, operator-friendly package that provides closed-loop control of tractor three-point hitches and similar functions such as combine harvester headers. The system combines an electronic interface controller, sensors, and mobile hydraulic control valves for a completely integrated vehicle solution.

Features & Specifications

Implement Programming

Save adjustment setting for implement type or field conditions

Operation

Fewer buttons to turn, less confusion

Icon-based menu systems

View Integrated LCD

Information Feedback to operator

Easy to read

Displays diagnostic messages – not just a flashing LED

Displays real-time input and output values

Options

Quick and Accurate diagnosis minimizes downtime

Multi-language support

System sensors and Auxiliary controls:

Draft and Position Sensors

Remote fender switches

Control Panel Basics



Fig. 4.5.1 EHR Control Panel. Basic information.

Raise-Stop-Lower Toggle Switch: This is a 3 position toggle switch is used to select the active mode. The center position is Stop. To access the raise mode the switch must be pressed down at the end closest to the 'Menu' Key. To access lower mode the switch must be pressed down at the end closest to the 'Enter' key. Note: Raise and lower mode can only be accessed once the system has been unlocked. This will be described further later in this document.

Menu Key: The menu key is used to access the menu system, pressing it while navigating the menus will return you to the previous menu level or out of the menu system.

Scroll Knob: The scroll knob is used to scroll through the menus and adjust selected settings.

Enter Key: The enter key is used to select a setting for adjustment and can be held to save the EZ-Select® settings. This will be described further later in this document.

LCD Screen: The LCD screen is where all the information is displayed for the user.

Automatic Mode Screens

The Start Up Screen (or Locked Screen)

The system will display this screen whenever the system is restarted, such as when the tractor ignition is turned on, after the remote switches are activated or whenever the initial calibration procedure is complete.




Fig. 4.5.2 EHR Control Panel. The Start Up Screen

Locked Icon: This signifies the system is in locked mode and illustrates what is needed to unlock it. In order for the system to be unlocked the Raise-Stop-Lower Toggle Switch must go through all modes (Raise-Stop-Lower) and return to Stop position. As each mode is entered the associated arrow on the icon will appear solid. When both are solid and the rocker is returned to Stop the system is unlocked.

EZ-Select Implement Number or Diagnostic Symbol: The EZ-Select Implement Number will be displayed in this area, see the EZ-Select description for further details. In the event of a trouble code the trouble code icon (see below) will be shown



= Trouble Code icon

Software & Revision: The software identification and revision is displayed in this area.

Depth: The depth set point is displayed.

Current Position Arrow: Points to the current position on the Position Bar. In Scrolling Position Bar mode, this arrow is stationary as the Position Bar moves. In Scrolling Arrow mode, this arrow moves while the Position Bar is stationary.

Current Position Value: This signifies the numerical value for current position.

Position Bar: The scrolling position bar displays the 60 increments around the current position. There are two wider bars that signify the Height and Depth set points. Below the Depth set point and above the Height set point the bar is thinner signifying that the system can physically operate outside of the set points. The total bar length signifies the maximum range of the positions available. The bar has 101 positions numbered from 0-100 where 0 is the lowest available point and 100 is the highest available point. This scale changes if the Ground Level is set. If ground level is set then ground level is displayed as 0 and below Ground Level points become displayed as negatives. The total number of increments will remain 102 (including Float, explained later) however some will be above and some will be below the Ground Level.

Height: The height is displayed.

If the Enter Key is pressed on this screen a box will appear around the Depth, this means the Depth value can be changed by rotating the Scroll Knob. If the Enter Key is pressed for a second time the box move from around the Depth value and appears around the Height value. Rotating the Scroll Knob will now adjust the Height set point. Pressing the Enter Key a third time will remove the box from around anything and the Scroll Knob will not adjust anything if moved.

Anytime a box is present around a value it is adjustable with the Scroll Knob.

The Stop Mode Screen (or Unlocked Screen)

When the system has been unlocked by going through all modes (Raise-Stop-Lower) then returning to Stop the screen below is displayed.



Fig. 4.5.3 EHR Control Panel. The Stop Mode Screen

In addition to the item already described this mode has displays the following:

Unlocked Icon: This icon signifies the system is unlocked but in Stop Mode.

Height and Depth Values can be changed in the same manner as on the Start Up Screen.

The Lower Mode Screen

When the Raise-Stop-Lower Toggle Switch is moved in to the Lower Position the screen below is displayed.




Fig. 4.5.4 EHR Control Panel. The Lower Mode Screen

In addition to the item already described this mode has displays the following:

Lower Mode Icon: This icon signifies the system is unlocked and in the Lower Mode.

Mix Setting: The Mix Setting is a setting that can be adjusted between 0-10. When it is set to 0 the system will ignore draft loads and only maintain hitch depth. When the setting is 1-10 the system will respond to changes in draft load once the Depth Setpoint has been reached. If draft load increases the hitch will raise to relieve the load and if the draft load decreases the hitch will lower to increase the load. The higher the Mix Setting number (1-10) the faster the raise and lower speed will be when reacting to load changes.

Active Direction Indicator: This icon appears whenever the controller is providing a significant current to the Raise or Lower component of the valve. The arrow shown can either point in the direction shown or the opposite direction. In the example screen, the direction shown signifies the Lower component of the valve is receiving a current.

In this mode a box appears around the Depth value by default, allowing it to be changed with the Scroll Knob. Pressing the Enter Key will move the box back and forth between the Depth and Mix values.

The Float Mode Screen

When the Raise-Stop-Lower Toggle Switch is moved in to the Lower Position and the Depth is set below the minimum value the screen below is displayed.




Fig. 4.5.5 EHR Control Panel. The Float Mode Screen

In addition to the item already described this mode has displays the following:

Float Icon: This icon signifies the system is unlocked and in the Lower Mode but the Depth has been set below the lowest set point. This means that the lower portion of the valve will be commanded. This will allow oil to pass between the hitch cylinder(s) and the tank as needed and in both directions.

Float: This is shown in place of the Depth setting when the Scroll Knob has set the Depth to below the minimum set point.

The Raise Mode Screen

When the Raise-Stop-Lower Toggle Switch is moved in to the Raise Position the screen below is displayed.




Fig. 4.5.6 EHR Control Panel. Fig. The Raise Mode Screen

Raise Icon: This icon signifies the system is unlocked and in the Raise Mode. When Transport Mode is enabled; the icon shown below is displayed.. Transport Mode can be toggled on and off by pressing the Enter Key.



If Transport Mode is activated a box will appear on the Scrolling Position Bar and the hitch will lower to the middle of the box. The box signifies the range of movement the hitch could see under dynamic loading conditions.

Ground Level Indicator: This icon signifies Ground level. This can be enabled in the menu and set to a position. Once set the icon will appear, as shown in the example, and the Depth and Height will be changed to be relative to ground. Below ground positions will be negative and above ground positions will be positive.

In this mode a box appears around the Height by default, this means the Height value can be changed by rotating the Scroll Knob.

Manual Mode

Remote Switch Actuation

The Remote Switches should be accessible from the rear of the tractor and can be used to make adjustments. Pressing the Raise remote switch will command a Raise and pressing the Lower remote switch will command a lower. If the remote switches are used the system will go into locked mode and the control panel controls will be disabled until the system is unlocked again. When the remote switches are used the hitch speed is 50% of maximum.



Operation when Automatic Modes are not available

If the system is not calibrated, calibration failed or the system has an error associated with the Position Sensor or coil drivers/feedback


then the Raise-Stop-Lower Toggle Switch will act like the remote switches allowing an operator to slowly raise when the Raise-Stop-Lower Toggle Switch is in the Raise position and slowly lower when the Raise-Stop-Lower Toggle Switch is in the Lower position.

Navigating the Menu's

Navigation through the screens is done by pressing the Menu key to get to the Menu screens then using the Scroll Knob to scroll through.

Once the Menu Key is pressed the current mode is displayed in the upper left hand corner of the screen and the EZ-Select Implement Number or Diagnostic Symbol remains in the upper right hand corner of the screen.

The menus are described below:




The current Depth value is displayed. If the Enter Key is pressed a box will appear around the value and the Depth value can be adjusted using the Scroll Knob. Pressing Enter again removes the box from around the Depth value and allows you to use the Scroll Knob to scroll through the menu again.

The current Lower Rate value is displayed. If the Enter Key is pressed a box will appear around the value and the Lower Rate value can be adjusted using the Scroll Knob. Pressing Enter again removes the box from around the Lower Rate value and allows you to use the Scroll Knob to scroll through the menu again.

The current Raise Rate value is displayed. If the Enter Key is pressed a box will appear around the value and the Raise Rate value can be adjusted using the Scroll Knob. Pressing Enter again removes the box from around the Raise Rate value and allows you to use the Scroll Knob to scroll through the menu again.

The current Height value is displayed. If the Enter Key is pressed a box will appear around the value and the Height value can be adjusted using the Scroll Knob. Pressing Enter again removes the box from around the Height value and allows you to use the Scroll



Height

Mix Setting



Transport Mode



Transport Sensitivity




Diagnostics

Knob to scroll through the menu again.

The current Mix Setting value is displayed. If the Enter Key is pressed a box will appear around the value and the Mix Setting value can be adjusted using the Scroll Knob. Pressing Enter again removes the box from around the Mix Setting value and allows you to use the Scroll Knob to scroll through the menu again.

If the Enter Key is pressed the following icons will appear:



The Scroll Knob is now used to select Transport Mode On (box is around the icon to the right) or Transport Mode Off (box is around the icon to the left). Pressing Enter again removes these icons and allows you to use the Scroll Knob to scroll through the menu again.

The current Transport Sensitivity value is displayed. If the Enter Key is pressed a box will appear around the value and the Transport Sensitivity value can be adjusted between 1 and 10 using the Scroll Knob. Pressing Enter again removes the box from around the Transport Sensitivity value and allows you to use the Scroll Knob to scroll through the menu again.

The higher the Transport Sensitivity value the larger the amount of time an error

correction is applied for a specific change in draft load. The correct setting will largely depend on the implement attached and should be experimented with.

If the Enter Key is pressed the Diagnostic sub-menu will be displayed. The Scroll Knob will now scroll through this sub-set of menu screens.



Trouble Codes

The current highest priority trouble code is displayed or if no codes are active then 'No Problem' will be displayed. The list of error codes and the priority is displayed in the Troubleshooting section of this guide. If the Enter Key is pressed another screen is displayed that shows a list of all error codes active, if none are active 'None' will be displayed.

If the Enter Key is pressed another screen is displayed that shows the following information:

1. Position in Volts
2. Draft Sensor 1 in Volts
3. Draft Sensor 2 in Volts
4. Ignition Voltage in Volts
5. Alternator Voltage in Volts
6. Remote Raise on(1) or off(0)
7. Remote Lower on(1) or off(0)
8. Raise Current in milliamps
9. Lower Current in milliamps
10. Raise Current Feedback in milliamps
11. Lower Current Feedback in milliamps

The Scroll Knob can be used to scroll down to be able to see the values further down the list.

Pressing Menu allows you to use the Scroll Knob to scroll through the Diagnostic sub-menu again.

Before starting the calibration procedure please ensure the Engine RPM is set to a level sufficient to meet the cycle times and that the oil temperature is 50 Deg C.

If the Enter Key is pressed the automatic calibration procedure will begin and the hitch



Status

Diagnostics (continued)



Calibration

will begin to move. As the procedure progresses the number at the bottom of the screen will change as each step of the processes is completed. Once the Calibration procedure is complete,

the system will return to the Locked position. If for any reason calibration fails the system will remain on the calibration screen and the number of the failed step will be displayed.

If Ground level is turned off then "OFF" will be displayed on this screen. If the Enter Key is pressed the current position is recorded as ground level. To set this correctly the user should lower the implement to the ground and then navigate to this screen and press Enter. To Turn Ground Level off, hold the Enter Key for 5 seconds. The Ground Level icon is shown below:



Ground Level



The current Brightness value is displayed. If the Enter Key is pressed a box will appear around the value and the Brightness value can be adjusted using the Scroll Knob. Pressing Enter again removes the box from around the Brightness value and allows you to use the Scroll Knob to scroll through the Diagnostic sub-menu again.



Brightness

The current Contrast value is displayed. If the Enter Key is pressed a box will appear around the value and the Contrast value can be adjusted using the Scroll Knob. Pressing Enter again removes the box from around the Contrast value and allows you to use the Scroll Knob to scroll through the Diagnostic sub-menu again.



Contrast

The current Display Type value is displayed. If the Enter Key is pressed a box will appear around the value and the Display Type value can be adjusted using the Scroll Knob. Pressing Enter again removes the box from around the Display Type value and allows you to use the Scroll Knob to scroll through the Diagnostic sub-menu again. 0 is Scrolling Position Bar mode and 1 is Scrolling Arrow mode where the current position arrow will move up and down the screen as position changes. The entire position bar is displayed.



Display Type

The current selected implement will be displayed with its number and its 12 character description. If the Enter Key is pressed the EZ-Select Screen appears showing up to 4

stored implements, this page is only accessible when the Raise-Stop-Lower Toggle Switch is in the Stop position. The Scroll Knob is used to scroll through the list and the

Enter key is used to select the desired implement and load its stored settings. Pressing and holding the Enter key for 5 seconds will allow the user to enter in a 12 character description using the Scroll Knob to cycle through 0-9 'space' A-Z. Enter is pressed to move to the next character once the 12 have been entered the description will be saved and the Scroll Knob will scroll through the implements again. Press Menu to

EZ-Select



return to the previous screen.

On every page the EZ-Select number is displayed in the top right hand corner. An example of the EZ-Select number displayed is shown below:

1

If a user changes one of the setting away from the stored value, the displayed EZ-Select number will change as displayed below:

11

To save the changes made simply hold the Enter Key for 5 seconds. To discard the changes, navigate to the EZ-Select menu page, press Enter and scroll to highlight a different implement. Press Enter again to select a different implement. Then Scroll back to the original implement and press Enter to re-select it.

Troubleshooting

Indicators of a Problem

There are several indicators built in to inform you of an error if one is detected. The most common is the Trouble Code symbol (right). This symbol will appear in the top right hand corner of the screen whenever a trouble code is detected. In addition to this, some of the particular trouble codes have other indicators:



Current Position Arrow flashes: The Current Position Arrow flashes if the position sensor voltage is high or low indicating a potential problem with the Position Sensor. Under these conditions automatic modes will be disabled and therefore the rocker switch will work like the remote switches in that they will command a slow raise or slow lower.

Height and Depth Values flashing: If the unit is yet to be calibrated or failed calibration then the Height and Depth values will flash indicating that the upper and lower position limits are unknown. Under these conditions automatic modes will be disabled and therefore the rocker switch will work like the remote switches in that they will command a slow raise or slow lower.

Mix Setting flashes: If one of the Draft Sensor voltages is high or low, indicating a potential problem with one of the Draft Sensors, the Mix Setting icon will flash. Under these conditions automatic modes will not be disabled, only the Draft mode will be disabled, allowing the user to continue to work in position mode.

Error Code Location

If you do have an error code you can look at what codes you have by navigating to the Trouble Code page in the menu as described in the 'Navigating the Menu's' section of this manual. Once on the Trouble Code page the error code with the highest priority as described in the 'Error Code Description' section will be displayed. Pressing Enter on this screen will display a full list of the error codes that are present.

To further investigate any problem the Status page can be used. Navigate to the Status page as described in the 'Navigating the Menu's' section of this manual and then press Enter. This will show you the current values of all inputs and outputs and can be used to diagnose failures of certain equipment.

Priority	Diagnostic Trouble Code	SPN	FMI	Condition to set active
1	ECU Failure	628	12	Raise button AND Lower button are active for 100 milliseconds
2	ECU Never calibrated	628	14	Active when shipped from HUSCO
3	ECU Needs calibration	628	13	Set when calibration aborts
4	Raise Coil short to ground/open	701	5	Condition to set active TBD
5	Raise Coil short to battery	701	6	Condition to set active TBD
6	Lower Coil short to ground/open	702	5	Condition to set active TBD
7	Lower Coil short to battery	702	6	Condition to set active TBD
8	Position Sensor under voltage	703	4	Position Sensor voltage < 0.25 Volts for 100 milliseconds
9	Position Sensor over voltage	703	3	Position Sensor voltage > 4.75 Volts for 100 milliseconds
10	Draft Pin1 under voltage	704	4	Draft1 Sensor voltage < 0.25 Volts for 100 milliseconds
11	Draft Pin1 over voltage	704	3	Draft1 Sensor voltage > 4.75 Volts for 100 milliseconds
12	Draft Pin2 under voltage	705	4	Draft2 Sensor voltage < 0.25 Volts for 100 milliseconds
13	Draft Pin2 over voltage	705	3	Draft Sensor voltage > 4.75 Volts for 100 milliseconds
14	Remote Raise switch stuck on	706	6	Remote Raise switch is active @ Reset and stays active for 5 seconds.
15	Remote Lower switch stuck on	707	6	Remote Lower switch is active @ Reset and stays active for 5 seconds.
16	Battery Voltage high	158	0	Battery Voltage >18 Volts for 5 seconds
17	Battery Voltage low	158	17	Battery Voltage < 7 Volts for 1 second

4.5.2. External hydraulics control.

The external hydraulic valves controls the oil flow to the hydraulic equipment found on farm machinery, namely: double-acting ram cylinders and hydraulic motors.

NOTE:	It is important that the components are checked correctly before the machine or implement is attached to or operated by the tractor, otherwise damage to the system may result.
--------------	---

External hydraulic valves are located under the cab platform and connected through piping system to quick-release couplers at the rear of the tractor (6 – Fig. 5.14)

The external hydraulic system is fitted with three spool valves with 6 quick-release couplers.

System is controlled with a three levers (19- Fig. 3.1 and 4.5.2). Depending on the levers position the pressure appears on relevant coupler. (Fig. 4.5.7).

Lever A have four service positions and is fitted with detent which locks the lever in 1, 2 and 4 service position. Front, last is the floating position.

Levers B and C have three service positions. Also fitted with detent which locks the lever at front position.

The lock position of spool valve is designed to supply another hydraulic distributor or hydraulic motor.

To release the lever from locked position, must be manually moved. In other position, the lever when released, automatically returns to the neutral position.





Fig. 4.5.7 Pressure layout on external hydraulics quick-couplers.

Quick coupler label		Quick coupler label	
	Pressure at lower right quick-coupler, return at lower left quick-coupler		Pressure at lower left quick-coupler, return at lower right quick-coupler
	Pressure at centre right quick-coupler, return at centre left quick-coupler		Pressure at centre left quick-coupler, return at centre right quick-coupler
	Pressure at upper right quick-coupler, return at upper left quick-coupler		Pressure at upper left quick-coupler, return at upper right quick-coupler



N - Neutral position
< - Locked position




Fig. 4.5.8 External hydraulic control levers.

WARNING: Do not leave hydraulic control levers in lock service position unless needed, to avoid hydraulic pump damage.



WARNING: Leaking fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids. If an accident occurs, see a doctor immediately or gangrene may result.



To operate external hydraulic valves, connect the remote cylinder feed hose to the lift coupler after removing the dust cap. Ensure that the hose is properly seated. The return hose from the double-acting cylinder must also be connected to the drop coupler.

NOTE: Before connecting remote cylinder hoses, thoroughly clean the connections to prevent oil contamination. Remote cylinders are operated by oil drawn from the tractor transmission system. Therefore, always check and replenish the transmission system oil after remote cylinder equipment has been connected and cycled a few times

If hoses are accidentally disconnected from the tractor during use, clean tip and coupler receptacles. Hoses can be reinstalled as previously described with minimal loss of oil.

WARNING: Make sure that the oil level in the gearbox is not below the minimum level. Take special care when cleaning the hydraulic unit on the implement/equipment so as not pollute the oil in the transmission housing.



4.6. Equipment attaching on three-point linkage.

The tractor hydraulic lift system with three-point linkage (see Fig. 4.6.1 and 4.6.3) facilitates control of implements and machines from operator's place.

The three-point linkage consists of following elements:

1. Top link (1) it is fitted with locking sleeve and lever to adjust the length of the link. It can be attached to one of three openings in top link rocker (2). When transporting the tractor, hook the link over the lug.
2. Lower links (6 and 7).
 1. Lift rods, right (5) and left (4) attached lower links with lift arms. Both lift rods length is adjusted by means of rotary handles. To turn the handle pull it upwards to unlock.
 2. Stabilizer bars protect implements of excessive lateral movement. The external bars are adjustable with means of a sleeve nut (8) locking with check nut (9).
3. Quick couplers of lower links and top link are designed to attach implements to three point linkage.

Attaching implement to the three-point linkage

- shift the upper transport hitch to top position (1 - Fig. 4.6.2),
- remove the drawbar (5 - Fig. 4.6.2) after putting out pins (11 - Fig. 4.6.2),
- move back the tractor to the implement aligning the ends of lower links (12, 13 - Fig. 4.6) with the implement hitch pins,
- put ball joint sleeves on implement hitch pins to attach the implement to tractor lower links,
- using the lift control switch on rear mudguard (10- Fig. 4.6.1), raise the lower links to the position in which implement hitch pins join tractor lower links quick couplers,
- make sure the self-locking latch of quick couplers blocked the ball joints on implement hitch pins,
- **apply the parking brake,**
- level the implement in horizontal plane by changing length of lift rods. There are two methods of rods mounting to lower links – setting the head and pin washer horizontally (Fig. 4.6.3), which ensure non shifting connection of lift rod to lower link or setting the head and pin washer vertically (Fig. 4.6.4), which ensure fluid height adjustment of lift rod due to which implement position is adopted to tractor in horizontal plane,
- depending on the implement, attach the top link (2 - Fig. 4.6.1) to a selected hole of the lift rocker and then to the implement cross shaft adjusting its length as necessary,
 - lower hole – light implements – Hydraulic system is more sensitive to load changes
 - upper hole – heavy implements – Hydraulic system is less sensitive to load changes
- adjust the stabilizer bars for side swing (Fig. 4.6.1),
To lengthen or shorten the stabilizers use tube nut (8 - Fig. 4.6.1) with handle.
After setting length of both stabilizers secure the nut with lock nut (9 - Fig. 4.6.1).

Make sure the stabilizers have the same length.

In transport position stabilizers length should be set as they not to be strained.

When operating with plough implement the length of stabilizers should be set such as side mowing did not exceed 125 mm at end of each lower link.

NOTE:	When attaching mounted or semi mounted equipment to the three-point linkage, or when coupling trailed equipment to the drawbar, ensure that there is adequate clearance between the implement and the tractor. The clearance in the raised position should be checked by raising the implement carefully in Position Control. Check the swing clearance by performing a series of left and right hand turns with the tractor and implement combination.
--------------	---

Detaching the implement

- select level and firm ground to detach the implement and lower the implement to the ground,
- apply the parking brake and stop the engine,
- ensure all hydraulic pressure is relieved,
- turn the leveling lever control to level the implement with the ground, if needed,
- support the implement so that it will not tip or fall when detached from the tractor,
- detach the top link and lower links from the implement frame.

WARNING: Never tow implements attaching to the hydraulic lift rocker




Fig. 4.6.1. Three-point linkage

1- top link, 2- top link rocker, 3- quick coupler, 4- lift rods, 5- tube nuts for lift rods adjustment, 6- lower links, 7- External stabilizers, 8- External stabilizers lock pins, 9- PTO rpm selection lever, 10- rear mudguard lift control switch.




Fig. 4.6.2. Hitches

1- Upper hitch, 2- Upper hitch pin, 3- Upper hitch adjustment lever, 4- PTO shaft cup, 5- Lower transportation hitch, 6- Lower hitch lock, 7- Lower hitch lock pin, 8- Lower hitch attaching pin, 9- Tractor drawbar, 10- Tractor drawbar pin, 11- Drawbar attaching pins, 12- Upper hitch locking pins, 13- Upper hitch adjustment lever lock button.




Fig. 4.6.3. Lift rods attachment non shifting to lower links – pin head and washer set horizontally




Fig. 4.6.4. Lift rods attachment shifting to lower links – pin head and washer set vertically

4.7. Attaching trailed machines and implements.

Apart from the three-point hitch (Fig 4.6.1), the machines and implements can be attached to:

- upper transportation hitch movable,
- tractor drawbar,
- lower hitch (fixed).

Upper transportation hitch (1 - Fig. 4.6.2) – is used for hitching a two-axle trailers.

The hitch is movable in vertical plane. To change the hitch position, push the hitch adjustment lever lock button (13 - Fig. 4.6.2) and pull the adjustment lever (3 - Fig. 4.6.2) upwards to move out lock pins from slide ways holes (12 - Fig. 4.6.2). With the same lever shift the hitch for required height and put down the lever to let the pins enter holes in slide ways and lock the hitch at required height.

Tractor drawbar (9 - Fig. 4.6.2) – is used for hitching trailed single-axle machines and implements.

Lower transportation hitch (5 - Fig. 4.6.2) – is used for hitching single-axle trailers and implements with 50 mm dia. hitch-ring. To attach a trailer put up and move backwards hitch lock (6 - Fig. 4.6.2) then put the lock and secure with pin (7 - Fig. 4.6.2).



WARNING:

Ensure to stay clear from the area of the three-point linkage and of the pick-up hitch when controlling them.

Ensure to stay clear from the area between tractor and trailed vehicle.

4.8. Tractor weighing.

For maximum performance in heavy draft conditions weight should be added to the tractor in the form cast iron weights. Front-end ballast may be required for stability and steering control when weight is transferred from the front to the rear wheels as the implement is raised by the tractor three-point linkage.

Weighing limitations

Additional weights can be applied:

- to front weight carrier - 10 wafer weights of 22 kg each ($10 \times 22 = 220$ kg), central tow hook of 40 kg can be dismantled in case of front axle unload need – installation of front loader.
- to rear wheels – 2 rear wheel weights of 39 kg each and 4 additional weights of 32 kg each ($2 \times 39 + 4 \times 32 = 206$ kg).

WARNING:



Take special care when carry and assembly rear wheel weights and front weight carrier, due to it's high weight – should be done by two persons.

4.9. Jacking Up Tractor.

Jacking Up Tractor - Lifting Points




Fig. 4.8. Lifting points recommended for jacking up the tractor

4.10. Engine bonnet opening.




Fig. 4.10. Engine bonnet electric lock release button.

To open engine bonnet push the button (Fig. 4.10). The bonnet is raised and held in position with gas springs.

5. MAINTENANCE AND ADJUSTMENT.

5.1. Periodic maintenance chart.

Table 4

Hours of operation	Service requirements	Check	Clean	Lubricate	Change	Adjust Replenish	Drain Remove
Every 10 Hours	Engine oil level	X				X	
	Dry air cleaner dust collector						X
	Radiator coolant level	X				X	
	Radiator matrix and oil cooler		X				
	Water in air reservoir (if fitted)						X
	Air compressor V-belt (during first 30 hours)	X				X	
	Dry air cleaner outer element		X				
First 50 hours	Engine oil and oil filter	A	A		A		A
	Fuel filter(s)	A	A				A
	Radiator coolant level	A				A	
	Dry air cleaner outer element		A				
	Air compressor (if fitted) and fan V-belts tension	A				A	
	Clutch pedal free travel	A				A	
	Transmission and rear axle oil level	A				A	
	Hydraulic oil filters				A		
	Front drive axle oil including final reduction units				A		
	Front drive axle oil breather		A				
	Braking system (including foot brake valve)	A				A	
	Tightness of trailer air braking system (if fitted)	A				A	
	Operation of electrical equipment	A				A	
	Battery electrolyte level and concentration	A				A	
	Lubrication acc. to the Grease Points Chart.				A		
	Leakage of oil and coolant (after road test)	A				A	
Tightness of external threaded connections (wheels, manifolds, cab, ballast weights,	A				A		
Tires, condition, inflation	A				A		
Every 300 Hours	Fuel filter(s)	X	X				X
	Engine oil and oil filter				X		X
	Brake fluid	X				X	
	Condition of tyres and pressures	X				X	
	Lubrication acc. to the Grease Points Chart.			X			
	Dry air cleaner outer element	X	X				
	Transmission and rear axle oil level	X				X	
	Clutch pedal free travel	X				X	
	Tightness of external threaded connections (wheels, manifolds, cab, ballast weights, 3-point linkage etc.)	X				X	
	Cabin air cleaner element		X				
	Hydraulic oil filter				A		
	Braking system adjustment	A				A	

	V-belts tension	A				A	
	Tightness of trailer air braking system (if fitted)	A				A	
Every 600 Hours	Dry air cleaner outer element				X		
	Engine oil and oil filter				A	X	
	Front drive axle oil including final reduction units	X				X	
	Fuel filter element				X		
	Radiator coolant				X	X	
	Fuel system breathing					X	
	Front wheels toe in	A				A	
	Condition of all lines (fuel, hydraulic, electric) and tightness	A				A	
	Starter motor pinion	A	A				
Every 900 Hours	Transmission and rear axle oil level				X		
	Front drive axle oil including final reduction units				X		
or every year	Fuel tank and air reservoir (if fitted)		A				
	Cooling system	X	X				X
	Alternator brushes				A		

NOTE

Carry out maintenance every specified number of operation hours

- it means, that carrying out maintenance after 300 hours of operation, also should be carried out maintenance after 10 and 50 hours of operation etc.
- **A – maintenance to be carry out by Authorized Service Shop**

5.2. Lubrication / Fluid application

5.2.1. Oils.

Lubricating oil grades applicable in Farmtrac tractors are specified in Table No. 5:

Table 5

Fluid	Recommended grade / Fluid type	Application	Capacity in liters
Engine oil	API CK-4 (CJ-4) 10W-30	Oil sump	10
Transmission oil	API GL-4 10W-40	Rear axle, Transmission, Hydraulic lift, Reduction gears	53
	API GL-4 80W-90	Front axle	6,0
		Front reduction gears	2x1
Coolant	GLIKSOL	Cooling system	17
Diesel fuel • summer • interim period • winter	B w/g PN-EN 590+A1:2017 D w/g PN-EN 590+A1:2017 F w/g PN-EN 590+A1:2017	Fuel tank	160
Wind screen spray		Wind screen spray container	1,5
Brake fluid	Mineral brake fluid	Mineral brake container	0,8
Grease		Grease points as per Table 6	0,15 kg

5.2.2 . Reservoir filling.

Keep oil and grease in tight and clean containers.

Clean control & filler plugs and area around before oil / coolant level check. Check and replace plug seals, if necessary,.

Fill fuel tank using thick strainer funnel with relevant fuel according to ambient temperature.

Fill radiator with antifreeze coolant available on the market.

Liquid top levels are shown in table No. 5.

5.2.3. Greases.

In the FARMTRAC tractor grease is applied by hand or using grease gun in grease fittings. Greasing points are shown in Table No. 6.

NOTE:	Clean the grease gun and grease point nipple, before and after lubrication.
--------------	---

Table 6

	Grease point (Fig. 5.2.1)	Lubricate every hours of operation
2	Bearing of reducer pivot stub axle of front axle	50
3	Telescopic stabilisers	50
4	Upper and lower hanger points	50
5	Articulated joints of reducer drive shafts	50
6	Upper and lower securing points of hydraulic cylinder	50
7	Rotation axis of lift arms	50
8	Articulated joints of front axle drive shaft	50
9	Articulated joints of front axle drive shaft	50
10	Front axle drive shaft sleeves	50

11	Front axle pivot pin	50
12	Front axle pivot pin	50




Fig. 5.2.1. Grease points.

5.3. Engine.

5.3.1. Engine lubrication system.

Engine oil and filter change

Check the engine oil level every 10 hours of operation, or daily. Before checking the oil level, stop the engine and wait for a short period to allow the oil to drain back into the sump (tractor must be on level ground). Check the oil level by means of the dipstick (5-Fig. 5.3.2). If necessary, remove the filler plug and top up with fresh oil to the upper mark on the dipstick. Do not overfill.

Change the engine oil and oil filter as specified in table 4.

To change the oil, proceed as follows:

Warm the engine to operating temperature. Stop the engine, remove the drain plugs on oil sump both sides (4-Fig. 5.3.2 and Fig. 5.3.3), and collect the oil in a suitable container. Unscrew and discard the oil filter (5-Fig. 5.3.3). Clean the area around the filter. Smear clean engine oil around the rubber seal of a new filter and install on the tractor. Screw up until the faces just meet, then tighten a further 3/4 of a turn. Do not over tighten.

Replace the drain plug, remove the filler plug, and refill the engine with clean oil. Replace the filler plug.

Run the engine for a minute or so, to circulate the oil, then stop the engine. Wait for a short period to allow the oil to drain back to sump, then check the oil level by means of the dipstick.

Add clean oil, as necessary, until the oil reaches the upper mark on the dipstick.




Fig. 5.3.2. Engine L.H. side.

- 1- Brake system air compressor.
- 2- A/C air compressor.
- 3- Engine oil filler cup.
- 4- Engine oil drain plug on engine L.H. side.
- 5- Dipstick.
- 6- Fuel filter.
- 7- Fuel filler cup.
- 8- AdBlue/DEF tank filler cap.
- 9- Hydraulic pump.
- 10- Wind screen spray container
- 11- Turbo charger.



Fig. 5.3.3. Engine R.H. side.

- 1- Brake fluid container.
- 2- Fuel Injection pump.
- 3- Pressure regulator.
- 5- Engine oil filter.
- 4- Engine oil drain plug on engine R.H. side.
- 6- Alternator.



WARNING:

Don't mix different kinds of engine oil.



WARNING:

Do not wash the engine and engine control module (located under the driver's cabin) using pressure washing devices.

This may damage the electrical system and immobilize the engine.

5.3.2. Fuel system.

Keep fuel system clean. It is recommended to clean fuel tank once a year. Fill the tank with clean diesel fuel. Don't empty fuel tank completely.

Fuel filter maintenance

Remove water and impurities from filter every 50 hours of operation (2-Fig. 5.3.4).

To remove water and impurities from the fuel filter, loosen the drain plugs (3 - Fig. 5.3.4) at the bottom of the fuel filter to allow the water/fuel to drain into a suitable container. Additionally tractor is fitted with fuel separator (3-Fig. 5.3.4). Drain the separator when water and impurities accumulates inside by loosening the drain plugs (4 - Fig. 5.3.4).

Every 600 hours of operation change the fuel filter element (2-Fig. 5.3.4).

To replace the fuel filter canister:

- thoroughly clean the outside surface of the fuel filter assembly,
- loosen the drain nut at the bottom of the filter and allow the water/fuel to drain into a suitable container,
- use a strap wrench or similar tool to loosen the filter canister and remove the canister,
- lubricate lightly the two top seals 2 and 3 of the new canister with clean fuel. Fit the new canister to the filter head and tighten, by hand only,
- eliminate the air from the fuel filter, see "Bleeding the fuel system" in this section.

Bleeding the fuel system

If air enters the fuel system, it must be removed before the engine can be started.

Air can enter in to the system if:

- the fuel tank is drained during normal operation,
- the low-pressure fuel pipes are disconnected,
- a part of the low-pressure fuel system leaks during engine operation.

There is generally no need to bleed tractor fuel system as the electrical fuel lift pump can solve the problem.




Fig. 5.3.4. Fuel system. (A – engine RH side, B – engine LH side)

1- Fuel injection pump. 2- Fuel Filter. 3- Water Separator. 4- Drain plug. 5- Fuel feed pump.

5.3.3. Dry air cleaner.

Dry air cleaner maintenance.

Remove any accumulated dust from the dry air cleaner dust collector every 10 hours of operation, or daily in extremely dusty conditions (Fig. 5.3.6);

Clean the outer element every 50 hours of operation, or whenever the air cleaner warning lamp on the instrument panel comes on.

To clean the outer element:

- remove the Cleaner cover (2 - Fig. 5.3.6) by releasing 3 latches (4 - Fig. 5.3.6) and carefully slide the element (6 - Fig. 5.3.6) out the filter housing,
- clean the element by hand. Do not beat the element against a hard surface as the element may be damaged or distorted,
- alternatively, compressed air not exceeding 2 kg/cm² may be used. Insert the air line nozzle inside the element and blow the dust from the inside to the outside. Keep the nozzle at a safe distance from the element. Blow loose particles from the outside of the element by holding the nozzle at least 150 mm from the element,
- clean the inside of the air cleaner housing with a damp lint-free cloth,
- reinstall the outer element ensuring that the rubber sealing ring on the end is secure.

Every 600 hours of operation replace the outer element

Replace the inner element every three changes of outer element.

NOTE: Never attempt to clean the inner element. It must be replaced.




Fig. 5.3.6. Dry air cleaner.

1-Filter housing. 2- Cover. 3- Dust collector . 4- Latches. 5- Preliminary element. 6- Secondary element.

5.3.4. Cooling system.

Check the radiator coolant level every 10 hours of operation, or daily.

With the engine cold, remove the radiator filler cap and check that the coolant level is with the bottom of the filler neck. Top up, as necessary.

Clean the radiator matrix and oil cooler every 10 hours of operation, or daily. by blowing compressed air from the rear of the radiator.

Every year or every 900 hours of operation clean cooling system and change coolant.

5.4. Electrical system.

The electrical system is connected to battery after ground switch is switched on (11-Fig. 3.4).

WARNING:



To avoid damage to the alternator charging system, observe following service precautions:

- NEVER make or break any of the charging circuit connections, including the battery, when the engine is running.
- Washing tractor, be careful and don't let water enter into the alternator and starter motor.
- NEVER short any of the charging components to ground.
- ALWAYS disconnect the battery ground terminal when installing or removing the alternator.
- DO NOT use a slave battery of higher than 12 volts nominal voltage.
- ALWAYS disconnect the battery ground cable when charging the battery in the tractor using a battery charger.
- ALWAYS observe correct polarity when installing a battery or using a slave battery to jump-start the engine.
- ALWAYS disconnect the battery ground cable before carrying out arc welding on the tractor or on any implement attached to the tractor.




Fig. 5.4. 1. V-belts.

1 – Alternator, fan and A/C compressor multi V-belt.

2- Air braking compressor V-belt.

5.4.1 Alternator maintenance.

Check the multi V-belts tension every 300 hours of operation. (Fig. 5.4.1).

Belt (1- Fig. 5.4.1).tension is maintained with tensioner.

5.4.2. Starter motor maintenance.

Push clutch pedal during engine starting to reduce starter motor load.

If the starter motor fails, have it repaired at specialized service.

WARNING:



Don't start the starter motor when engine is running which may cause the motor damage.

Don't crank the engine longer than 5 second and next crank can be made after 30 seconds.

5.4.3. Battery maintenance.

The battery (1- Fig.5.4.2) is mounted on the R.H. side under the cab step. To gain access to the battery, remove the nut (2- Fig. 5.4.2) securing the shelf and deflect the shelf with the battery.

Check the electrolyte level every 50 hours of operation. The electrolyte level in each cell should be 10 ÷ 15 mm above the top of separator plates and can be measured with glass tube. If necessary, replenish each cell with distilled water to the required level.

When conventional battery is fitted, periodic inspection of electrolyte level and concentration is required.

At regular intervals, clean the battery terminals and cable ends, then smear them with petroleum jelly. Keep the battery top clean.

To ensure proper battery performance, check also at regular intervals the electrolyte concentration so that the battery charge level could be defined.

If the battery is found discharged to 50 %, or more, it should be recharged until a signs of full battery charge are evident (intensive gas emission) and the electrolyte concentration.

NOTE:	In some territories maintenance free batteries are fitted on tractors. Follow the manufacturer's maintenance instructions.
--------------	--

WARNING: 	<ol style="list-style-type: none">1. During servicing be utmost careful when in contact with sulphuric acid (pour acid into water) to prevent contamination of the body, clothing or other objects. If such contamination occurs, immediately flush the contaminated spot with water liberally and neutralize with 2,5% solution of borax and water. The electrolyte should be prepared using protective clothing and glasses.2. Do not approach the battery with an open fire and avoid situations leading to short-circuit or "flashing" as explosion is likely to occur.
--	--

5.4.4. Spot lamps adjustment.

Regarding the safety of road traffic the front headlamps adjustment should be executed in authorized service depot.

5.4.5. Bulb and fuse - replacement.

Be sure of correct power of installed bulb. Disconnect the main ground switch before bulb change.

NOTE:	Do not replace blown fuse with another of a different capacity
--------------	--

The fuses are placed in a box located under the instrument panel. Remove the plastic cover to gain access to the fuses.

Fuses location in fuse box is specified in table No. 9 . Table No. 8 describes bulbs specification.




Fig. 5.4.2 Battery.

- 1- Battery box,
- 2- Battery box mounting bolt.

Table 8

Application	Bulb indication	Nos. per tractor
Headlights (main beam)	HB3 12V 60W	2
Headlights (dipped beam)	HB3 12V 60W	2
Flashing indicators (front)	12V 21W	2
Front marker lights	12V 5 W	2
Work lamps	LED 10-30V 27W	4
Rear marker lights	LED 12-24V 1,2/2,4W	2
Stop lights	LED 12-24V 1/2W	
Flashing indicators (rear)	LED 12-24V 1,2/2,4W	
Number plate illumination	12V 5 W	1
Cab lighting	12V C5 W	1



Fig. 5.4.3 Fuse and relays layout in fuse box

Table 9

FUSE BOX		
Fuse	Electric circuit	Value
1	Front PTO	10 A
2	Radiator fan	15 A
3	Combined switch	30 A
4	EHR (Option)	15 A
5	Monitor power supply	15 A
6	Roof work light	15 A
7	Indicator panel power supply	15 A
8	12V socket	15 A
9	Speed sensor	7.5 A
10	Air valve	10 A
15	PTO relays power supply	15 A
16	ECU ignition switch signal	15 A
17	Front drive switch	15 A
18	Emergency lights	15 A
19	Cab roof devices power supply	15 A
20	Cab roof devices power supply	25 A
21	Ignition power supply	25 A
22	Implement socket power supply	25 A
23	Emergency lights	15 A
24	Panel switches power supply, central locking	10 A
25	High beam, Dipped beam	25 A
27	Windscreen wiper power supply	25 A
28	Cab roof devices power supply	7.5 A
29	Cab roof devices power supply	25 A
30	7-pin socket	10 A
31	Starter motor	30 A
37	Air conditioning	10 A
38	High beam	15 A
39	Dipped beam	15 A
40	Marker lights	15 A
41	Fuses power supply	70 A
42	DC Fuses power supply	70 A
RELAYS		
1	Compressor	
2	Front-wheel drive	
4	Starter	
6	Operator's seat	
7	Stop lights	
8	Ignition switch	
9	Compressor clutch	
10	Traffic lights	
11	Brake air valve	
12	Dipped beam	

5.5. Hydrostatic steering system.

Hydrostatic steering system has a common oil system with tractor hydraulic system. Replace hydraulic oil filters (Fig. 5.9.2/ 5.9.3) every 300 hours of operation (see chapter 5.9).

WARNING: Replace the flexible hydrostatic steering lines every five years, or when observed damaged.



WARNING: In case of hydraulic pump failure, or if the engine is not running, tractor steering is preserved, but requires driver increased effort to turn the steering wheel. With reduced tractor speed, you can get to the nearest service center for repair.



5.6. Front axle.

Lubrication

Every 50 hours of operation grease front axle pivot pins (4-Fig. 5.6) and king pins (5-Fig. 5.6) grease points.

Check the oil level in the front final drive housing (2-Fig. 5.6) and clean the breather (1-Fig. 5.6) of the final drive housing after every 50 hours of operation.

To check, remove the filler / level plug (2-Fig. 5.6). The oil should reach the edge of level hole.

To clean the oil breather, remove it, clean in fuel oil and allow it to dry. Tighten it to a torque of 10 Nm.




Fig. 5.6. Front drive axle.
1- Breather. 2- Filler / level plug.
3- Oil drain plug. 4- Front axle pivot pin greasing points. 5- King pin grease points (2 pcs. on each side of tractor). 6- Filler / level plug in wheel hub. 7- Oil level line in wheel hub.

Check the oil level in the epicyclic reduction units of front drive axle after first 50 and every 600 hours of operation.

To check, set the wheel hub with the filler/level, drain plug (6-Fig. 5.6) in horizontal position as indicated by the line (7-Fig. 5.6) and remove the plug. The oil level should reach the hole level.

Replace the oil in the front final drive housing every 600 hours of operation or once a year, whichever occurs first.

To replace, proceed as follows (6, 7-Fig. 5.6):

- set the plug in its upper position and then loosen it to release possible internal pressure,
- set the plug in its lowest position and remove it,
- after draining the oil, set the plug in horizontal position as indicated by the line and fill the system with a fresh oil of recommended grade up to the level of the plug hole. For capacity, see Table 7.
- fit the plug and tighten to a torque of 80 Nm.

5.7. Wheels.

5.7.1. Front wheel track adjustment.

The different track widths are obtained by altering the position of the wheel rim in relation to the reduction unit flange as well as by reversing the wheels and interchanging them in the range of 1520 ÷ 1920 mm.

NOTE:	If the wheels are reversed, they must be transferred to the opposite side of the tractor so as to maintain the correct tire tread direction.
--------------	--

NOTE:	After wheel tracks change check the front wheel nuts tightening and adjust front wheel toe-in.
--------------	--

When refitting or adjusting front wheel, tighten the nuts/bolts progressively to the following torque:

- disc to axle hub – **300 ÷ 360 Nm.**

5.7.2. Front wheels toe-in.

Toe-in measurement and adjustment (Fig. 5.7.5)..

Check and adjust the front wheel toe-in every 600 hours of operation and after every change in the track setting and when excessive tyre wear is noticed.

To adjust front drive axle toe-in:

- dismount the track rod,
- loosen the lock nut of track rod at each track rod end,
- shorten or lengthen the track rod by track rod ends rotating. Adjustment must be made equally to both track rod ends,
- refit the track rod to the front axle and tighten the lock nuts, to the torque of 140 Nm,
- recheck the toe-in and adjust, if necessary.




Fig. 5.7.2. Front drive axle toe-in adjustment

5.7.3. Rear wheel track adjustment.

Rear wheel track adjustment is effected by changing the position of the wheel rim in relation to the axle hub as well as by reversing the wheels and interchanging them. in the range of 1508 ÷ 1908 mm.

NOTE: If the wheels are reversed, they must be transferred to the opposite sides of the tractor so as to maintain the correct direction of the tyre tread.

When refitting or adjusting a wheel, tighten the nuts/bolts progressively to the following torque:

- rim to disc – **144 Nm**,
- disc to axle hub – **300 ÷ 360 Nm**.

WARNING: Recheck after driving the tractor 200 m and then twice at 10 hour interval. If heavy work is involved, check twice at 2 hour interval until torque is held according to the values as given above.



5.7.4. Tyres use & maintenance.

Check tyre inflation pressure every 10 hours of operation or daily before starting work.

WARNING: These rules, if followed carefully, will ensure maximum tyre life:



- Apply recommended tyre pressures, check that the tyre pressures are correct for the particular operation to be performed. In certain conditions the pressures may be lowered, particularly where the loads are light or the soil is very humid, resulting in the tyre tread failing to self clean. If the tyre pressures are reduced, have someone observe the tractor. Do not exceed 20 km/h on the road, if the tyre pressures have been lowered for ploughing.
- Keep oil grease and strong alkaline or acid fertilizers away from the tyres to prevent deterioration of the rubber.
- re-vulcanized any small sidewall, or thread splits or cuts, as soon after they occur as possible. This extends the life of the tyre.
- Tyre inflation pressure at one axle wheels must be equal.

5.7.5. Wheel bearings greasing.

Every 50 hours of operation grease rear wheel bearing (Fig. 5.7.5).




Fig. 5.7.5. Rear wheel bearing grease point.




Fig. 5.8.1. Reverse pivot sleeves grease point.



Fig. 5.8.2. Clutch release bearing grease point.

5.8. Clutch.

Every 50 hours of operation grease:

a) with grease,

- reverse pivot sleeves (Fig. 5.8.1) – upper sleeve is accessible after opened tractor bonnet and lower sleeve is accessible after removed steering column LHS cover
- clutch release bearing grease point. (Fig. 5.8.2)

b) with grease-maintaining agent - clutch linkage attachment pivot in clutch pedal lever fork

Check and adjust, if necessary, the free travel of transmission clutch pedal every 300 hours of operation.

- loosen the locknut and remove the split pin and clevis pin,
- turn the clevis to lengthen or shorten the operation rod, as required,
- secure the clevis pin with a new split pin and tighten the locknut.

With correct lever setting, clutch pedal free travel is 25÷35 mm.

5.9. Transmission & rear axle maintenance.

Every 50 hours of operation check and replenish if necessary transmission & rear axle oil. When controlling oil level, park tractor on level ground.



Fig. 5.9.1. Rear axle / transmission oil drain plug.



Fig. 5.9.2. Hydraulic oil filter secondary.



Fig. 5.9.3. Hydraulic oil filter primary.




Fig. 5.9.4. Transmission oil level indicator.




Fig. 5.9.5. Three-point linkage grease points



Fig. 5.9.6. Three-point linkage central link grease points.

Replace hydraulic oil filter primary (Fig. 5.9.3) and secondary (Fig. 5.9.2) every 300 hours of operation. Transmission & rear axle oil should be replaced every 1200 hours of operation or once a year short time after stopping the engine. To drain the oil remove drain plug at the bottom of rear axle (Fig. 5.9.1) and wait for a moment to allow the oil to drain to a suitable container, replace plugs after oil has completely drained.

Refill the rear axle with clean oil through the filler plug at R.H. side of rear axle center housing (8-Fig. 5.14). After refilling, oil should reach level between top and bottom mark on the dipstick.

WARNING: Don't mix different kinds of engine oil.



5.10. Three-point linkage.

Grease every 50 hours of operation, lift rods greasing fittings as shown on Fig. 5.9.5. and Fig. 5.9.6. Threading joints grease every 300 hours of operation.

5.11. Cab and operator's seat.

Clean the cab air filter every 300 hours of operation. Clean every 10 hours or daily if operated in heavy dust conditions.

To remove and clean the air filter, proceed as follows (5-Fig. 3.5):

- unscrew two bolts securing the grille to the roof,
- pull the filter out,
- clean the filter element by blowing on the filter element with compressed air at a pressure not exceeding 0,7 MPa and keeping the nozzle at a reasonable distance from the element. The air stream should be directed opposite to this of air flow in normal operation,
- before refitting the filter element, wipe out its compartment with a damp cloth to remove the remaining dust particles,
- refit the filter element correctly to ensure proper air flow and tightness,
- refit the filter guard.

If the filter element is moist and the above cleaning procedure gives no satisfactory results, wash it in warm (about 30° C) solution of water and non-foaming detergent for automatic washing machine. Soak the element in solution for about 10 minutes and then agitate the element in solution to help remove the dirt. Ensure the element is rinsed thoroughly in clean water, then shake off water and allow 12 hours for the filter to dry. After drying inspect the element for holes or tears by looking through it towards a bright light and particularly check for damaged gasket.

Do not wash the filter element more than 10 times.

Do not direct the water jet onto the cab air filter, when washing the tractor.

Grease elements of operator's seat suspension; every 300 hours of operation.

WARNING: Do not wash the engine and engine control module (located under the driver's cabin) using pressure washing devices. This may damage the electrical system and immobilize the engine.



5.12. Braking system.




Fig. 5.12. Service break adjustment.
1- Brake pedal lever, 2- Brake pump push rod fork,
3- Locknut, 4- Brake pump push rod.

5.12.1. Service break adjustment.

Check the brakes operation every day.

Pedal correct free travel should be 20 - 25 mm.

If the free travel is out of the limits, as given above, or the braking performance of wheels is uneven, adjust the brakes by screwing the brake pump push rod fork in or out (Fig. 5.12)

To adjust the brakes, proceed as follows :

- chock the front wheels,
- release the parking brake,
- unlatch the brake pedals,
- remove the instrument panel cover,
- unlock the locknut (3-Fig. 5.12),
- adjust by turning push rod (4-Fig. 5.12) in brake pump fork (3-Fig. 5.12) so that there is a free travel at the pedal of 20 to 25 mm,
- lock the locknut (3-Fig. 5.12),
- repeat the procedure for the other side brake,
- if the adjustment range does not permit obtaining correct adjustment, adjust the length of operating rods of the system,

5.12.2. Parking brake.

Parking brake adjustment should follow the service brake adjustment.

If correctly adjusted, the parking brake should act securely, when the ratchet pawl is snapped in the third to fifth recess on the rack, counting from the lowest position.

Adjust the parking brake as follows:

- latch the brake pedals,
- place the parking brake lever in its lowest position,
- slacken the pull rod locknut, each side,
- shorten the pull rods by turning the adjusting nuts as far as possible and without interfering the free travel of the brake pedals,
- retighten the lock nuts,
- check the brake for correct adjustment,
- road test the tractor with the brakes latched and check the parking brake for pulling to one side.

Lock the brake pedals together and road test to ensure that the brakes are balanced and will stop the tractor in a straight line. If the tractor pulls to one side, adjust until the brakes are correctly balanced.

5.13. Air braking system.

Tractor air braking system is used for actuating the trailer air brakes and for tyre inflating. Tractor system is adapted to control trailer with single or double-line trailer air braking system. It is fitted with trailer control valve. The system contains of Air compressor, Pressure regulating valve, Air reservoir, coupling for connection to trailer air braking system (Fig. 5.14). Air braking system is shown at Fig. 5.13.

	1. Never start towing of a trailer with the air pressure gauge showing pressure below $0,4 \pm 0,04$ MPa.
	2. Stop towing of a trailer with air braking system if the air pressure warning lamp illuminates.

Air compressor

The energy (compressed air) source for trailer air braking system is a piston one cylinder compressor. The air compressor is equipped with a special type of valves enabling the pressure to be self-stabilized. This means that the pressure in the air reservoir is maintained constant due to the compressor delivery stopping at a definite pressure.

The compressor maintains a pressure from the compressor to the pressure regulating valve.

The air compressor is driven by V-belt from the engine crankshaft pulley..

The compressor is pressure lubricated with the engine oil from the engine lubrication system.

The lamp on instrument panel (38- Fig. 3.2) illuminates at excessively low air pressure inside the trailer air braking system (below $450^{\pm 50}$ kPa).and the pressure gauge (54-Fig. 3.2) informs about the current pressure in the air container.

Avoid to contact the V-belt to oil and grease.

Check the multi V-belts tension every 300 hours of operation. (Fig. 5.4.1).

Belt (2- Fig. 5.4.1).tension is maintained with tensioner.




Fig. 5.13. Diagram of air system. 1 - Air compressor. 2 - Pressure regulating valve. 3 - Air reservoir. 4 - Drain valve. 5 - Air pressure gauge. 6 - Air pressure sensor. 7 - Air pressure drop warning lamp. 8 -Trailer braking valve. 9 - Parking brake valve. 10 - Trailer braking control valve. 11 - Equalizing valve. 12 - Coupling valve. 13 - Coupling valve red. 14 - Coupling valve yellow .




Fig. 5.14. Rear of the tractor
 1- Coupler of supply triple line trailer air braking system. 3- Coupler of single line trailer air braking system. 4- Coupler of control triple line trailer air braking system. 5- Seven pin socket. 6- Quick couplers (see description in 4.5.2). 7- PTO 540/1000 selector lever.. 8- Transmission oil filler plug with dipstick.




Fig. 5.15. Air Pressure regulating valve.
 1-Safety valve.
 2-Tyre inflating valve.
 3-Air regulating valve.

Air reservoir

The capacity of the air reservoir is 15 liters. The air reservoir ensures the compressed air supply to the trailer air braking system. It prevents rapid pressure drop in the system when the trailer air brakes are used frequently.

After 900 hours of operation or after two years of operation, and then every 900 hours or once a year clean the reservoir thoroughly with detergents and blow through with hot air.

At every tractor inspection ensure that the air compressor is firmly secured.

A defective reservoir (cracks, indents, etc.) should be replaced by a new one immediately.

Any kind of the air reservoir repair is not permitted

Drain water from the air reservoir every 10 hours of operation or daily by pushing drain valve at bottom of the reservoir.

Pressure regulating valve with safety valve

The pressure is compressed to the air container through the valve. The valve reduces the air pressure maintained by the compressor to $p_e=0,8^{±0,02}$ and $Δp_e=0,06^{±0,04}$ MPa. The pressure regulating valve is fitted with a tyre inflating valve and a safety valve which limits the maximum air pressure inside the tractor pneumatic installation for braking the trailers (Fig. 5.15).

To inflate the tractor or trailer tyres, first reduce pressure in air system to 0,3 MPa (stop the engine and drop air by the drain valve from the air reservoir) and connect the valve to the wheel inflation valve with a rubber hose and with the engine running, inflate tyres to the prescribed pressure. The valve is located on front lower edge of cab on tractor R.H. side (beside main ground switch).

No periodical servicing of this pressure regulating valve is necessary. Inspections and adjustments can be made by a specialized service only.

Equalizing device

The equalizing device (which is at the same time the foot of R.H. side brake pedal) is used for leveling the R.H. and L.H. pedal plates of the main brake (two pedals latched together).

Neither servicing nor adjustment of this device is necessary.

Trailer braking control valve

The foot brake valve (which is at the same time the foot of R.H. side pedal) is used to operate the trailer brakes.

The trailer braking force is proportional to the pressure exerted on the brake pedal. Pressing on the pedal causes the compressed air supply to the trailer to be progressively cut off and thus braking the trailer. The air escapes through the valve.

Adjust the foot brake valve every 250 hours of operation by setting correct length of the valve linkages.

The adjustment of the foot brake valve must always follow the adjustment of tractor brakes.

Parking brake valve

The valve is connected by pull rod with the parking brake lever. When engaging the parking brake, the hand brake valve is operated (a hissing sound of the air escaping from the valve should be heard). If the hand brake valve is out of operation (no hissing sound) shorten the pull rod which connects the valve with the parking brake lever.

Coupling valve

The pneumatic system of the tractor and trailer can be coupled by means of this valve which is standard design.

Connecting the trailer and tractor air braking system

The tractor is fitted with three couplings (3, 4, 1 - Fig. 5.14.):

white – to couple single line trailer air braking system,

red – to supply triple line trailer air braking system,

yellow – to control triple line trailer air braking system.

All couplings are fitted with automatic valves to cut off tractor air braking system after disconnected of trailer coupling. The couplings are accordant to ISO standard.

To couple the trailer and tractor air braking system, equalize air pressure in tractor system with ambient pressure (by engaging the parking brake) and after connecting hose couplers release the parking brake. Tractor and trailer braking should be at the same time. Couple also trailer electrical system to the tractor seven pin socket (5 - Fig. 5.14.).

5.14. Hydraulic lift.

Hydraulic lift is supplied with oil from tractor transmission system.

Grease lift rocker solid grease.

6. TRACTOR STORAGE

If your tractor is to be out of service of any length of time, certain precautionary measures must be taken to safeguard it.

It is recommended, if the standstill period is not very long, to run the engine every 7 days until the operating temperature of the engine is reached (green scale in the water temperature gauge).

If the tractor is to be out of service for an extended period of time the following precautionary measures should be taken:

- clean the tractor,
- drain the engine and transmission oil and refill with fresh oil,
- drain the fuel tank and pour approximately 10 litres of special calibrating fuel into the tank. Run the engine for at least 10 minutes to ensure complete distribution of the calibration fuel throughout injection system. See the next item before running the engine,
- check the radiator coolant level. If the coolant is within 200 hours of the next change, renew the coolant. Run the engine for one hour to disperse the inhibitor throughout the cooling system,
- lubricate all grease fittings,
- rise the lift linkage hydraulically and support the lift arms in the fully raised position,
- lightly coat all exposed hydraulic piston rods with petroleum jelly, e.g. power steering cylinder rams, spool valves, etc.,
- remove the battery and store in a warm, dry atmosphere. Recharge periodically,
- block the clutch pedal in the fully depressed position,
- cover the exhaust pipes opening

PREPARING THE TRACTOR FOR USE AFTER STORAGE

- inflate the tires to the correct pressure,
- refill the fuel tank,
- check the radiator coolant level,
- check all oil levels,
- install a fully charged battery,
- remove the exhaust pipe covering,
- start the engine and check that all instruments and controls are functioning correctly,
- drive the tractor without a load to ensure that it is operating satisfactorily