

Parts Catalog

FARMTRAC

TRACTOR FARMTRAC 6045 HERITAGE

Escorts Agri Machinery

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
1	Cylinder Block, Liner And Cyl Head	1	1-4
2	Crankshaft And Fly Wheel Assembly	2	5-6
3	Camshaft	3	7-10
4	Piston And Connecting Rod	4	11-12
5	Oil Pump And Oil Pan	5	13-14
6	Exhaust System Subassembly	6	15-16
7	Fuel Tank And Fuel System	7	17-20
8	Thermostat	9	21-22
9	Water Pump	11	23-24
10	Air Intake Subassembly	12	25-26
11	Cooling System Subassembly	13	27-28
12	Frame Cooling System And Electrical Front Assembly	14	29-30
13	Throttle Control	15	31-32
14	Guard Assembly Radiator RH	16	33-34
15	Guard Assembly Radiator LH	17	35-36
16	Axle Front And Support Assembly (Power Steering)	18	37-38
17	Axle Front With Slider And Spindle Assembly (Power Steering)	19	39-40
18	Slider And Spindle Assembly Lh	20	41-42
19	Slider And Spindle Assembly Rh	21	43-44
20	Motor And Column Assembly Power Steering	22	45-46
21	Tube Steering	23	47-48
22	Clutch Assembly	24	49-50
23	Clutch Controls	25	51-52
24	Transmission Case And Shift Levers	26	53-56
25	Transmission Gears	27	57-60
26	Center Housing	28	61-62
27	Differential And Gear Set	29	63-64
28	Differntial Lock	30	65-66
29	Rear Axle	31	67-68
30	Power Take-Off Assembly	32	69-70

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
31	Independent Parking Brake Assembly	33	71-72
32	WHEEL AND TYRE ASSEMBLY FRONT	34	73-74
33	Wheel And Tyre Assembly Rear	35	75-76
34	Oil Immeresed Brake	36	77-80
35	Oil Immeresed Brakes-Pipes	37	81-82
36	BRAKE LINKAGE SUBASSEMBLY	38	83-84
37	Hydraulic Lift Cover	39	85-92
38	Hydraulic Lift Cylinder	40	93-94
39	Hydraulic Lift Shafts	41	95-98
40	Hydraulic Flow System	42	99-100
41	Linkage Three Point Subassembly	43	101-102
42	Tubing Hydraulic Subassembly	44	103-106
43	Hydraulic Tubing Subassembly	45	107-108
44	Solenoid And Linkage Subassembly	46	109-110
45	Liftomatic Control Subassembly	47	111-112
46	BATTERY SUBASSEMBLY	48	113-114
47	Harness Subassembly	49	115-116
48	Lamp Beacon Subassembly	50	117-118
49	Fender Assembly With Electrical Rear Rh	51	119-120
50	Fender Assembly With Electrical Rear Lh	52	121-122
51	Hood Front And Panel Top Assembly	54	123-124
52	Grill Front And Bezel Assembly	55	125-126
53	Hood Rear And Instrument Cluster Assembly	56	127-128
54	Seat Driver Subassembly	57	129-130
55	Hitch Rear Subassembly	58	131-132
56	Rops Foldable Assembly	59	133-134
57	Canopy Assembly	60	135-136
58	Ballast Front Subassembly	61	137-138
59	Ballast Rear Subassembly	62	139-140
60	Deflector Subassembly	63	141-142

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
61	Rear View Mirror	64	143-144
62	Tool Box Subassembly	65	145-146
63	Decal	66	147-148
64	Decal	66A	149-150
65	Accessories Ft Engine (Power Steering)	67	151-152
66	CRANKSHAFT AND GEAR ASSEMBLY	47	153-154
67	KIT ENGINE MAIN AND CONNECTING ROD BEARING SET SIZE STANDARD	48	155-156
68	KIT ROCKER ARM WITH SCREW	44	157-158
69	KIT ENGINE MAIN BEARING SET SIZE STANDARD	50	159-160
70	KIT PISTON RING SET	45	161-162
71	KIT ENGINE INLET AND EXHAUST VALVES	47	163-164
72	HOOTER & RELAY	74	165-166
73	KIT GEAR BOX BALL AND SPRING	1	167-168
74	KIT OIL PUMP REPAIR	46	169-170
75	KIT BUSHING HYDRAULIC LIFT SHAFT	103	171-172
76	KIT SLEEVE PTO	47	173-174
77	KIT MIRROR AND BRACKET REAR VIEW	50	175-176
78	KIT CUP AND CONE ROLLER BEARING REAR AXLE	104	177-178
79	KIT PINION AND GEAR REAR AXLE DIFFERENTIAL SIDE LH/RH	51	179-180
80	KIT LEVER HYDRAULIC LIFT DRAFT CONTROLWITH LEVER AND LINK	52	181-182
81	KIT REAR WHEEL BOLT AND NUT	105	183-184
82	KIT WASHER SET CENTRE PIN	59	185-186
83	KIT SHAFT AND BOLT ASSEMBLY REAR AXLE	53	187-188
84	KIT CUP AND CONE ROLLER BEARIN	54	189-190
85	KIT CONVERSION Â REAR AXLEÂ HOUSING LH	85	191-192

TABLE-1
Cylinder Block, Liner And Cyl Head




TABLE-1**Cylinder Block, Liner And Cyl Head**

Fig. No.	Part No.	Description	Qty
1	D10473820.9	HEAD ASSEMBLY CYLINDER (FT6050 EXPORT)	1
2	D10082880.9	PLUG 1.12" CUP	3
3	D10082900.9	PLUG 1.761" CUP	1
4	D10473830.9	HEAD CYLINDER MACHINED (FT6050 EXPORT)	1
5	D10045040.9	INSERT INTAKE VALVE SEAT	3
6	D10045030.9	INSERT EXHAUST VALVE SEAT	3
6A	D10011390.9	BOLT CYLINDER HEAD	10
7	D81000150.9	BOLT 3/8"-16X0.75" HEX HEAD	3
8	D86000010.9	WASHER 3/8" SPRING LOCK	3
9	D10346240.9	GASKET ENGINE TO TRANSMISSION ASSEMBLY	1
10	D10348720.9	ADAPTER PLATE ENGINE	1
10A	D10017570.9	GASKET STARTER MOTOR	1
11	D10044860.9	GASKET REAR PLATE	1
12	D81000330.9	BOLT 5/16"-18X1.00" HEX HEAD	8
13	D86000040.9	WASHER 5/16" SPRING LOCK	8
14	D10223860.9	GASKET CYLINDER HEAD E3.315 AVL (NON ASBESTOS)	1
15	D10175540.9	CARRIER SEAL REAR OIL SEAL	1
16	D93100040.9	PLUG 3/8"X0.42" HEX HEAD	2
18	D10010280.9	DOWEL CYLINDER HEAD TO BLOCK CYLINDER	2
19	D10448380.9	BLOCK ASSEMBLY CYLINDER F3.315	1
19A	D10067030.9	PLUG COVER	1
20	D93100010.9	PLUG 1/4"-18 PIPE	1
21	D10082890.9	PLUG 1.50" CUP	2
22	D10011570.9	PLUG 0.761" CUP	2
23	D10010150.9	BEARING CAM SHAFT	1
23A	D10010230.9	BEARING CRANKSHAFT MAIN LOWER	3
24	D87000030.9	PIN 3/8"X1.125" PLAIN DOWEL	2
25	D10010240.9	BOLT 9/16"-12X4.45" HEX HEAD	8
26	D10412970.9	CAP CRANKSHAFT MAIN BEARING REAR (F3.287)	1
26A	D10412960.9	CAP CRANKSHAFT MAIN BEARING (F3.287)	3
27	D10010330.9	PIN 1/2"X1.00" DOWEL	2
29	D93100110.9	PLUG REAR THREAD	1
30	D93100020.9	PLUG 1/8"-27 HEX HEAD	1
31	D10175540.9	CARRIER SEAL REAR OIL SEAL	1
32	D10012340.9	STIFFENER ENGINE REAR COVER PLATE	1
33	D10405550.9	INSERT OIL FILTER MOUNTING	1
34	D10405960.9	FILTER ASSEMBLY LUBE OIL (FARMTRAC)	1
35	D10193260.9	INDICATOR ASSEMBLY OIL LEVEL	1
36	D10193250.9	TUBE OIL LEVEL INDICATOR	1
37	D93100030.9	PLUG 3/8"-18 HEX HEAD	1

TABLE-1

Cylinder Block, Liner And Cyl Head




TABLE-1**Cylinder Block, Liner And Cyl Head**

Fig. No.	Part No.	Description	Qty
38	D10010890.9	DEFLECTOR FAN AIR RH	1
39	D83000060.9	NUT 5/16"-18 HEX	2
40	D86000040.9	WASHER 5/16" SPRING LOCK	2
41A	D10010740.9	RING FUEL INJECTION PUMP	1
42	D10424930.9	HOUSING TIMING GEAR INLINE FIP	1
43	D84500040.9	STUD B M8X22-8.8	4
45	D10192780.9	GASKET TIMING GEAR INSPECTION COVER	1
46	D10251150.9	COVER TIMING GEAR ENGINE	1
47	D10044730.9	COVER FUEL INJECTION PUMP TIMING	1
48	D10010920.9	FILTER ASSEMBLY ENGINE LUBE OIL	1
49	D10039090.9	CAP OIL FILLING	1
50	D86000040.9	WASHER 5/16" SPRING LOCK	5
51	D81000210.9	BOLT 3/8"-16X2.50" HEX HEAD	2
52	D81000180.9	BOLT 5/16"-18X2.12" HEX HEAD	4
53	D86000040.9	WASHER 5/16" SPRING LOCK	4
54	D81000340.9	BOLT 5/16"-18X2.50" HEX HEAD	2
55	D81000190.9	BOLT 3/8"-16X1.50" HEX HEAD	1
56	D81000210.9	BOLT 3/8"-16X2.50" HEX HEAD	2
57	D86000010.9	WASHER 3/8" SPRING LOCK	8
58	D81000170.9	BOLT 3/8"-16X2.25" HEX HEAD	8
59	D10010220.9	BEARING CRANKSHAFT MAIN UPPER	3
60	D81000330.9	BOLT 5/16"-18X1.00" HEX HEAD	8
61	D10045010.9	GUIDE VALVE	6
62	D10061780.9	STOP OIL PUMP GEAR	1

TABLE-2
Crankshaft And Fly Wheel Assembly




TABLE-2**Crankshaft And Fly Wheel Assembly**

Fig. No.	Part No.	Description	Qty
1	D10198950.9	PULLEY CRANKSHAFT B TYPE (BALANCED)	1
2	D91000060.9	KEY 3/16"X3/4" WOODRUFF	1
3	D86500090.9	WASHER M10 SPRING LOCK	1
4	D10010450.9	BOLT 3/4"-16X1.75" HEX HEAD	1
5	D10010380.9	GEAR CRANKSHAFT	1
7	D10010400.9	SEAL O RING 0.103"X1.75"	1
8	D10010850.9	SEAL DUST CRANKSHAFT FRONT	1
9	D10009550.9	SEAL OIL CRANKSHAFT FRONT (M/S FENNER PART NO 7844)	1
10	D10251140.9	SPACER CRANKSHAFT PULLEY	1
11	D81000300.9	BOLT 9/16"-18X1.625" HEX HEAD	6
12	D86000040.9	WASHER 5/16" SPRING LOCK	6
13	D10389150.9	FLYWHEEL ASSEMBLY (DUAL CLUTCH)	1
14	D10044920.9	DOWEL FLY-WHEEL	1
15	D10011200.9	SEAL OIL ASSEMBLY CRANKSHAFT REAR	1
16	D10344460.9	CRANKSHAFT	1
17	D10010200.9	BEARING CRANKSHAFT MAIN THRUST UPPER	1
18	D10010210.9	BEARING CRANKSHAFT MAIN THRUST LOWER	1
19	D10308030.9	RING GEAR FLYWHEEL	1
20	D10011710.9	RETAINER CLUTCH PILOT BEARING	1
21	D10010460.9	BEARING CLUTCH PILOT	1

TABLE-3

Camshaft




TABLE-3
Camshaft

Fig. No.	Part No.	Description	Qty
1	D10012510.9	CLAMP ASSEMBLY RADIATOR HOSE UPPER	2
2	D10193240.9	HOSE CRANK CASE VENTILATION	1
3	D10193290.9	TUBE ASSEMBLY CRANK CASE VENTILATION AVL (POWER STEERING)	1
4	D10011390.9	BOLT CYLINDER HEAD	4
5	D10212790.9	BRACKET VALVE ROCKER	4
6	D10196470.9	ARM ROCKER VALVE	6
7	D10196000.9	SCREW ROCKER ARM ADJUSTING	6
8	D10011590.9	SPRING VALVE ROCKER ARM	3
9	D10011600.9	SPACER VALVE ROCKER ARM	3
10	D10011570.9	PLUG 0.761" CUP	2
11	D10011560.9	SHAFT VALVE ROCKER	1
12	D82500070.9	SCREW M8X1.25X15-6.8 HEX HEAD	8
13	D86000040.9	WASHER 5/16" SPRING LOCK	8
14	D10229340.9	COVER ASSEMBLY VALVE ROCKER ARM	1
15	D10044820.9	GASKET VALVE ROCKER ARM	1
16	D10045200.9	KEY VALVE SPRING RETAINER	12
17A	D10044900.9	RETAINER VALVE SPRING LOWER	6
17B	D10045050.9	RETAINER VALVE SPRING UPPER	6
18	D10045060.9	SEAL VALVE STEM	6
19	D10044890.9	SPRING VALVE	6
20	D10044510.9	TAPPET VALVE	6
21	D10045070.9	ROD VALVE PUSH	6
22	D81000090.9	BOLT 7/16"-14X1.25" HEX HEAD	1
23	D86000020.9	WASHER 7/16" SPRING LOCK	1
24	D10010520.9	WASHER CAMSHAFT	1
25	D10387910.9	GEAR CAMSHAFT	1
26	D10061110.9	BOLT 7/16"-14X1.38" HEX HEAD	2
27	D86000040.9	WASHER 5/16" SPRING LOCK	2
28	D10010490.9	PLATE CAM SHAFT THRUST	1
29	D10010480.9	SPACER CAM SHAFT	1
30	D10010150.9	BEARING CAM SHAFT	4
31	D10387920.9	GEAR ASSEMBLY CAMSHAFT DRIVE	1
32	D10397860.9	CAMSHAFT ENGINE	1
33	D91000060.9	KEY 3/16"X3/4" WOODRUFF	1
34	D10020980.9	BUSH CAM SHAFT DRIVE	1
35	D10010560.9	ADAPTER CAM SHAFT	1
36	D10010570.9	BOLT 5/8"-11X2.125" HEX HEAD LOCK	1
37	D10044490.9	VALVE EXHAUST	3
38	D10044500.9	VALVE AIR INTAKE	3
40	D10010520.9	WASHER CAMSHAFT	1

TABLE-3
Camshaft




TABLE-3

Camshaft

Fig. No.	Part No.	Description	Qty
41	D86000020.9	WASHER 7/16" SPRING LOCK	1
42	D81000090.9	BOLT 7/16"-14X1.25" HEX HEAD	1
43	D10175570.9	PLUG CAMSHAFT HYDRAULIC PUMP DRIVE GEAR	1

TABLE-4
Piston And Connecting Rod




TABLE-4**Piston And Connecting Rod**

Fig. No.	Part No.	Description	Qty
2	D10010670.9	RING PISTON COMPRESSION UPPER	3
3	D10010680.9	RING PISTON COMPRESSION LOWER	3
4	D10044670.9	CONFORMABLE OIL RING ASSEMBLY AVL-70	3
5	D10045100.9	RING RETAINING	6
6	D10044660.9	PIN PISTON AVL-70	3
7	D10368890.9	PISTON 4.4 FT60AVL OVER SIZE GRADE A (M/S FM)	3
9	D10212460.9	ROD AND CAP ASSEMBLY CONNECTIN	3
10	D10044990.9	BUSH CONNECTING ROD	3
11	D10212470.9	BOLT M12X69-10.9 CONNECTING ROD	6
13	D10045000.9	BEARING CONNECTING ROD	6
15	D10368891.9	PISTON 4.4 FT60AVL (M/S IPL)	3

TABLE-5
Oil Pump And Oil Pan




TABLE-5**Oil Pump And Oil Pan**

Fig. No.	Part No.	Description	Qty
1	D10193410.9	SHAFT AND GEAR LUBE OIL PUMP DRIVE ASSEMBLY	1
1A	D10011130.9	GEAR LUBE OIL PUMP DRIVE	1
1B	D10184300.9	SHAFT LUBE OIL PUMP DRIVE	1
1C	D87000040.9	PIN 5/32"X0.88" SPRING DOWEL	1
2	D10011170.9	SHAFT LUBE OIL PUMP	1
3	D10011140.9	GASKET LUBE OIL PUMP	1
4	D10044480.9	BODY OIL PUMP AVL	1
5	D10011150.9	WASHER LUBE OIL PUMP LOCK	2
6	D10011160.9	BOLT 3/8"-16X1.38" HEX HEAD	2
7	D10011060.9	ROTOR ASSEMBLY LUBE OIL PUMP OUTER AND INNER	1
8	D10011000.9	SHAFT LUBE OIL PUMP DRIVE	1
9	D10011040.9	STOP LUBE OIL PUMP RELIEF VALVE	1
10	D86500030.9	WASHER M8 SPRING LOCK	1
11	D81000200.9	BOLT 5/16"-18X0.75 HEX HEAD	1
12	D10010970.9	PUMP ASSEMBLY ENGINE LUBE OIL	1
13	D10010990.9	PLUG LUBE OIL PUMP RELIEF VALVE	1
14	D10011010.9	SPRING LUBE OIL PUMP RELIEF VALVE	1
15	D10011050.9	VALVE LUBE OIL PRESSURE RELIEF	1
16	D10011020.9	COVER LUBE OIL PUMP	1
17	D10011070.9	COVER LUBE OIL PUMP SCREEN	1
18	D10011030.9	SCREEN LUBE OIL PUMP	1
19	D10011080.9	SPRING LUBE OIL PUMP SCREEN	1
20	D10011090.9	BOLT M6X1.00X20-6.6 HEX FLANGED (LUBE OIL PUMP)	4
21	D86000050.9	WASHER 1/4" SPRING LOCK	4
23	D10044630.9	PAN ASSEMBLY OIL	1
24	D85000010.9	WASHER 3/8" FLAT	25
25	D86000010.9	WASHER 3/8" SPRING LOCK	22
26	D81000060.9	BOLT 3/8"-16X1.00" HEX HEAD	25
27	D10061670.9	PLUG OIL PAN DRAIN	1
28	D10044710.9	GASKET DRAIN PLUG	1

TABLE-6
Exhaust System Subassembly




TABLE-6**Exhaust System Subassembly**

Fig. No.	Part No.	Description	Qty
1	D10507760.9	BRACKET ASSEMBLY SUPPORT MUFFLER HORIZONTAL (FRONT)	1
2	D10507620.9	MUFFLER ASSEMBLY HORIZONTAL(INSIDE)	1
3	D10496070.9	GASKET EXHAUST ELBOW	1
4	D10551450.9	ELBOW ASSEMBLY EXHAUST PIPE	1
5	D10507800.9	SUPPORT ASSEMBLY EXHAUST ELBOW	1
6	D10559730.9	GASKET PIPE TAIL ASSEMBLY EXHAUST MUFFLER	1
7	D10551360.9	PIPE TAIL ASSEMBLY EXHAUST MUFFLER	1
8	D10551490.9	GUARD ELBOW EXHAUST PIPE	1
9	D85500050.9	WASHER M8 FLAT	8
10	D85500110.9	WASHER M6 FLAT	2
11	D85500010.9	WASHER M10 FLAT	2
12	D86000010.9	WASHER 3/8" SPRING LOCK	3
13	D86500050.9	WASHER M10 SPRING LOCK	4
14	D86500030.9	WASHER M8 SPRING LOCK	10
15	D81000060.9	BOLT 3/8"-16X1.00" HEX HEAD	3
16	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	4
17	D82500080.9	SCREW M8X1.25X25-8.8 HEX HEAD	2
18	D81500310.9	SCREW M8X1.25X30-8.8 HEX HEAD	4
19	D81500200.9	BOLT M10X1.50X20-6.6 HEX HEAD	2
20	D82500050.9	SCREW M6X1.00X12-6.8 HEX HEAD	2
21	D84500020.9	STUD B M10X26-6.8 ZINC PASSIVATED	2
22	D83500060.9	NUT M8X1.25-6 HEX	6
23	D83500090.9	NUT M10X1.50-8 HEX	2
24	D10321610.9	MANIFOLD ENGINE AIR INTAKE	1
25	D10205310.9	MANIFOLD EXHAUST	1
26	D10386620.9	GASKET EXHAUST MANIFOLD	1
27	D10011540.9	GASKET MUFFLER PIPE INLET	1
28	D81000280.9	BOLT 3/8"-16X1.00" HEX HEAD	3
29	D81500210.9	BOLT M10X1.50X35-6.6P HEX HEAD	8
30	D10011480.9	SENSOR UNIT WATER TEMPERATURE GAUGE	1
31	D10045190.9	BOLT M8X1.25X130-6.6 HEX HEAD	3

TABLE-7**Fuel Tank And Fuel System**

Fig. No.	Part No.	Description	Qty
1	D10044870.9	TUBE ASSEMBLY FUEL INJECTION LEAK OFF	1
2	D10017510.9	WASHER FIP LEAK OFF TUBE (TYPE 603)	6
3	D10047580.9	BOLT HEX HEAD PIPE UNION	3
4	D10088780.9	CLAMP THERMOSTAT TUBE	2
5	D10026170.9	TUBE NYLON THERMOSTAT	1
6	D10017460.9	CLAMP ASSEMBLY FUEL TUBE	2
7	D10017360.9	CONNECTOR FUEL RETURN TO TANK TUBE	1
8	D10044460.9	INJECTOR ASSEMBLY FUEL (MICO PART NUMBER F002C8Z870)	3
8A	D81000260.9	BOLT 5/16"-18X1.50" HEX HEAD	6
9	D86000040.9	WASHER 5/16" SPRING LOCK	6
10	D10011410.9	SEAL FUEL INJECTOR	3
11	D10045150.9	WASHER FUEL INJECTOR TUBE	3
12	D10314580.9	TUBE ASSEMBLY FUEL TANK RETURN	1
13	D10337890.9	TUBE ASSEMBLY FUEL INJECTION CYLINDER #3 (FT60AVL BT 3A)	1
13A	D10011450.9	CLAMP ASSEMBLY FUEL INJECTION TUBE	2
14	D10337880.9	TUBE ASSEMBLY FUEL INJECTION CYLINDER #2 (FT60AVL BT 3A)	1
15	D10337870.9	TUBE ASSEMBLY FUEL INJECTION CYLINDER #1 (FT60AVL BT 3A)	1
17	D10012580.9	WASHER 14.2X19.9 COPPER SEALING (MICO PART NO 2916710610)	17
18	D10012590.9	BOLT M14X1.5X25.5 HEX HEAD PIPE UNION	7
19	D10397740.9	TUBE ASSEMBLY FUEL FEED PUMP TO FUEL FILTER	1
20	D81000720.9	BOLT 3/8"-16X0.875" HEX HEAD	2
21	D85000010.9	WASHER 3/8" FLAT	2
22	D81000570.9	BOLT 1/2"-20X2.00" HEX HEAD	2
24	D86000060.9	WASHER 1/2" SPRING LOCK	2
25	D83000140.9	NUT 1/2"-20 HEX	2
26	D10559910.9	CAP AND KEY ASSEMBLY FUEL TANK	1
27	D10561420.9	FUEL TANK ASSEMBLY WITH CAP AND KEY	1
27A	D10212530.9	BEADING CONSOLE FUEL TANK	1
28	D10348870.9	TUBE ASSEMBLY WATER SEPARATOR TO FUEL FEED PUMP	1
28A	D10015140.9	FILTER ASSEMBLY FUEL (MICO PART NO 9450030120)	1
29	D10013040.9	SEAL O RING FUEL INJECTION PUMP	1
29A	D10010740.9	RING FUEL INJECTION PUMP	1
30	D10044980.9	PIPE FUEL INJECTION PIPE LUBRICATION	1
31	D10303470.9	PUMP ASSEMBLY FUEL INJECTION LLR 8MM LIFT AF3.315 (1850RPM X-TRA TORQUE)	1
32	D85000010.9	WASHER 3/8" FLAT	3
33	D81000190.9	BOLT 3/8"-16X1.50" HEX HEAD	4
34	D10010500.9	CLIP FUEL INJECTION PUMP	1
35	D10010800.9	BOLT FUEL INJECTION PUMP ADAPTER PLATE	3
36	D86000040.9	WASHER 5/16" SPRING LOCK	3
37	D10010780.9	PLATE FUEL INJECTION PUMP	1

TABLE-7
Fuel Tank And Fuel System




TABLE-7**Fuel Tank And Fuel System**

Fig. No.	Part No.	Description	Qty
38	D10387930.9	GEAR FUEL INJECTION PUMP DRIVE	1
39	D10010760.9	COUPLING FUEL INJECTION PUMP DRIVE	1
40	D10598920.9	BRACKET ASSEMBLY WATER PARATOR AND SOLENOID PIVOT MOUNTING	1
41	D10192790.9	GASKET FUEL INJECTION PUMP	1
42	D81500610.9	BOLT M10X1.50X40-8.8 HEX HEAD	2
43	D10035000.9	SEPARATOR ASSEMBLY WATER	1
44	D10397760.9	TUBE ASSEMBLY FUEL FILTER TO FUEL INJECTION PUMP	1
45	D10366610.9	TAP AND SCREEN ASSEMBLY FUEL CONTROL	1
45A	D10160380.9	WASHER 22.0X29.0 SEALING	1
46	D81000650.9	BOLT 5/16"-24X0.625" HEX HEAD	1
47	D10348880.9	HOSE ASSEMBLY FUEL TANK TO FUEL WATER SEPARATOR	1
48	D81000330.9	BOLT 5/16"-18X1.00" HEX HEAD	1
49	D10018360.9	SPACER FUEL TANK MOUNTING LOWER	1
50	D86000110.9	WASHER 5/16" LOCK EXTERNAL TOOTH	1
51	D85000040.9	WASHER 5/16" FLAT	1
52	D83000080.9	NUT 5/16"-18 HEX	1

TABLE-9
Thermostat




TABLE-9
Thermostat

Fig. No.	Part No.	Description	Qty
1	D10011760.9	GASKET WATER OUTLET	1
2	D10096420.9	THERMOSTART ENGINE	1
3	D10011770.9	CONNECTION WATER OUTLET	1
4	D10011750.9	THERMOSTAT ASSEMBLY WATER	1
5	D86500030.9	WASHER M8 SPRING LOCK	3
6	D81500260.9	BOLT M8X1.25X55-6.6P HEX HEAD	3
7	D10013970.9	CLAMP HOSE 35A	2
8	D10013780.9	HOSE WATER PUMP TO THERMOSTAT HOUSING	1

TABLE-11
Water Pump




TABLE-11
Water Pump

Fig. No.	Part No.	Description	Qty
1	D10011250.9	GASKET WATER PUMP	1
2	D10441440.9	PUMP WATER AND HUB ASSEMBLY	1
3	D10063000.9	GASKET WATER PUMP COVER	1
4	D10068820.9	IMPELLER WATER PUMP	1
5	D10068860.9	SEAL AND SEAT ASSEMBLY WATER PUMP	1
6	D10011240.9	BEARING WATER PUMP	1
7	D86000040.9	WASHER 5/16" SPRING LOCK	4
8	D81000160.9	BOLT 5/16"-18X.75" HEX HEAD LOCK	4
9	D10389650.9	PULLEY WATER PUMP (SHEET METAL)	1
10	D81000250.9	BOLT 7/16"-14X3.00" HEX HEAD	4
11	D86000020.9	WASHER 7/16" SPRING LOCK	4
12	D10123410.9	FAN ASSEMBLY WATER COOLING DIA 380MM (METALLIC)	1
13	D10198990.9	BELT DRIVE COGGED (B TYPE)	1
14	D86000040.9	WASHER 5/16" SPRING LOCK	4
15	D81000420.9	BOLT 5/16"-18X0.88" HEX HEAD	4

TABLE-12
Air Intake Subassembly




TABLE-12**Air Intake Subassembly**

Fig. No.	Part No.	Description	Qty
1	D83500060.9	NUT M8X1.25-6 HEX	5
2	D85500050.9	WASHER M8 FLAT	5
3	D86500030.9	WASHER M8 SPRING LOCK	1
4	D10345210.9	CLEANER ASSEMBLY ENGINE AIR (DRY TYPE)	1

TABLE-13
Cooling System Subassembly




TABLE-13**Cooling System Subassembly**

Fig. No.	Part No.	Description	Qty
1	D81500200.9	BOLT M10X1.50X20-6.6 HEX HEAD	2
2	D10441200.9	RADIATOR AND SHROUD ASSEMBLY	1
3	D10441260.9	HOSE WATER PUMP TO RADIATOR INLET	1
4	D10017540.9	CLAMP RADIATOR HOSE UPPER	2
5	D85500010.9	WASHER M10 FLAT	2
6	D85500060.9	WASHER M12 FLAT	2
7	D82500090.9	SCREW M12X1.75X25-6.6 HEX HEAD	2
8	D10017620.9	CLAMP RADIATOR HOSE LOWER	2
9	D10323280.9	HOSE WATER PUMP TO RADIATOR OUTLET	1
10	D81000420.9	BOLT 5/16"-18X0.88" HEX HEAD	4
11	D86000040.9	WASHER 5/16" SPRING LOCK	4
12	D10123410.9	FAN ASSEMBLY WATER COOLING DIA 380MM (METALLIC)	1
13	D10581630.9	FOAM SEALING RADIATOR SIDE RH	1
14	D10581620.9	FOAM SEALING RADIATOR SIDE LH	1
15	D10581640.9	FOAM SEALING RADIATOR BOTTOM	1
16	D10611500.9	FOAM SEALING RADIATOR TOP	1

TABLE-14
Frame Cooling System And Electrical Front Assembly




TABLE-14**Frame Cooling System And Electrical Front Assembly**

Fig. No.	Part No.	Description	Qty
1	D10344900.9	FRAME ASSEMBLY RADIATOR	1
2	D10223100.9	LATCH ASSEMBLY HOOD	1
3	D81500340.9	BOLT M6X1.00X35-8.0 HEX HEAD	4
4	D10441230.9	FOAM SEALING RADIATOR SIDE	1
5	D10293310.9	CLIP CABLE LATCH	1
6	D83500060.9	NUT M8X1.25-6 HEX	1
7	D86500150.9	WASHER M8 SPRING LOCK	1
8	D10338530.9	WIRE ASSEMBLY HEAD LAMP PROJECTOR	1
9	D81500590.9	BOLT M8X1.25X25-6.6 HEX HEAD	2
10	D10297810.9	BAFFLE ASSEMBLY FRONT AXLE SUPPORT	1
11	D10344880.9	SUPPORT ASSEMBLY RADIATOR LH	1
12	D10344890.9	SUPPORT ASSEMBLY RADIATOR RH	1

TABLE-15
Throttle Control




TABLE-15
Throttle Control

Fig. No.	Part No.	Description	Qty
1	D81000400.9	NUT 1/4"-28 HEX	1
2	D10012910.9	ARM ASSEMBLY ACCELERATOR CONTROL	1
3	D10043360.9	ROD ASSEMBLY THROTTLE CONTROL	1
4	D10045210.9	LINKAGE ASSEMBLY THROTTLE CONTROL	1
5	D10012760.9	BRACKET ACCELERATOR PEDAL	1
6	D10019090.9	ARM ASSEMBLY HAND THROTTLE CONTROL	2
7	D10104660.9	LEVER HAND THROTTLE	1
8	D10511400.9	KNOB HAND THROTTLE CONTROL LEVER	1
9	D10083700.9	LINK ASSEMBLY FOOT ACCELERATOR	1
10	D10017560.9	PIN 3/8"X13/16" CLEVIS	1
11	D85000010.9	WASHER 3/8" FLAT	1
12	D10013450.9	PIN 3/32"X0.75" COTTER	1
13	D10026540.9	GROMMET HAND THROTTLE CONTROL LEVER	1
14	D10240100.9	SPACER HAND THROTTLE CONTROL LEVER	1
15	D10018690.9	WASHER 5/16" FLAT	1
16	D81000670.9	BOLT 5/16"-24X1.25" SQUARE HEAD	1
17	D10016890.9	NUT 3/8"-24 HEX	1
18	D10017960.9	PLATE THROTTLE CONTROL	1
19	D10021590.9	PLATE ASSEMBLY THROTTLE CONTROL POWER STEERING	1
20	D10018170.9	DISC THROTTLE CONTROL	2
21	D10016480.9	SPRING GOVERNOR MANUAL CONTROL LEVER	1
22	D85000050.9	WASHER 3/8" FLAT	2
23	D10017970.9	STOP THROTTLE CONTROL LEVER	1
24	D82500030.9	SCREW M5X0.80X10-6.6 HEX HEAD	1
25	D10012750.9	SPRING FOOT ACCELERATOR PEDAL	2
26	D10019410.9	NUT 5/16"-24 HEX	1
27	D81500310.9	SCREW M8X1.25X30-8.8 HEX HEAD	2
28	D86000010.9	WASHER 3/8" SPRING LOCK	2
29	D10000640.9	PIN 1/16"X0.50" COTTER	1
30	D85000030.9	WASHER 1/4" FLAT	3
31	D10012920.9	PEDAL ASSEMBLY ACCELERATOR	1
32	D10012940.9	PAD AND HUB ASSEMBLY ACCELERATOR PEDAL	1
33	D81000390.9	BOLT 1/4"-28X0.62" HEX HEAD	2
34	D10012780.9	BRACKET AND HUB ASSEMBLY ACCELERATOR PEDAL	1

TABLE-16
Guard Assembly Radiator RH




TABLE-16**Guard Assembly Radiator RH**

Fig. No.	Part No.	Description	Qty
1	D10341710.9	GUARD ASSEMBLY SIDE RH	1
2	D10286160.9	STRIP LOCK SIDE GUARD	1
3	D10342180.9	PIN LOCATING	2
4	D10319000.9	SEALING ASSEMBLY SIDE GUARD LOWER RH (FT6050)	1
5	D10286140.9	PIN LOCK SIDE PANEL	2
6	D10016990.9	SCREW M4X0.70X10 CROSS RECESSED PAN HEAD	2
7	D10017000.9	NUT M4X0.70 NYLOCK	2
8	D10342430.9	SEALING ASSEMBLY SIDE GUARD UPPER	1
9	D10306490.9	PIN LOCK SIDE GUARD	1
10	D82500030.9	SCREW M5X0.80X10-6.6 HEX HEAD	5
11	D85500090.9	WASHER M5 FLAT	5

TABLE-17
Guard Assembly Radiator LH




TABLE-17**Guard Assembly Radiator LH**

Fig. No.	Part No.	Description	Qty
1	D10342140.9	GUARD ASSEMBLY SIDE LH	1
2	D10016990.9	SCREW M4X0.70X10 CROSS RECESSED PAN HEAD	2
3	D10311740.9	STRIP LOCK SIDE GUARD	1
4	D10017000.9	NUT M4X0.70 NYLOCK	2
5	D10319020.9	SEALING ASSEMBLY SIDE GUARD LOWER LH (FT6050)	1
6	D10342430.9	SEALING ASSEMBLY SIDE GUARD UPPER	1
7	D82500030.9	SCREW M5X0.80X10-6.6 HEX HEAD	5
8	D85500090.9	WASHER M5 FLAT	5
9	D10306490.9	PIN LOCK SIDE GUARD	2

TABLE-18
Axle Front And Support Assembly (Power Steering)




TABLE-18**Axle Front And Support Assembly (Power Steering)**

Fig. No.	Part No.	Description	Qty
1	D10297150.9	SUPPORT FRONT AXLE	1
2	D10634750.9	AXLE FRONT WITH SLIDER AND SPINDLE ASSEMBLY (POWER STEERING)	1
3	D10286530.9	FRONT SUPPORT (PILLOW BLOCK)	1
4	D10013020.9	PLUG AND NUT ASSEMBLY FRONT AXLE TRUNION	1
5	D90500120.9	CIRCLIP B62X2.0 N	1
6	D93100020.9	PLUG 1/8"-27 HEX HEAD	1
7	D92500020.9	GREASE NIPPLE A M10X1	1
8	D81000370.9	BOLT 1/2"-13X2.25" HEX HEAD	4
9	D10003580.9	WASHER 1/2" FLAT	4
10	D10012730.9	SHIM FRONT AXLE CENTRE PIN (0.016")	1
11	D10012880.9	WASHER FRONT AXLE CENTRE PIN THRUST	1
12	D10012680.9	SEAL O RING 0.780"X1.98"	1
13	D10286520.9	PILLOW BLOCK REAR	1
14	D92500010.9	GREASE NIPPLE B M6	1
15	D86500040.9	WASHER M6 SPRING LOCK	3
16	D81500360.9	BOLT M6X1.00X16-9.8 HEX HEAD	3
17	D82500050.9	SCREW M6X1.00X12-6.8 HEX HEAD	1
18	D10287040.9	PLATE FRONT AXLE SUPPORT	1
19	D10013010.9	WASHER FRONT AXLE CENTRE REAR	1
20	D10013000.9	WASHER FRONT AXLE THRUST REAR	1
21	D10012650.9	BUSH FRONT AXLE SUPPORT	1
22	D10012890.9	SEAL O RING 0.780"X1.72"	1
23	D81000910.9	BOLT 3/4"-10X3.50" HEX HEAD	4
24	D86000150.9	WASHER 3/4" SPRING LOCK	4

TABLE-19
Axle Front With Slider And Spindle Assembly (Power Steering)




TABLE-19**Axle Front With Slider And Spindle Assembly (Power Steering)**

Fig. No.	Part No.	Description	Qty
1	D10334610.9	AXLE ASSEMBLY CENTRE	1
2	D10425710.9	CYLINDER ASSEMBLY POWER STEERING	1
3	D10634760.9	SLIDER AND SPINDLE ASSEMBLY LH	1
4	D10634770.9	SLIDER AND SPINDLE ASSEMBLY RH	1
5	D10406290.9	LINK ASSEMBLY STEERING DRAG	2
6	D10484710.9	LINK ASSEMBLY STEERING DRAG LH	1
7	D86500070.9	WASHER M14 SPRING LOCK	4
7-1	D81500740.9	BOLT M14X2.00X35-10.9 HEX HEAD LOCK	4
8	D81000940.9	BOLT 5/8"-11X4.50" HEX HEAD	4
9	D10103070.9	SPACER FRONT AXLE	4
10	D83000090.9	NUT 5/8"-11 HEX	4
11	D10292120.9	LOCK WASHER	2
12	D10331010.9	AXLE FRONT CENTRE POWER STEERING	1
13	D10012600.9	SLEEVE FRONT AXLE TRUNION CENTRE	1
14	D10012790.9	SLEEVE FRONT AXLE CENTRE	1

TABLE-20
Slider And Spindle Assembly Lh




TABLE-20**Slider And Spindle Assembly Lh**

Fig. No.	Part No.	Description	Qty
1	D10376210.9	ARM STEERING SPINDLE FRONT AXLE WITH LOCK (SQUARE TYPE)	1
2	D10376240.9	AXLE FRONT LH	1
3	D10292090.9	SPINDLE ASSEMBLY FRONT AXLE LH (SQUARE TYPE)	1
4	D92500020.9	GREASE NIPPLE A M10X1	1
5	D83000370.9	NUT 7/16"-14-10.9 HEX	1
6	D81001700.9	BOLT 7/16"-14X2.25"- 10.9 HEX HEAD	1
7	D83500290.9	NUT M12X1.75 HEX	1
8	D10293090.9	SCREW GRUB M12X40	1
9	D10042900.9	SEAL O RING 3.00X39.00	1
10	D10012840.9	SEAL FRONT AXLE SPINDLE	1
11	D10042910.9	SEAL ASSEMBLY LOWER FRONT AXLE SPINDLE	1
12	D10042930.9	SPACER FRONT WHEEL SPINDLE THRUST	1
13	D10039800.9	BEARING ASSEMBLY FRONT AXLE SPINDLE THRUST	1
14	D10012810.9	SEAL FRONT AXLE SPINDLE UPPER	1
15	D10042940.9	COVER SEAL DUST UPPER	1
16	D10192400.9	COVER FRONT AXLE SPINDLE SEAL DUST UPPER (SQUARE TYPE)	1
17	D10617260.9	HUB FRONT WHEEL	1
18	D10013290.9	BEARING ASSEMBLY FRONT WHEEL INNER	1
19	D10459440.9	SEAL FRONT AXLE HUB	1
20	D10012100.9	BEARING ASSEMBLY FRONT WHEEL OUTER	1
21	D10012970.9	WASHER FRONT HUB BEARING RETAINER	1
22	D10012980.9	NUT 1"-12 SLOTTED HEX	1
23	D88400090.9	PIN 4.0X40.0 COTTER	1
24	D10213580.9	GASKET FRONT WHEEL HUB COVER	1
25	D10213570.9	CAP HUB GREASE	1
26	D86500040.9	WASHER M6 SPRING LOCK	4
27	D81500490.9	BOLT M6X1.00X20-9.8 HEX HEAD	4
28	D81502050.9	BOLT M12X1.75X70-10.9 HEX HEAD	1
29	D83500760.9	NUT M12X1.75-6 HEX (GRADE 10.9)	1

TABLE-21
Slider And Spindle Assembly Rh




TABLE-21**Slider And Spindle Assembly Rh**

Fig. No.	Part No.	Description	Qty
1	D10376220.9	ARM STEERING SPINDLE FRONT AXLE (SQUARE TYPE)	1
2	D10376230.9	AXLE FRONT RH	1
3	D10292100.9	SPINDLE ASSEMBLY FRONT AXLE RH (SQUARE TYPE)	1
4	D92500020.9	GREASE NIPPLE A M10X1	1
5	D10293090.9	SCREW GRUB M12X40	1
6	D10042900.9	SEAL O RING 3.00X39.00	1
7	D81001700.9	BOLT 7/16"-14X2.25"- 10.9 HEX HEAD	1
8	D83000370.9	NUT 7/16"-14-10.9 HEX	1
9	D10012810.9	SEAL FRONT AXLE SPINDLE UPPER	1
10	D10012840.9	SEAL FRONT AXLE SPINDLE	1
11	D10192400.9	COVER FRONT AXLE SPINDLE SEAL DUST UPPER (SQUARE TYPE)	1
12	D10042910.9	SEAL ASSEMBLY LOWER FRONT AXLE SPINDLE	1
13	D10042940.9	COVER SEAL DUST UPPER	1
14	D10042930.9	SPACER FRONT WHEEL SPINDLE THRUST	1
15	D10039800.9	BEARING ASSEMBLY FRONT AXLE SPINDLE THRUST	1
16	D83500290.9	NUT M12X1.75 HEX	1
17	D10617260.9	HUB FRONT WHEEL	1
18	D10013290.9	BEARING ASSEMBLY FRONT WHEEL INNER	1
19	D10459440.9	SEAL FRONT AXLE HUB	1
20	D10012100.9	BEARING ASSEMBLY FRONT WHEEL OUTER	1
21	D10012970.9	WASHER FRONT HUB BEARING RETAINER	1
22	D10012980.9	NUT 1"-12 SLOTTED HEX	1
23	D88400090.9	PIN 4.0X40.0 COTTER	1
24	D10213580.9	GASKET FRONT WHEEL HUB COVER	1
25	D10213570.9	CAP HUB GREASE	1
26	D86500040.9	WASHER M6 SPRING LOCK	1
27	D81500490.9	BOLT M6X1.00X20-9.8 HEX HEAD	1
28	D81502050.9	BOLT M12X1.75X70-10.9 HEX HEAD	1
29	D83500760.9	NUT M12X1.75-6 HEX (GRADE 10.9)	1
30	D81000410.9	BOLT 3/4"-10X4.00" HEX HEAD	4
31	D83000070.9	NUT 3/4"-10 HEX	4

TABLE-22
Motor And Column Assembly Power Steering




TABLE-22**Motor And Column Assembly Power Steering**

Fig. No.	Part No.	Description	Qty
1	D10335990.9	MOTOR ASSEMBLY POWER STEERING	1
2	D10304720.9	COLUMN ASSEMBLY POWER STEERING	1
3	D10315560.9	BRACKET ASSEMBLY POWER STEERING MOUNTING	1
4	D86500090.9	WASHER M10 SPRING LOCK	4
5	D81500060.9	BOLT M10X1.50X30-8.8 HEX HEAD	3
6	D81500200.9	BOLT M10X1.50X20-6.6 HEX HEAD	1
7	D10321620.9	BRACKET STEERING COVER MOUNTING	1
8	D82500070.9	SCREW M8X1.25X15-6.8 HEX HEAD	2
9	D86500030.9	WASHER M8 SPRING LOCK	2
10	D10280990.9	BRACKET STEERING GEAR COVER REAR	1
11	D81500590.9	BOLT M8X1.25X25-6.6 HEX HEAD	2
12	D85500130.9	WASHER M8 FLAT	2
13	D83500110.9	NUT M8X1.25-8 HEX	2
14	D10021080.9	ADAPTOR 3/4" POWER STEERING	4
15	D10016480.9	SPRING GOVERNOR MANUAL CONTROL LEVER	1
16	D10016540.9	GROMMET STEERING COLUMN SHROUD	1
17	D10313020.9	CAP STEERING WHEEL	1
18	D10455770.9	WHEEL ASSEMBLY POWER STEERING	1
19	D10016830.9	SCREW #10-16X1.25" CROSS RECESSED PAN HEAD TAPPING	1

TABLE-23
Tube Steering




TABLE-23**Tube Steering**

Fig. No.	Part No.	Description	Qty
1	D10013970.9	CLAMP HOSE 35A	4
2	D10530500.9	TUBE ASSEMBLY STEERING SUCTION RESERVOIR HOSE TO TANDEM PUMP	1
3	D10519950.9	HOSE STEERING SUCTION TUBE	2
4	D10528420.9	TUBE STEERING SUCTION RESERVOIR TO HOSE TANDEM PUMP	1
5	D86500030.9	WASHER M8 SPRING LOCK	6
6	D81500340.9	BOLT M6X1.00X35-8.0 HEX HEAD	2
7	D93600670.9	SEAL O RING 1.78X15.6	1
8	D10375240.9	ADAPTOR 13/16"-16 UN AND 3/4"-16 UNF	4
9	D10477470.9	BRACKET ASSEMBLY POWER STEERING TUBE HOLDING UPPER	2
10	D10511550.9	BRACKET POWER STEERING TUBE HOLDING FRONT	2
11	D10508210.9	TUBE ASSEMBLY POWER STEERING PUMP TO MOTOR	1
12	D10508190.9	TUBE ASSEMBLY POWER STEERING LEFT TURN	1
13	D10508200.9	TUBE ASSEMBLY POWER STEERING MOTOR TO RH TURN	1
14	D10505670.9	TUBE ASSEMBLY POWER STEERING RH TURN HOSE	1
15	D81500030.9	BOLT M8X1.25X35-6.6 HEX HEAD	2
16	D10490500.9	RESERVOIR ASSEMBLY POWER STEERING OIL	1
17	D10509970.9	HOSE ASSEMBLY STEERING MOTOR TO STEERING OIL RESERVOIR	1
18	D10530420.9	BRACKET ASSEMBLY STEERING RESERVOIR MOUNTING	1
19	D93600580.9	SEAL O RING 1.78X23.52	1
20	D91500040.9	ELBOW 13/16-16 UNF AND 1/2-14 BSP	1
21	D81500280.9	BOLT M10X1.50X25-9.8 HEX HEAD	2
22	D85500140.9	WASHER M10 FLAT	2
23	D81500490.9	BOLT M6X1.00X20-9.8 HEX HEAD	1
24	D10504280.9	CLAMP TUBE HOLDING DIA 25	1
25	D10504240.9	BRACKET ASSEMBLY POWER STEERING TUBE HOLDING	1
26	D86500040.9	WASHER M6 SPRING LOCK	2
27	D10068840.9	BOLT M8X1.25X30-8.8 HEX HEAD	4
28	D10498990.9	CLAMP ASSEMBLY POWER STEERING TUBE HOLDING	2
29	D10513620.9	BRACKET ASSEMBLY POWER STEERING TUBE HOLDING RH	1
30	D10509960.9	HOSE ASSEMBLY STEERING CYLINDER RH	2

TABLE-24
Clutch Assembly




TABLE-24**Clutch Assembly**

Fig. No.	Part No.	Description	Qty
1	D10435910.9	CLUTCH ASSEMBLY DUAL 11"X11" (ORGANIC DISC)	1
2	D10435900.9	PLATE AND COVER ASSEMBLY DUAL CLUTCH 11" (ORGANIC DISC)	1
3	D10117940.9	DISC ASSEMBLY TRANSMISSION CLUTCH 11" ORGANIC LINING (LUK MAKE)	1
4	D81502160.9	BOLT M8X1.25X60-10.9 HEX HEAD	6
5	D86500030.9	WASHER M8 SPRING LOCK	6

TABLE-25
Clutch Controls




TABLE-25**Clutch Controls**

Fig. No.	Part No.	Description	Qty
1	D10000160.9	PLUG CLUTCH RELEASE SHAFT	1
2	D10188380.9	BUSH CLUTCH RELEASE SHAFT WITH OUT GRAPHITE INDENTATION	2
3	D10001520.9	NUT 3/8"-16 HEX PREVAILING TORQUE	1
4	D10001500.9	FORK CLUTCH RELEASE SHAFT	1
4A	D10019590.9	HUB CLUTCH RELEASE BEARING	1
4B	D10228590.9	BEARING ASSEMBLY CLUTCH RELEASE	1
5	D10001510.9	BOLT CLUTCH RELEASE FORK TO SHAFT	1
6	D10001490.9	WASHER CLUTCH RELEASE SHAFT	1
7	D10001480.9	SEAL O RING 1.40"X0.92"	1
8	D10177870.9	SHAFT ASSEMBLY CLUTCH RELEASE	1
9	D93400030.9	PIN 3/8"X1.14" CLEVIS	2
10	D10013460.9	PIN 1/8"X0.75" COTTER	2
11	D83000010.9	NUT 3/8"-24 HEX	2
12	D10019700.9	ROD AND CLEVIS ASSEMBLY CLUTCH CONTROL	1
13	D10623610.9	PEDAL ASSEMBLY CLUTCH	1
14	D81000090.9	BOLT 7/16"-14X1.25" HEX HEAD	2
15	D10002330.9	BRACKET CLUTCH PEDAL SPRING PIVOT REAR AXLE LIVE PTO	1
16	D86000020.9	WASHER 7/16" SPRING LOCK	2
17	D10012380.9	SPRING ASSEMBLY CLUTCH PEDAL LEVER ASSIST	1
18	D10087240.9	BUSH CLUTCH PEDAL	2
19	D92500020.9	GREASE NIPPLE A M10X1	2

TABLE-26
Transmission Case And Shift Levers




TABLE-26**Transmission Case And Shift Levers**

Fig. No.	Part No.	Description	Qty
1	D10223080.9	LEVER TRANSMISSION HIGH LOW GEAR SHIFT	1
2	D93600540.9	SEAL O RING 2.0X15	2
3	D10199450.9	PIN TRANSMISSION GEAR SHAFT LEVER SOCKET	2
4	D10072420.9	BOOT HIGH LOW LEVER	2
5	D10199430.9	STOP GEAR SHIFTING HI LOW LEVER	1
6	D10298520.9	STOP GEAR SHIFTING MAIN LEVER WITH WIRE CLAMP	1
7	D10107590.9	BOLT 5/6"-18X0.56" HEX HEAD	4
8	D10199460.9	RETAINER GEAR SHIFTING LEVER	2
9	D10062360.9	SPRING TRANSMISSION GEAR SHIFTING LEVER	2
10	D10062370.9	RING TRANSMISSION GEAR SHIFTING LEVER SNAP	2
11	D10223070.9	LEVER TRANSMISSION MAIN GEAR SHIFT	1
12	D10639430.9	COVER TRANSMISSION CASE UPPER (CENTRE SHIFTING GEAR)	1
13	D10107600.9	PIN DOWEL	1
14	D10107610.9	PIN	1
15	D10107630.9	WIRE LOCKING GEAR SHIFTING PLATE TO COVER	2
16	D10501630.9	INDICATOR ASSEMBLY WITH BREATHER TRANSMISSION OIL	1
17	D95002100.9	LOCTITE 638	1
18	D10500680.9	TUBE BREATHER MOUNTING TOP COVER	1
19	D10001890.9	CLIP SAFETY START SWITCH HARNESS	1
20	D10000520.9	SWITCH ASSEMBLY TRANSMISSION CONTROL SELECTOR NEUTRAL	1
21	D10000510.9	PLUNGER SAFETY START SWITCH	1
22	D10000490.9	BALL 3/8" DIAMETER	1
23	D10000500.9	SPRING SAFETY START SWITCH	1
24	D10107610.9	PIN	1
25	D10179670.9	RETAINER SAFETY START SWITCH	1
29	D10000570.9	FORK TRANSMISSION GEAR SHIFT 1ST AND 3RD SPEED	1
30	D81000770.9	BOLT 5/8"-11X1.75" HEX HEAD	2
31	D81000580.9	BOLT 3/4"-16X2.75" HEX HEAD	2
32	D10000070.9	CASE TRANSMISSION (MACHINED)	1
33	D10000530.9	CONNECTOR GEAR SHIFTING HIGH LOW	1
34	D10000550.9	SCREW TRANSMISSION CONNECTOR LOCK	6
35	D83000010.9	NUT 3/8"-24 HEX	6
36	D10000540.9	FORK TRANSMISSION GEAR SHIFT HIGH LOW	1
37	D10000580.9	CONNECTOR GEAR SHIFTING 1ST AND 3RD SPEED	1
38	D10253530.9	FORK TRANSMISSION GEAR SHIFT 2ND AND REVERSE SPEED	1
39	D93400010.9	PIN 3/16"X1.219" CLEVIS	1
40	D10000650.9	PLUNGER TRANSMISSION GEAR SHIFT ARM	1
41	D10000660.9	SPRING SELECTOR STOP PLUNGER	1
42	D10000670.9	RETAINER SELECTOR SPRING PLUNGER	1
43	D10000630.9	ARM TRANSMISSION 4TH SPEED	1

TABLE-26
Transmission Case And Shift Levers




TABLE-26**Transmission Case And Shift Levers**

Fig. No.	Part No.	Description	Qty
44	D10000640.9	PIN 1/16"X0.50" COTTER	1
45	D10000680.9	FORK TRANSMISSION GEAR SHIFT 4TH SPEED	1
46	D10000710.9	PIN TRANSMISSION GEAR SHIFT	1
47	D10000690.9	SPRING TRANSMISSION GEAR SHIFT	4
48	D10000490.9	BALL 3/8" DIAMETER	1
49	D10458410.9	GASKET COVER TOP HOUSING TRANSMISSION	1
50	D93100010.9	PLUG 1/4"-18 PIPE	1
51	D10000310.9	INTERLOCK TRANSMISSION GEAR SHIFTING	2
52	D10000090.9	DOWEL 1/2"X0.8125" PLAIN	2
53	D10000610.9	RAIL TRANSMISSION GEAR SHIFT 4TH SPEED	1
54	D10253520.9	RAIL TRANSMISSION GEAR SHIFT 2ND AND REVERSE SPEED	1
55	D10000560.9	RAIL TRANSMISSION GEAR SHIFT 1ST AND 3RD SPEED	1
56	D10000460.9	RAIL TRANSMISSION GEAR SHIFT HIGH LOW SPEED	1
57	D10213110.9	PLUG DRAIN 3/4-14 NPTF (MAGNETIC)	1
58	D83000090.9	NUT 5/8"-11 HEX	2
59	D10188380.9	BUSH CLUTCH RELEASE SHAFT WITH OUT GRAPHITE INDENTATION	2
60	D81000890.9	BOLT 5/8"-11X3.25 HEX HEAD	2
61	D86000020.9	WASHER 7/16" SPRING LOCK	12
62	D81000090.9	BOLT 7/16"-14X1.25" HEX HEAD	6
63	D10107630.9	WIRE LOCKING GEAR SHIFTING PLATE TO COVER	2
64	D10517790.9	KNOB TRANSMISSION MAIN GEAR SHIFT LEVER	1
65	D10622490.9	KNOB TRANSMISSION GEAR SHIFTER HIGH LOW	1
65-1	D10688280.9	KNOB TRANSMISSION GEAR SHIFTER HIGH LOW	1
66	D10228930.9	COVER CLUTCH INSPECTION CASE TRANSMISSION	1
67	D95010830.9	LOCTITE 5060	1
68	D81000140.9	BOLT 5/16"-18X0.88" HEX HEAD	6
69	D10256250.9	BRACKET ASSEMBLY STOPPER DUAL CLUTCH LEVER	1

TABLE-27
Transmission Gears




TABLE-27**Transmission Gears**

Fig. No.	Part No.	Description	Qty
1	D10019710.9	BEARING ASSEMBLY LIVE PTO	1
2	D10019610.9	RING PTO INPUT SHAFT SNAP	1
3	D10019660.9	SEAL OIL TRANSMISSION INPUT SHAFT	1
4	D87000010.9	PIN 3/8"X0.687" DOWEL	2
5	D95010840.9	LOCTITE ANAEROBIC L-5182	1
6	D10249930.9	PLATE CLUTCH RELEASE (REVERSE PTO)	1
6A	D10249960.9	COVER CLUTCH RELEASE PLATE	1
6B	D95010840.9	LOCTITE ANAEROBIC L-5182	1
7	D81000020.9	BOLT 3/8"-16X1.125" HEX HEAD	7
8	D95010840.9	LOCTITE ANAEROBIC L-5182	1
9	D10019860.9	RETAINER TRANSMISSION INPUT SHAFT LIVE PTO (MACHINED)	1
10	D81000030.9	BOLT 3/8"-16X0.875" HEX HEAD LOCK (GRADE-5)	5
11	D10019730.9	BEARING ASSEMBLY LIVE PTO	1
12	D10031320.9	SEAL OIL TRANSMISSION MAIN DRIVE SHAFT	1
13	D10341070.9	SHAFT PTO INPUT TRANSMISSION Z-17	1
14	D10000120.9	RING TRANSMISSION MAIN DRIVE SHAFT BEARING SNAP	1
15	D10019640.9	RING MAIN SHAFT DRIVE GEAR	1
16	D10019630.9	PLATE TRANSMISSION MAIN DRIVE	1
17	D10000900.9	BEARING BALL TRANSMISSION INPUT SHAFT	1
18	D10566320.9	SHAFT TRANSMISSION INPUT Z-18	1
19	D10000450.9	RING TRANSMISSION MAIN COUNTERSHAFT SNAP	1
20	D10000440.9	WASHER MAIN DRIVE SHAFT GEAR THRUST	1
21	D10254120.9	GEAR TRANSMISSION 3RD SPEED Z-35	1
22	D10000390.9	COUPLING TRANSMISSION GEAR SHIFT (MACHINED)	3
23	D10087550.9	CONNECTOR TRANSMISSION 1ST AND 3RD SPEED	2
24	D10240700.9	GEAR TRANSMISSION 1ST AND 5TH SPEED	1
25	D10000400.9	WASHER MAIN DRIVE SHAFT GEAR THRUST	2
26	D10240710.9	GEAR TRANSMISSION REVERSE SPEED	1
27	D10316140.9	GEAR TRANSMISSION 2ND AND 6TH SPEED Z-39	1
28	D10001980.9	BEARING ASSEMBLY TRANSMISSION MAIN SHAFT	1
29	D10019720.9	BEARING PTO COUNTERSHAFT	1
29A	D10184680.9	LOCKING PLATE PTO COUNTER SHAFT	1
30	D10019650.9	RING PTO COUNTER SHAFT GEAR SNAP	1
31	D10019600.9	WASHER PTO COUNTERSHAFT THRUST	1
32	D10019880.9	GEAR PTO COUNTERSHAFT Z-57 (MACHINED)	1
33	D10000120.9	RING TRANSMISSION MAIN DRIVE SHAFT BEARING SNAP	1
34	D10019710.9	BEARING ASSEMBLY LIVE PTO	1
35	D10401160.9	GEAR TRANSMISSION COUNTERSHAFT (Z-57/30)	1
36	D10220880.9	SHAFT COUNTER TRANSMISSION LIVE PTO (MACHINED)	1
37	D10000230.9	BEARING BALL COUNTERSHAFT REAR	1

TABLE-27
Transmission Gears




TABLE-27**Transmission Gears**

Fig. No.	Part No.	Description	Qty
38	D10000940.9	WASHER NEEDLE BEARING INPUT SHAFT THRUST	2
39	D10291160.9	BEARING NEEDLE TRANSMISSION INPUT SHAFT (24X35X20)	1
40	D10478470.9	SHAFT TRANSMISSION MAIN DRIVE Z-30	1
41	D10001990.9	BEARING ASSEMBLY TRANSMISSION MAIN SHAFT REAR PILOT	1
42	D10000830.9	BUSH TRANSMISSION GEAR OUTPUT	1
43	D10000790.9	SHAFT TRANSMISSION OUTPUT (MACHINED)	1
44	D10000390.9	COUPLING TRANSMISSION GEAR SHIFT (MACHINED)	1
45	D10338010.9	GEAR ASSEMBLY TRANSMISSION OUTPUT (Z-49)	1
46	D10000840.9	WASHER TRANSMISSION OUTPUT SHAFT	1
47	D10002000.9	BEARING ASSEMBLY TRANSMISSION OUTPUT SHAFT	1
48	D10369140.9	CIRCLIP HOUSING TRANSMISSION INNER	1
49	D10320410.9	COUPLING TRANSMISSION COUNTERSHAFT SLIDING GEAR Z-19	1
50	D10000140.9	RING TRANSMISSION COUNTER SHAFT FRONT BEARING SNAP	1
51	D10000730.9	BEARING BALL TRANSMISSION COUNTERSHAFT HIGH LOW REAR	1
52	D10000750.9	GEAR TRANSMISSION COUNTERSHAFT HIGH LOW Z-16/35 (MACHINED)	1
53	D10080370.9	SEAL OIL 32.5X39.5X5	2
54	D10019740.9	PTO COUNTERSHAFT LIVE PTO (MACHINED)	1
55	D90500120.9	CIRCLIP B62X2.0 N	1
56	D10000090.9	DOWEL 1/2"X0.8125" PLAIN	2
57	D95010840.9	LOCTITE ANAEROBIC L-5182	1
58	D10490530.9	RETAINER TRANSMISSION OUTPUT SHAFT BEARING (EPI)	1
59	D10001120.9	SEAL TRANSMISSION OUTPUT SHAFT	1
60	D81000020.9	BOLT 3/8"-16X1.125" HEX HEAD	10
61	D10001130.9	SHIM TRANSMISSION OUTPUT SHAFT 0.003" THICK	AR
61S1	D10001140.9	SHIM TRANSMISSION OUTPUT SHAFT 0.005" THICK	AR
61S2	D10001150.9	SHIM TRANSMISSION OUTPUT SHAFT 0.012" THICK	AR
62	D10001100.9	RETAINER TRANSMISSION OUTPUT	1
63	D81000030.9	BOLT 3/8"-16X0.875" HEX HEAD LOCK (GRADE-5)	4
64	D10000280.9	BUSH TRANSMISSION REVERSE IDLER GEAR	1
65	D10220950.9	GEAR TRANSMISSION REVERSE IDLER	1
66	D10000260.9	SHAFT TRANSMISSION REVERSE IDLER	1
67	D10000290.9	SEAL IDLER SHAFT RETAINER BOLT LOCK	1
68	D10000300.9	BOLT TRANSMISSION REVERSE IDLER	1
69	D10001060.9	RING PTO COUNTERSHAFT SMALL BEARING SNAP	1
70	D10012290.9	BUSHING FRONT WHEEL SPINDLE PIN UPPER	1
71	D10080360.9	SEAL OIL 50.6X73X15.87	2
72	D10001040.9	BEARING BALL PTO COUNTERSHAFT	1
73	D10000990.9	SEAL OIL PTO COUNTERSHAFT	1
74	D10000740.9	BEARING BALL TRANSMISSION COUNTERSHAFT HIGH LOW FRONT	1

TABLE-28
Center Housing




TABLE-28
Center Housing

Fig. No.	Part No.	Description	Qty
1	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	1
2	D10002070.9	GASKET HAND BRAKE OPENING COVER	1
3	D10002060.9	COVER HAND BRAKE OPENING	1
3A	D85000090.9	WASHER 7/16" FLAT	4
4	D81000070.9	BOLT 7/16"-14X0.875" HEX HEAD	4
5	D10004030.9	BREATHER ASSEMBLY TRANSMISSION OIL FILLER	1
7	D10254090.9	HOUSING ASSEMBLY REAR AXLE CENTRE	1
7-Jan	D10475770.9	HOUSING ASSEMBLY REAR AXLE CENTRE	1
7-Feb	D10656430.9	HOUSING ASSEMBLY REAR AXLE CENTRE (FLAT BACKEND)	1
8	D83000110.9	NUT 9/16"-12 HEX	4
8-Jan	D83000420.9	NUT 9/16"-12 HEX (GRADE 8)	4
9	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	1
10	D81000370.9	BOLT 1/2"-13X2.25" HEX HEAD	2
11	D83000050.9	NUT 1/2"-13 HEX	6
11-Jan	D83000430.9	NUT 1/2"-13 HEX (GRADE 8)	6
12	D81000530.9	BOLT 9/16"-12X2.50" HEX HEAD	2
13	D81000520.9	BOLT 9/16"-12X 2.00" HEX HEAD	2
14	D81000360.9	BOLT 1/2"-13X2.00"HEX HEAD	3
15	D81000350.9	BOLT 1/2"-13X1.75" HEX HEAD	1
16	D93100010.9	PLUG 1/4"-18 PIPE	1
17	D10002040.9	BUSH BRAKE PEDAL SHAFT	2
18	D10213110.9	PLUG DRAIN 3/4-14 NPTF (MAGNETIC)	1
19	D10558270.9	BRACKET ASSEMBLY TRAILER SOCKET	1

TABLE-29
Differential And Gear Set




TABLE-29**Differential And Gear Set**

Fig. No.	Part No.	Description	Qty
1	D10087270.9	BEARING ASSEMBLY TAPER ROLLER (REAR AXLE)	1
2	D10003020.9	NUT 1/2"-20 NYLOCK HEX	12
4	D10003010.9	SCREW 1/2"-20X1.62" FLIP HEAD	12
5	D10003000.9	BUSH DIFFERENTIAL CASE REAR AXLE	2
6	D10003050.9	WASHER REAR AXLE DIFFERENTIAL SUN GEAR THRUST	2
7	D10003030.9	GEAR REAR AXLE DIFFERENTIAL SIDE LH (Z-16)	2
8	D10217030.9	GEAR SET BEVEL PINION AND CROWN WHEEL REAR AXLE	1
9	D10002620.9	CONE AND ROLLER ASSEMBLY REAR AXLE	2
10	D81001570.9	BOLT 9/16"-12X1.5" HEX HEAD (PRECOATED)	4
11	D86000160.9	WASHER 9/16" SPRING LOCK	4
12	D10002590.9	RETAINER ASSEMBLY BEVEL PINION SHAFT REAR AXLE	1
13	D10002650.9	BEARING REAR AXLE BEVEL PINION SHAFT PILOT	1
14	D10002660.9	RING REAR AXLE BEVEL PINION SHAFT SNAP	1
15	D10003080.9	SPIDER SHAFT REAR AXLE DIFFERENTIAL	1
16	D10003090.9	PINION REAR AXLE DIFFERENTIAL (Z-9)	4
17	D10289990.9	WASHER SATELLITE DIFFERENTIAL FRICTION	4
18	D10013400.9	COUPLING DRIVE SHAFT REAR AXLE	1
19	D10002700.9	BOLT REAR AXLE CLAMP NUT	1
20	D10002690.9	CLAMP REAR AXLE DRIVE PINION	1
21	D10002710.9	NUT LOCK REAR AXLE	1
22	D10002680.9	WASHER REAR AXLE DRIVE PINION BEARING THRUST	1
23	D10002670.9	WASHER REAR AXLE DRIVE PINION BEARING THRUST	1
24	D10003040.9	GEAR REAR AXLE DIFFERENTIAL SIDE RH (Z-16)	1
26	D81000240.9	BOLT 1/2"-13X2.88" HEX HEAD LOCK	8
27	D10003070.9	CONE AND ROLLER ASSEMBLY REAR AXLE DIFFERENTIAL RH	1
28	D10003110.9	ADAPTOR REAR AXLE DIFFERENTIAL LOCK	1
29	D10003120.9	SPRING ADAPTOR REAR AXLE DIFFERENTIAL LOCK	1
30	D10003130.9	COUPLING REAR AXLE DIFFERENTIAL LOCK	1
31	D10003140.9	WASHER COUPLING DIFFERENTIAL LOCK REAR AXLE	1
32	D10003150.9	RING BULL PINION BEARING SNAP	1
33	D10002960.9	CASE ASSEMBLY REAR AXLE DIFFERENTIAL	1

TABLE-30
Differential Lock




TABLE-30**Differential Lock**

Fig. No.	Part No.	Description	Qty
1	D10529910.9	PEDAL ASSEMBLY REAR AXLE DIFFERENTIAL LOCK	1
2	D10333550.9	PLATE DIFFERENTIAL LOCK PEDAL	1
3	D10333570.9	BUSH DIFFERENTIAL LOCK PEDAL	1
4	D10396670.9	SHANK DIFFERENTIAL LOCK PEDAL	1
5	D10333580.9	HUB DIFFERENTIAL LOCK PEDAL	1
6	D10068070.9	BUSH	1

TABLE-31

Rear Axle




TABLE-31**Rear Axle**

Fig. No.	Part No.	Description	Qty
1	D10003640.9	BLOCK REAR AXLE DRIVE GEAR THRUST	1
1A	D10003650.9	SHIM REAR AXLE THRUST BLOCK DRIVE GEAR (0.10MM)	1
2	D86000010.9	WASHER 3/8" SPRING LOCK	2
3	D81000060.9	BOLT 3/8"-16X1.00" HEX HEAD	2
4	D10002850.9	GASKET REAR AXLE HOUSING	AR
4A	D10002850.9	GASKET REAR AXLE HOUSING	AR
5	D10210670.9	HOUSING ASSEMBLY REAR AXLE RH	1
5A	D10249320.9	HOUSING ASSEMBLY REAR AXLE LH	1
6	D10002900.9	BOLT REAR AXLE HOUSING TO CENTRE HOUSING	26
7	D10003740.9	SHIM REAR AXLE SHAFT BEARING EXTENSION (0.016")	5
8	D10003460.9	SEAL OIL REAR AXLE SHAFT	2
9	D10003440.9	RETAINER REAR AXLE SEAL	2
10	D10251330.9	BOLT REAR WHEEL M16X1.5X61-10.9	16
11	D10296950.9	SHAFT REAR AXLE (MACHINED)	2
12	D10296950.9	SHAFT REAR AXLE (MACHINED)	2
13	D10002780.9	SHAFT AND LEVER ASSEMBLY REAR AXLE DIFFERENTIAL LOCK	1
14	D10002760.9	SEAL DIFFERENTIAL LOCK LEVER SHAFT RH REAR AXLE	1
14A	D83000020.9	NUT 3/8"-16 HEX	1
15	D10002840.9	SCREW REAR AXLE DIFFERENTIAL LOCK FORK STOP	1
16	D10002810.9	FORK REAR AXLE DIFFERENTIAL LOCK	1
17	D83000010.9	NUT 3/8"-24 HEX	1
18	D10000550.9	SCREW TRANSMISSION CONNECTOR LOCK	1
19	D10518770.9	LEVER AND HUB ASSEMBLY PARKING BRAKE	1
20	D10518810.9	LEVER AND HUB ASSEMBLY PARKING BRAKE LH	1
21	D10518840.9	HUB PARKING BRAKE ASSEMBLY	1

TABLE-32
Power Take-Off Assembly




TABLE-32**Power Take-Off Assembly**

Fig. No.	Part No.	Description	Qty
1	D10216850.9	SHAFT ASSEMBLY PTO REAR	1
2	D90000110.9	CIRCLIP A35X2.0 N	1
3	D90000240.9	CIRCLIP B72X2.5 N	1
4	D10216000.9	WASHER PTO SHAFT THRUST	1
5	D10216010.9	WASHER COVER PTO THRUST	1
6	D10002140.9	BEARING BALL PTO SHAFT REAR AXLE	3
7	D10002210.9	GASKET PTO COVER REAR AXLE	2
8	D10490400.9	COVER PTO REAR	1
9	D81000090.9	BOLT 7/16"-14X1.25" HEX HEAD	4
10	D10238270.9	SLEEVE PTO SHAFT REAR AXLE	1
11	D10002130.9	SEAL OIL PTO SHAFT REAR AXLE	3
12	D10042010.9	CAP PTO	1
13	D10000490.9	BALL 3/8" DIAMETER	1
14	D10195960.9	SPRING TRANSMISSION PTO SHIFTER PLATE	1
15	D10002280.9	ARM PTO SHIFTER REAR AXLE	1
16	D10002300.9	FORK PTO SHIFTER REAR AXLE	2
17	D10002230.9	SLEEVE SHAFT PTO REAR AXLE	1
18	D10656360.9	LEVER ASSEMBLY PTO SHIFTER REAR AXLE	1
19	D93600090.9	SEAL O RING 0.103"X0.625"	1
20	D10002250.9	PLATE PTO SHIFTER REAR AXLE	1
21	D10002310.9	GASKET PTO SHIFTER PLATE REAR AXLE	1
22	D87000140.9	PIN 1/4"X1.00" SPRING DOWEL COMBINATION TYPE	1
23	D81000100.9	BOLT 7/16"-14X1.00" HEX HEAD	3
24	D86000020.9	WASHER 7/16" SPRING LOCK	3
25	D10527070.9	KNOB PTO LEVER CONTROL YELLOW	1

TABLE-33
Independent Parking Brake Assembly




TABLE-33**Independent Parking Brake Assembly**

Fig. No.	Part No.	Description	Qty
1	D10518770.9	LEVER AND HUB ASSEMBLY PARKING BRAKE	2
2	D10518810.9	LEVER AND HUB ASSEMBLY PARKING BRAKE LH	1
3	D10518860.9	ROD AND CLEVIS ASSEMBLY FRONT PARKING BRAKE	1
4	D83000010.9	NUT 3/8"-24 HEX	1
5	D83500290.9	NUT M12X1.75 HEX	1
6	D10518880.9	HUB AND LEVER ASSEMBLY PARKING BRAKE LEFT	1
7	D10518910.9	HUB AND LEVER ASSEMBLY PARKING BRAKE RIGHT	1
8	D10518940.9	BRACKET ASSEMBLY LEVER PARKING BRAKE MOUNTING	1
9	D83500070.9	NUT M6X1.00-6 HEX	3
10	D10518990.9	BRACKET AND BUSH ASSEMBLY PARKING BRAKE	1
11	D10519020.9	SHAFT LOWER PARKING BRAKE	1
12	D10520280.9	PIN DIA10 (LENGTH 65)	2
13	D10518840.9	HUB PARKING BRAKE ASSEMBLY	1
14	D81001480.9	BOLT 5/8"-11X1.50"-8.0 HEX HEAD	2
15	D10013460.9	PIN 1/8"X0.75" COTTER	3
16	D85500140.9	WASHER M10 FLAT	6
17	D92500020.9	GREASE NIPPLE A M10X1	2
18	D10292730.9	PIN 3/8" CLEVIS	4
19	D86000120.9	WASHER 5/8" SPRING LOCK	2
20	D85500060.9	WASHER M12 FLAT	2
21	D87500320.9	PIN 6.35X40 SPRING DOWEL COMBINATION TYPE	2
21-1	D87000160.9	PIN 1/4"X1.50" SPRING DOWEL COMBINATION TYPE	2
22	D10258180.9	PIN 10X35 CLEVIS	1
23	D10011090.9	BOLT M6X1.00X20-6.6 HEX FLANGED (LUBE OIL PUMP)	3
24	D10255220.9	LEVER ASSEMBLY PARKING BRAKE	1
25	D10010020.9	SEAL O RING 3.00X28.00	4
26	D10322350.9	LINK ASSEMBLY PARKING BRAKE	2
27	D90000570.9	CIRCLIP A28X1.5 N	2
28	D10102360.9	CLEVIS 3/8"	1
29	D83000180.9	NUT 7/16"-20 HEX	3
30	D81001190.9	BOLT 7/16-20X2.50 HEX HEAD LOCK	3
31	D10518890.9	BOLT BRACKET PARKING BRAKE MOUNTING	1
32	D83000110.9	NUT 9/16"-12 HEX	1
33	D10002890.9	WASHER 9/16" FLAT	1
34	D91000070.9	KEY 1/4"X7/8" WOODRUFF	2

TABLE-34
WHEEL AND TYRE ASSEMBLY FRONT




TABLE-34**WHEEL AND TYRE ASSEMBLY FRONT**

Fig. No.	Part No.	Description	Qty
1	D10370700.9	RIM ASSEMBLY FRONT WHEEL W4.5X16 (ANTIQUE SILVER)	2
2	D10531900.9	TYRE ASSEMBLY FRONT WHEEL 5.5X16	2
2-1	D10017680.9	TYRE ASSEMBLY FRONT WHEEL 6.00X16-8 PLY	2
3	D10531910.9	TUBE ASSEMBLY FRONT TYRE 6.00X16	2
3-1	D10015220.9	TUBE ASSEMBLY FRONT TYRE 6.00X16	2
4	D10374910.9	BOLT FRONT WHEEL HUB	12

TABLE-35
Wheel And Tyre Assembly Rear




TABLE-35**Wheel And Tyre Assembly Rear**

Fig. No.	Part No.	Description	Qty
1	D10415580.9	RIM ASSEMBLY REAR WHEEL W11X28 (ANTIQUE SILVER)	2
2	D10517340.9	TYRE ASSEMBLY REAR WHEEL 12.4X28	2
2-1	D10030460.9	TYRE ASSEMBLY REAR WHEEL 13.6X28-12 PLY	2
3	D10517350.9	TUBE ASSEMBLY REAR TYRE 12.4X28	2
3-1	D10017370.9	TUBE ASSEMBLY REAR TYRE 13.6X28	2
4	D10241480.9	NUT REAR WHEEL	16

TABLE-36
Oil Immersed Brake




TABLE-36**Oil Immeresed Brake**

Fig. No.	Part No.	Description	Qty
1	D10094530.9	CAM SHAFT BRAKE ACTUATING LH (M/S BRAKES INDIA LTD 29320931)	1
1A	D10094540.9	CAM SHAFT BRAKE ACTUATING RH (M/S BRAKES INDIA LTD 29320932)	1
2	D10003220.9	RETAINER REAR AXLE BRAKE CAM SHAFT	2
2A	D10003230.9	BOOT REAR AXLE BRAKE CAM SHAFT	1
3	D86000040.9	WASHER 5/16" SPRING LOCK	4
4	D81000140.9	BOLT 5/16"-18X0.88" HEX HEAD	4
5	D10243340.9	CLAMP ASSEMBLY RUBBER BOOT BRAKE	2
6	D10651230.9	LEVER AND HUB ASSEMBLY PARKING BRAKE	1
7	D83000040.9	NUT 7/16"-14HEX	2
8	D91000010.9	KEY 1/4"X1.25" WOODRUFF	2
9	D10003690.9	ARM REAR AXLE BRAKE CAM SHAFT LH	1
10	D10002870.9	ARM BRAKE CAM SHAFT RH	1
11	D10002880.9	BUSHING BRAKE CROSS SHAFT	2
12	D81000130.9	BOLT 7/16"-14X2.50" HEX HEAD	2
13	D10228530.9	BRAKE ASSEMBLY REAR AXLE WITHOUT DISC FRICTION RH	1
14	D10228540.9	BRAKE ASSEMBLY REAR AXLE WITHOUT DISC FRICTION LH	1
14A	D10228520.9	DISC FRICTION WET BRAKE	10
15	D10093220.9	SLEEVE SPLINED BRAKE DISC TO REAR AXLE	2
16	D10003370.9	RING SLEEVE BRAKE DISC REAR AXLE RETAINING	2
17	D10003570.9	GASKET REAR AXLE BRAKE HOUSING	2
18	D10389090.9	HOUSING REAR AXLE BRAKE INNER RH (OIB)	1
19	D10389100.9	HOUSING REAR AXLE BRAKE INNER LH (OIB)	1
20	D10093270.9	SEAL O RING	2
21	D10003290.9	BOLT 9/16"-12X2.09" HEX HEAD BRAKE HOUSING INNER	20
22	D10003260.9	WASHER DRAIN PLUG	2
23	D85000010.9	WASHER 3/8" FLAT	2
24	D81000150.9	BOLT 3/8"-16X0.75" HEX HEAD	2
25	D10003250.9	RING REAR AXLE BRAKE CAMSHAFT SNAP	2
26	D10003240.9	WASHER REAR AXLE BRAKE CAM SHAFT THRUST	2
27	D83000430.9	NUT 1/2"-13 HEX (GRADE 8)	2
28	D10003270.9	SCREW REAR AXLE BRAKE ADJUSTING	2
29	D10068180.9	BUSH REAR AXLE OUTER HOUSING	2
29A	D10003460.9	SEAL OIL REAR AXLE SHAFT	2
30	D10020040.9	BOLT BRAKE HOUSING REAR AXLE	16
31	D10003580.9	WASHER 1/2" FLAT	16
32	D10490370.9	HOUSING REAR AXLE BRAKE OUTER	2
33	D10003500.9	BEARING ASSEMBLY REAR AXLE SHAFT OUTER	2
33A	D10106720.9	SPACER SHAFT REAR AXLE	2
33B	D10003540.9	RING REAR AXLE OIL SEAL RETAINING	2
34	D10003560.9	NUT REAR AXLE SHAFT LOCK	2

TABLE-36
Oil Immersed Brake




TABLE-36**Oil Immeresed Brake**

Fig. No.	Part No.	Description	Qty
34A	D10094480.9	SEAL OIL BRAKE HOUSING OUTER REAR AXLE	1
35	D92000010.9	GREASE NIPPLE 1/8"-27 ELBOW FITTING	2
36	D10003290.9	BOLT 9/16"-12X2.09" HEX HEAD BRAKE HOUSING INNER	2
37	D10017550.9	FITTING VENTURI TUBE	2
38	D10018160.9	CLAMP BREATHER TUBE	2
39	D81500300.9	BOLT M5X0.80X8-9.8 HEX HEAD	2
40	D85500090.9	WASHER M5 FLAT	2
41	D10626770.9	ACTUATING UNIT ASSEMBLY (M/S BIL PART NO 29325706)	2
41A	D10626780.9	DISC ACTUATING (M/S BIL PART NO 29324810)	4
41B	D10626800.9	BALL ACTUATING (M/S BIL PART NO 64150456)	12
41C	D10626820.9	SPRING REAR AXLE BRAKE ACTUATING DISC RETURN (M/S BIL PART NO 29324692)	8
41D	D10626840.9	CLIP ROD RETAINING (M/S BIL PART NO 29320063)	4
41E	D10069980.9	ROD PUSH	4
42	D10186000.9	DISC INTERMEDIATE (M/S BRAKES INDIA LTD 29320929)	6
43	D10094530.9	CAM SHAFT BRAKE ACTUATING LH (M/S BRAKES INDIA LTD 29320931)	1
44	D10094540.9	CAM SHAFT BRAKE ACTUATING RH (M/S BRAKES INDIA LTD 29320932)	1
45	D10186010.9	PIN GUIDE (M/S BRAKES INDIA LTD 29320930)	2

TABLE-37
Oil Immersed Brakes-Pipes




TABLE-37**Oil Immersed Brakes-Pipes**

Fig. No.	Part No.	Description	Qty
1	D10007690.9	SEAL O RING 2.30X15.60	1
2	D10299520.9	TUBE ASSEMBLY JUNCTION BOX TO ACCESSORY PLATE	1
3	D10299540.9	TUBE ASSEMBLY JUNCTION BOX TO LH OIL IMMERSED BRAKE	1
4	D10299550.9	TUBE ASSEMBLY JUNCTION BOX TO RH OIL IMMERSED BRAKE	1
5	D10151650.9	ADAPTOR M18X3/4"	1
6	D83500160.9	NUT M8X1.25 NYLOCK HEX	1
7	D10288760.9	JUNCTION BOX SPOOL VALVE	1

TABLE-38
BRAKE LINKAGE SUBASSEMBLY




TABLE-38
BRAKE LINKAGE SUBASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10012260.9	WASHER BRAKE PEDAL CROSS SHAFT THRUST	4
2	D10012560.9	SEAL ASSEMBLY BRAKE PEDAL SHAFT	2
3	D10012250.9	SPRING BRAKE PEDAL RETURN	2
4	D10013460.9	PIN 1/8"X0.75" COTTER	2
5	D81000470.9	BOLT 7/16"-14X1.50" HEX HEAD	2
6	D93400030.9	PIN 3/8"X1.14" CLEVIS	2
7	D10012030.9	SHAFT BRAKE PEDAL	1
8	D10279840.9	PEDAL ASSEMBLY REAR AXLE BRAKE RH	1
9	D10012480.9	WASHER BRAKE PEDAL CROSS SHAFT THRUST	1
10	D10295840.9	PEDAL ASSEMBLY REAR AXLE BRAKE LH	1
11	D10012530.9	LEVER BRAKE OPERATING LH	1
12	D10518860.9	ROD AND CLEVIS ASSEMBLY FRONT PARKING BRAKE	2

TABLE-39
Hydraulic Lift Cover




TABLE-39
Hydraulic Lift Cover

Fig. No.	Part No.	Description	Qty
1	D10412940.9	COVER HYDRAULIC LIFT WITH SLEEVE ASSEMBLY	1
2	D10408140.9	COVER HYDRAULIC LIFT ACCESSORY	1
3	D10186470.9	ADAPTER M22X1.5 COVER HYDRAULIC LIFT ACCESSORY	1
4	D10186480.9	KNOB COVER HYDRAULIC LIFT ACCESSORY LOWER	1
5	D10228950.9	KNOB COVER HYDRAULIC LIFT ACCESSORY UPPER	1
6	D10186510.9	SPOOL COVER HYDRAULIC LIFT ACCESSORY	1
7	D10186460.9	WASHER 22X27 FLAT COPPER	1
8	D10186450.9	SEAL O RING 1.80X9.0	1
9	D10186500.9	SCREW COVER HYDRAULIC LIFT ACCESSORY	1
10	D10066820.9	SEAL 9/16" OIL PASSAGE PLUG	1
11	D81001170.9	BOLT 9/16-18X0.62 HEX HEAD	1
12	D10513980.9	CYLINDER WITH VALVE ASSEMBLY AND PISTON ASSEMBLY HYDRAULIC LIFT	1
13	D10177270.9	CYLINDER ASSEMBLY WITH BUSHING AND SPOOL VALVE HYDRAULIC LIFT	1
14	D10348970.9	SPRING HYDRAULIC LIFT CONTROL VALVE	1
15	D93600060.9	SEAL O RING 0.070"X0.500"	3
16	D10077950.9	SLEEVE HYDRAULIC LIFT CONTROL VALVE	1
17	D10194150.9	VALVE ASSEMBLY HYDRAULIC LIFT SAFETY	1
18	D85500130.9	WASHER M8 FLAT	1
19	D10059580.9	GASKET HYDRAULIC LIFT SAFETY VALVE	1
20	D10059200.9	RING HYDRAULIC CYLINDER DOWEL	2
21	D10072280.9	BOLT 5/16"-18X0.75" HEX HEAD FLANGED	6
22	D10068990.9	PLATE HYDRAULIC LIFT VALVE RETAINING REAR	1
23	D10281210.9	SEAL O RING PISTON HYDRAULIC LIFT	1
24	D10234190.9	RING HYDRAULIC LIFT PISTON SEAL	1
25	D10095140.9	PISTON HYDRAULIC LIFT CYLINDER	1
26	D90000220.9	RING 7/16" RETAINING TYPE RC EXTERNAL	2
27	D86000010.9	WASHER 3/8" SPRING LOCK	1
28	D10095200.9	BAFFLE HYDRAULIC LIFT CYLINDER OIL OUTER	1
29	D10067750.9	PIN HYDRAULIC LIFT ACTUATOR PIVOT	1
30	D10059910.9	LEVER HYDRAULIC LIFT CONTROL VALVE	1
31	D10066720.9	RING 5/16" RETAINING TYPE RB EXTERNAL	1
32	D10058580.9	ACTUATOR HYDRAULIC LIFT VALVE	1
33	D10072340.9	SEAL O RING 0.364"X0.066"	2
34	D10340260.9	LEVER ASSEMBLY HYDRAULIC LIFT CONTROL VALVE	1
35	D10067720.9	ROLLER HYDRAULIC LIFT POSITION CAM FOLLOWER	1
36	D10012440.9	RING 1/2" RETAINING TYPE RB EXTERNAL	2
37	D10067680.9	SHAFT HYDRAULIC LIFT CONTROL LEVER	1
38	D83000020.9	NUT 3/8"-16 HEX	1
39	D10348960.9	SPRING HYDRAULIC LIFT POSITION CONTROL VALVE OVERTRAVEL	1
40	D10249630.9	SEAL RING 1.68X11.44 DIAMETER HYDRAULIC LIFT ACCESS COVER	4

TABLE-39
Hydraulic Lift Cover




TABLE-39**Hydraulic Lift Cover**

Fig. No.	Part No.	Description	Qty
41	D10077910.9	SHAFT ASSEMBLY HYDRAULIC LIFT DRAFT CONTROL SELECTOR	1
42	D10068980.9	HANDLE ASSEMBLY HYDRAULIC LIFT DRAFT CONTROL	1
43	D81001010.9	BOLT 1/2"-20X1.00" HEX HEAD	2
44	D10058700.9	WASHER SHAFT HYDRAULIC LIFT LOCK	2
45	D10095210.9	WASHER SHAFT HYDRAULIC LIFT	2
46	D10077970.9	PIN PLUNGER GUIDE HYDRAULIC LIFT	1
47	D10072330.9	SHAFT HYDRAULIC LIFT CONTROL LEVER	1
48	D10067590.9	LEVER AND ROLLER ASSEMBLY HYDRAULIC LIFT CONTROL	1
49	D90000430.9	RING 1" RETAINING TYPE RC EXTERNAL	1
50	D10067690.9	LEVER HYDRAULIC LIFT CONTROL	1
51	D93400140.9	PIN	1
52	D81001670.9	BOLT 7/16"X4.1"-20 UNC HEX HEAD	1
53	D10067730.9	ROLLER HYDRAULIC LIFT POSITION CAM FOLLOWER	1
54	D90000410.9	RING 3/8" RETAINING TYPE RC EXTERNAL	1
55	D10067700.9	WASHER HYDRAULIC LIFT SHAFT THRUST	1
56	D10067070.9	BOLT 7/16"-20X1.75" HEX HEAD	3
57	D10433420.9	ARM HYDRAULIC LIFT RAM	1
58	D10095160.9	ROD HYDRAULIC LIFT CONNECTING	1
59	D10068910.9	RETAINER HYDRAULIC LIFT CHECK VALVE	1
60	D10060590.9	SPRING HYDRAULIC LIFT CHECK VALVE	1
61	D10061110.9	BOLT 7/16"-14X1.38" HEX HEAD	1
62	D10068170.9	QUADRANT ASSEMBLY HYDRAULIC LIFT CONTROL	1
63	D10069400.9	SUPPORT HYDRAULIC LIFT CONTROL QUADRANT	1
64	D81000730.9	BOLT 3/8"-16X1.25" HEX HEAD	2
65	D86000020.9	WASHER 7/16" SPRING LOCK	5
66	D86000010.9	WASHER 3/8" SPRING LOCK	2
67	D10058660.9	GASKET HYDRAULIC LIFT QUADRANT COVER	1
68	D10060820.9	SPACER HYDRAULIC LIFT CONTROL LEVER	1
69	D10077860.9	LINK HYDRAULIC LIFT DRAFT CONTROL CONNECTER	1
70	D10072290.9	GASKET HOUSING HYDRAULIC LIFT	1
71	D10236610.9	CLAMP YOKE HYDRAULIC LIFT	2
72	D10067060.9	PIN 3/8"X1.656" CLEVIS	1
73	D10013460.9	PIN 1/8"X0.75" COTTER	2
74	D10292860.9	BOLT 7/16"-14X1.75" HEX HEAD WITH HOLE	1
75	D10095230.9	BUSHING HYDRAULIC LIFT SHAFT	2
76	D10095240.9	BUSHING HYDRAULIC LIFT SHAFT	2
77	D10095170.9	SEAL O RING 3.2X54.0	2
78	D10067670.9	PLATE HYDRAULIC LIFT CONTROL FRICTION	1
79	D10059150.9	PLUG HYDRAULIC LIFT CHECK VALVE	1
80	D10066970.9	BALL 15/32" DIAMETER	1

TABLE-39
Hydraulic Lift Cover




TABLE-39
Hydraulic Lift Cover

Fig. No.	Part No.	Description	Qty
81	D93600090.9	SEAL O RING 0.103"X0.625"	1
82	D10069020.9	HANDLE ASSEMBLY HYDRAULIC LIFT POSITION CONTROL	1
83	D10069270.9	DISC HYDRAULIC LIFT CONTROL FRICTION	2
84	D83000100.9	NUT 7/16"-20 NYLOCK	1
85	D10072300.9	WASHER LIFT CONTROL SHAFT CUP	1
86	D10072320.9	WASHER HYDRAULIC LIFT CONTROL SPRING	1
87	D81001050.9	BOLT 1/4"-20X0.50" HEX HEAD	2
88	D10066580.9	PIN 5/16"X2.00" CLEVIS	1
89	D10433410.9	SHAFT HYDRAULIC LIFT	1
90	D10095220.9	WASHER HYDRAULIC LIFT SHAFT THRUST	1
91	D10433430.9	ARM ASSEMBLY HYDRAULIC LIFT LH	1
92	D10433440.9	ARM ASSEMBLY HYDRAULIC LIFT RH	1
93	D10024070.9	SEAL O RING 2.40X25.00	1
94	D81001030.9	BOLT 7/16"-14X1.75" HEX HEAD	2
95	D10360050.9	LINK ASSEMBLY AUTO LIFT CONTROL LINK	1
96	D10361070.9	WASHER HYDRAULIC LIFT SHAFT THRUST	2
97	D10361060.9	SEAL 2.62X17.12 ADOPTER	1
98	D10344200.9	WASHER SEALING M24	1
99	D10340240.9	PIN HYDRAULIC LIFT ACTUATOR PIVOT	1
100	D10340280.9	ADOPTER M24X1.5 HYDRAULIC LIFT PIVOT	1
101	D82500620.9	SCREW M8X1.25X35-8.8 HEX HEAD (PRECOATING)	1
102	D86500030.9	WASHER M8 SPRING LOCK	1
103	D81000130.9	BOLT 7/16"-14X2.50" HEX HEAD	1
104	D10004120.9	VALVE ASSEMBLY HYDRAULIC LIFT PUMP RELIEF	1
105	D10060690.9	PLUG HYDRAULIC LIFT UNLOAD VALVE	1
106	D10067770.9	PLUG HYDRAULIC LIFT VALVE BLOCK	1
107	D10069040.9	PLUG HYDRAULIC LIFT VALVE BLOCK	1
108	D93600050.9	SEAL O RING 0.070"X0.440"	1
109	D93600050.9	SEAL O RING 0.070"X0.440"	2
110	D93600200.9	SEAL O RING 0.103"X0.812"	1
111	D93600060.9	SEAL O RING 0.070"X0.500"	1
112	D93600190.9	SEAL O RING 0.103"X0.562"	5
113	D93600170.9	SEAL O RING 0.070"X0.562"	2
114	D10066650.9	SPRING HYDRAULIC LIFT UNLOAD VALVE	1
115	D10069030.9	SPRING FEATHERING VALVE	1
116	D10077850.9	LEVER HYDRAULIC LIFT DRAFT CONTROL	1
117	D10077960.9	PIN PIVOT ACUATOR HYDRAULIC LIFT	1
118	D10236300.9	BOOT HYDRAULIC LIFT YOKE	1
119	D10236320.9	HOUSING HYDRAULIC LIFT DRAFT CONTROL SPRING	1
120	D10058610.9	SPRING HYDRAULIC LIFT DRAFT CONTROL	1

TABLE-39
Hydraulic Lift Cover




TABLE-39**Hydraulic Lift Cover**

Fig. No.	Part No.	Description	Qty
121	D10236310.9	YOKE HYDRAULIC LIFT	1
122	D10059170.9	SHIM HYDRAULIC LIFT DRAFT CONTROL (0.0150")	1
123	D10059180.9	SHIM HYDRAULIC LIFT DRAFT CONTROL (0.0200")	1
124	D10059190.9	SHIM HYDRAULIC LIFT DRAFT CONTROL (0.0250")	1
125	D10077870.9	PLUNGER HYDRAULIC LIFT DRAFT CONTROL	1
126	D10058630.9	SEAT DRAFT CONTROL SPRING HOUSING	1
127	D10059510.9	SEAT HYDRAULIC LIFT DRAFT CONTROL SPRING	1
128	D86000040.9	WASHER 5/16" SPRING LOCK	2
129	D81500190.9	BOLT M8X1.25X45-8.8P HEX HEAD	1
130	D81000100.9	BOLT 7/16"-14X1.00" HEX HEAD	2
131	D10173630.9	ADAPTOR VALVE HYDRAULIC REMOTE	2

TABLE-40
Hydraulic Lift Cylinder




TABLE-40
Hydraulic Lift Cylinder

Fig. No.	Part No.	Description	Qty
1	D10072280.9	BOLT 5/16"-18X0.75" HEX HEAD FLANGED	3
2	D10068990.9	PLATE HYDRAULIC LIFT VALVE RETAINING REAR	1
3	D10059200.9	RING HYDRAULIC CYLINDER DOWEL	2
4	D10194150.9	VALVE ASSEMBLY HYDRAULIC LIFT SAFETY	1
5	D10059580.9	GASKET HYDRAULIC LIFT SAFETY VALVE	1
6	D93100060.9	PLUG 1/"8-27 SOCKET HEX HEAD (STEEL)	4
7	D10068920.9	BUSHING HYDRAULIC LIFT UNLOADING VALVE REAR	1
8	D93600060.9	SEAL O RING 0.070"X0.500"	1
9	D10069000.9	VALVE HYDRAULIC LIFT UNLOAD	1
10	D10066650.9	SPRING HYDRAULIC LIFT UNLOAD VALVE	1
11	D93600170.9	SEAL O RING 0.070"X0.562"	2
12	D10060690.9	PLUG HYDRAULIC LIFT UNLOAD VALVE	1
13	D10077940.9	VALVE HYDRAULIC LIFT CONTROL	1
14	D10348970.9	SPRING HYDRAULIC LIFT CONTROL VALVE	1
15	D10077920.9	BUSHING CONTROL VALVE HYDRAULIC LIFT	1
16	D10069040.9	PLUG HYDRAULIC LIFT VALVE BLOCK	1
17	D93600050.9	SEAL O RING 0.070"X0.440"	1
18	D10069030.9	SPRING FEATHERING VALVE	1
19	D10069010.9	SPOOL HYDRAULIC LIFT PUMP FLOW CONTROL VALVE	1
20	D10077930.9	BUSHING HYDRAULIC LIFT FLOW CONTROL	1
21	D93600060.9	SEAL O RING 0.070"X0.500"	2
22	D10067770.9	PLUG HYDRAULIC LIFT VALVE BLOCK	1
23	D10513980.9	CYLINDER WITH VALVE ASSEMBLY AND PISTON ASSEMBLY HYDRAULIC LIFT	1
24	D10077950.9	SLEEVE HYDRAULIC LIFT CONTROL VALVE	1
25	D10177270.9	CYLINDER ASSEMBLY WITH BUSHING AND SPOOL VALVE HYDRAULIC LIFT	1

TABLE-41
Hydraulic Lift Shafts




TABLE-41
Hydraulic Lift Shafts

Fig. No.	Part No.	Description	Qty
1	D10433440.9	ARM ASSEMBLY HYDRAULIC LIFT RH	1
2	D10067140.9	BUSH HYDRAULIC LIFT POWER ARM	4
3	D10433410.9	SHAFT HYDRAULIC LIFT	1
4	D10433420.9	ARM HYDRAULIC LIFT RAM	1
5	D10095230.9	BUSHING HYDRAULIC LIFT SHAFT	2
6	D10095170.9	SEAL O RING 3.2X54.0	2
7	D10095230.9	BUSHING HYDRAULIC LIFT SHAFT	2
8	D10433430.9	ARM ASSEMBLY HYDRAULIC LIFT LH	1
9	D81001010.9	BOLT 1/2"-20X1.00" HEX HEAD	2
10	D10058700.9	WASHER SHAFT HYDRAULIC LIFT LOCK	2
11	D10095210.9	WASHER SHAFT HYDRAULIC LIFT	2
12	D90000410.9	RING 3/8" RETAINING TYPE RC EXTERNAL	1
13	D10067730.9	ROLLER HYDRAULIC LIFT POSITION CAM FOLLOWER	1
14	D10077910.9	SHAFT ASSEMBLY HYDRAULIC LIFT DRAFT CONTROL SELECTOR	1
15	D10067590.9	LEVER AND ROLLER ASSEMBLY HYDRAULIC LIFT CONTROL	1
16	D10013460.9	PIN 1/8"X0.75" COTTER	1
17	D10067060.9	PIN 3/8"X1.656" CLEVIS	1
18	D90000430.9	RING 1" RETAINING TYPE RC EXTERNAL	1
19	D10095160.9	ROD HYDRAULIC LIFT CONNECTING	1
20	D10095140.9	PISTON HYDRAULIC LIFT CYLINDER	1
21	D10281210.9	SEAL O RING PISTON HYDRAULIC LIFT	1
22	D10234190.9	RING HYDRAULIC LIFT PISTON SEAL	1
22A	D10095220.9	WASHER HYDRAULIC LIFT SHAFT THRUST	1
23	D10072280.9	BOLT 5/16"-18X0.75" HEX HEAD FLANGED	3
24	D10095200.9	BAFFLE HYDRAULIC LIFT CYLINDER OIL OUTER	1
25	D93600050.9	SEAL O RING 0.070"X0.440"	1
26	D93600060.9	SEAL O RING 0.070"X0.500"	4
27	D10177330.9	CYLINDER WITH VALVE ASSEMBLY AND PISTON ASSEMBLY HYDRAULIC LIFT	1
28	D10068990.9	PLATE HYDRAULIC LIFT VALVE RETAINING REAR	1
29	D10067700.9	WASHER HYDRAULIC LIFT SHAFT THRUST	1
30	D10072330.9	SHAFT HYDRAULIC LIFT CONTROL LEVER	1
31	D93400140.9	PIN	1
32	D10067060.9	PIN 3/8"X1.656" CLEVIS	1
33	D10067690.9	LEVER HYDRAULIC LIFT CONTROL	1
34	D10013460.9	PIN 1/8"X0.75" COTTER	1
35	D10081380.9	LEVER AND LINK ASSEMBLY HYDRAULIC LIFT DRAFT CONTROL	1
35A	D10077860.9	LINK HYDRAULIC LIFT DRAFT CONTROL CONNECTER	1
35B	D10077960.9	PIN PIVOT ACUATOR HYDRAULIC LIFT	1
35C	D10077850.9	LEVER HYDRAULIC LIFT DRAFT CONTROL	1
36	D10059910.9	LEVER HYDRAULIC LIFT CONTROL VALVE	1

TABLE-41
Hydraulic Lift Shafts




TABLE-41
Hydraulic Lift Shafts

Fig. No.	Part No.	Description	Qty
37	D10067750.9	PIN HYDRAULIC LIFT ACTUATOR PIVOT	1
38	D90000220.9	RING 7/16" RETAINING TYPE RC EXTERNAL	2
39	D10067720.9	ROLLER HYDRAULIC LIFT POSITION CAM FOLLOWER	1
40	D10340260.9	LEVER ASSEMBLY HYDRAULIC LIFT CONTROL VALVE	1
41	D86000020.9	WASHER 7/16" SPRING LOCK	1
42	D83000020.9	NUT 3/8"-16 HEX	1
43	D10012440.9	RING 1/2" RETAINING TYPE RB EXTERNAL	2
44	D10067750.9	PIN HYDRAULIC LIFT ACTUATOR PIVOT	1
45	D10348960.9	SPRING HYDRAULIC LIFT POSITION CONTROL VALVE OVERTRAVEL	1
46	D10067680.9	SHAFT HYDRAULIC LIFT CONTROL LEVER	1
47	D10058580.9	ACTUATOR HYDRAULIC LIFT VALVE	1
48	D10066720.9	RING 5/16" RETAINING TYPE RB EXTERNAL	1

TABLE-42
Hydraulic Flow System




TABLE-42**Hydraulic Flow System**

Fig. No.	Part No.	Description	Qty
1	D93600060.9	SEAL O RING 0.070"X0.500"	2
2	D10284710.9	PIPE ASSEMBLY HYDRAULIC LIFT INTAKE FILTER	1
3	D10002380.9	SPACER HYDRAULIC LIFT OIL RETURN	1
4	D93600050.9	SEAL O RING 0.070"X0.440"	1
5	D10002390.9	RETAINER HYDRAULIC LIFT OIL RETURN	2
6	D10002340.9	TUBE ASSEMBLY HYDRAULIC OIL RETURN	1
7	D10002450.9	NUT HYDRAULIC PUMP RELIEF VALVE BAFFLE	1
8	D10002400.9	TUBE AND BRACKET ASSEMBLY HYDRAULIC LIFT RELIEF VALVE	1
9	D93600060.9	SEAL O RING 0.070"X0.500"	2
10	D10002470.9	TUBE ASSEMBLY HYDRAULIC LIFT PRESSURE	1
11	D10002480.9	RING TUBE HYDRAULIC LIFT PRESSURE SNAP	1
12	D10002460.9	SEAL 5/16" DIAMETER HYDRAULIC OIL RETURN	1
13	D81000660.9	BOLT 5/16"-24X1.125" HEX HEAD	1
14	D10004120.9	VALVE ASSEMBLY HYDRAULIC LIFT PUMP RELIEF	1

TABLE-43
Linkage Three Point Subassembly




TABLE-43**Linkage Three Point Subassembly**

Fig. No.	Part No.	Description	Qty
1	D10614280.9	LINK ASSEMBLY HYDRAULIC LOWER LINK LH	1
2	D10614300.9	LINK ASSEMBLY HYDRAULIC LOWER LINK RH	1
3	D10307430.9	SHAFT LOWER LINK HYDRAULIC LH	1
4	D10307440.9	SHAFT LOWER LINK HYDRAULIC RH	1
5	D81000060.9	BOLT 3/8"-16X1.00" HEX HEAD	4
6	D86000010.9	WASHER 3/8" SPRING LOCK	4
7	D10471850.9	LINK ASSEMBLY HYDRAULIC UPPER LIFT	1
8	D10245510.9	PIN DRAWBAR HYDRAULIC UPPER LIFT LINK	1
9	D10018450.9	PIN 1.0"X4.0" CLEVIS (HYDRAULIC LIFT UPPER LINK)	1
10	D81500030.9	BOLT M8X1.25X35-6.6 HEX HEAD	1
11	D83500160.9	NUT M8X1.25 NYLOCK HEX	1
12	D10475150.9	ROD ASSEMBLY HYDRAULIC LIFT LEVELLING RH	2
13	D10077320.9	PIN HYDRAULIC LIFT	2
14	D10020820.9	PIN 15.8X58 CLEVIS HYDRAULIC LIFT ROD LH	2
15	D10013470.9	PIN 1/8"X1.00" COTTER	4
16	D10440640.9	BRACKET STAY BAR MOUNTING LH	1
17	D10440660.9	BRACKET STAY BAR MOUNTING RH	1
18	D10440680.9	STAY BAR ASSEMBLY LH (SQUARE TYPE)	1
19	D10440690.9	STAY BAR ASSEMBLY RH (SQUARE TYPE)	1
20	D10440710.9	PIN 15.8X89 CLEVIS	2
21	D88400210.9	PIN 5.0X40.0 COTTER	2
22	D83500670.9	NUT M20X2.50 HEX NYLOCK	2

TABLE-44
Tubing Hydraulic Subassembly




TABLE-44**Tubing Hydraulic Subassembly**

Fig. No.	Part No.	Description	Qty
1	D10193330.9	COUPLING ASSEMBLY VALVE HYDRAULIC REMOTE (POPPET TYPE)	1
2	D10193340.9	COUPLING ASSEMBLY VALVE HYDRAULIC REMOTE (POPPET TYPE)	1
3	D91500050.9	ELBOW 13/16 AND 3/4-16 UN	1
4	D10375240.9	ADAPTOR 13/16"-16 UN AND 3/4"-16 UNF	3
5	D10027600.9	BRACKET ASSEMBLY COUPLING ASC VALVE	1
6	D10104180.9	PUMP ASSEMBLY HYDRAULIC LIFT OIL (TANDEM)	1
7	D10336940.9	BOLT HYDRAULIC CONNECTION M18X1.5X30	9
8	D10174950.9	SEAL BANJO BOLT DISTRIBUTOR TO CYLINDER TUBE	18
9	D10514040.9	TUBE ASSEMBLY SPOOL VALVE CONTROL TO QRC LOWER	1
10	D83500060.9	NUT M8X1.25-6 HEX	2
11	D81500130.9	BOLT M8X1.25X60-8.8 HEX HEAD	2
12	D10202470.9	VALVE ASSEMBLY HYDRAULIC CONTROL SINGLE SPOOL	1
13	D86000040.9	WASHER 5/16" SPRING LOCK	2
14	D81000090.9	BOLT 7/16"-14X1.25" HEX HEAD	4
15	D10305620.9	WASHER SEALING 3/4"-16	3
16	D86000020.9	WASHER 7/16" SPRING LOCK	4
17	D10514020.9	TUBE ASSEMBLY SPOOL VALVE CONTROL TO QRC UPPER	1
18	D10582650.9	BRACKET ASSEMBLY SPOOL VALVE AND SWITCH LIFTOMATIC CONTROL	1
19	D10514080.9	TUBE ASSEMBLY SPOOL VALVE CONTROL TO JUNCTION BOX	1
20	D10528430.9	CONNECTOR M18X1.5 AND 3/4-16 UNF STUD END	2
21	D81500190.9	BOLT M8X1.25X45-8.8P HEX HEAD	3
22	D10288760.9	JUNCTION BOX SPOOL VALVE	1
23	D10514790.9	BRACKET ASSEMBLY JUNCTION BOX MOUNTING	1
24	D10528520.9	TUBE ASSEMBLY JUNCTION BOX TO ACCESSORY PLATE	1
25	D10305610.9	BOLT HYDRAULIC CONNECTION 3/4"-16	1
26	D10530990.9	TUBE ASSEMBLY SPOOL VALVE TO ACCESSORY PLATE	1
27	D10469790.9	ADAPTOR M18 AND 13/16"-16 UN	1
28	D10505660.9	TUBE ASSEMBLY HYDRAULIC CENTER HOUSING HOSE TO SUCTION FILTER	1
29	D10013970.9	CLAMP HOSE 35A	2
30	D10388820.9	BRACKET FILTER ADAPTER MOUNTING	1
31	D10505720.9	TUBE ASSEMBLY HYDRAULIC SUCTION FILTER HOSE TO PUMP	1
32	D10124600.9	HOSE HYDRAULIC LIFT OIL	1
33	D10505710.9	TUBE ASSEMBLY HYDRAULIC SUCTION FILTER ADAPTOR TO HOSE PUMP	1
34	D86500030.9	WASHER M8 SPRING LOCK	2
35	D81500030.9	BOLT M8X1.25X35-6.6 HEX HEAD	2
36	D10505740.9	TUBE ASSEMBLY CENTRE HOUSING TO HOSE SUCTION FILTER	1
37	D10013170.9	HOSE HYDRAULIC LIFT PUMP INLET TUBE	1
38	D10222790.9	FILTER ASSEMBLY HYDRAULIC LIFT OIL INTAKE (DELPHINIUM BLUE)	1
39	D10284540.9	ADOPTER HYDRAULIC OIL FILTER	1
40	D81500340.9	BOLT M6X1.00X35-8.0 HEX HEAD	2

TABLE-44
Tubing Hydraulic Subassembly




TABLE-44**Tubing Hydraulic Subassembly**

Fig. No.	Part No.	Description	Qty
41	D86500040.9	WASHER M6 SPRING LOCK	4
42	D10293010.9	CLAMP ASSEMBLY HOSE 40MM	2
43	D86500150.9	WASHER M8 SPRING LOCK	7
44	D93600080.9	SEAL O RING 0.139"X1.125"	1
45	D86500090.9	WASHER M10 SPRING LOCK	2
46	D81500310.9	SCREW M8X1.25X30-8.8 HEX HEAD	2
47	D81000060.9	BOLT 3/8"-16X1.00" HEX HEAD	2
48	D10035900.9	SCREW M10X1.50X20-6.6 HEX HEAD	2
49	D81500490.9	BOLT M6X1.00X20-9.8 HEX HEAD	2
50	D86000010.9	WASHER 3/8" SPRING LOCK	2
51	D85500010.9	WASHER M10 FLAT	2
52	D81500660.9	BOLT M8X1.25X20-9.8 HEX HEAD	2
53	D83500110.9	NUT M8X1.25-8 HEX	2
54	D10505680.9	TUBE ASSEMBLY HYDRAULIC PRESSURE PUMP TO CONNECTOR TUBE	1
55	D10618010.9	TUBE ASSEMBLY HYDRAULIC PRESSURE CONNECTOR TUBE TO SPOOL VALVE	1
56	D10505510.9	TUBE ASSEMBLY JUNCTION BOX TO LH OIL IMMERSED BRAKE	1
57	D10627880.9	TUBE ASSEMBLY JUNCTION BOX TO RH OIL IMMERSED BRAKE	1
58	D10505690.9	TUBE ASSEMBLY HYDRAULIC PRESSURE CONNECTOR PUMP TUBE TO SPOOL TUBE	1
59	D10640040.9	KNOB SPOOL VALVE LEVER	1
60	D10546700.9	CLAMP ASSEMBLY HYDRAULIC SUCTION	1
61	D10651040.9	LEVER ASSEMBLY SPOOL VALVE CONTROL ACTUATING	1

TABLE-45
Hydraulic Tubing Subassembly




TABLE-45**Hydraulic Tubing Subassembly**

Fig. No.	Part No.	Description	Qty
1	D10480640.9	TUBE ASSEMBLY POWER STEERING RH TURN	1
2	D10480630.9	TUBE ASSEMBLY POWER STEERING LH TURN	1
3	D10514250.9	TUBE ASSEMBLY HYDRAULIC PUMP TO HYDRAULIC CONNECTOR	1
4	D10514020.9	TUBE ASSEMBLY SPOOL VALVE CONTROL TO QRC UPPER	1
5	D10651040.9	LEVER ASSEMBLY SPOOL VALVE CONTROL ACTUATING	1
6	D81500590.9	BOLT M8X1.25X25-6.6 HEX HEAD	1
7	D10514080.9	TUBE ASSEMBLY SPOOL VALVE CONTROL TO JUNCTION BOX	1
8	D10480560.9	TUBE ASSEMBLY HYDRAULIC PUMP TO HYDRAULIC FILTER HOSE	1

TABLE-46
Solenoid And Linkage Subassembly




TABLE-46**Solenoid And Linkage Subassembly**

Fig. No.	Part No.	Description	Qty
1	D85500110.9	WASHER M6 FLAT	5
2	D10598920.9	BRACKET ASSEMBLY WATER PARATOR AND SOLENOID PIVOT MOUNTING	1
3	D87500590.9	PIN 5.8X16 CLEVIS	2
4	D85500050.9	WASHER M8 FLAT	1
5	D10000640.9	PIN 1/16"X0.50" COTTER	4
6	D10598970.9	ROD ASSEMBLY PIVOT TO FIP STOP LEVER	1
7	D10598880.9	BRACKET ASSEMBLY SOLENOID MOUNTING	1
8	D10598950.9	LINKAGE SOLENOID TO PIVOT	1
9	D88400040.9	PIN 3.2X25.0 COTTER	1
10	D10598960.9	LINKAGE PIVOT SOLENOID LEVER	1
11	D10481020.9	SWITCH SINGLE ASSEMBLY CUT OFF VALVE	1
12	D81500490.9	BOLT M6X1.00X20-9.8 HEX HEAD	2
13	D86500040.9	WASHER M6 SPRING LOCK	2

TABLE-47
Liftomatic Control Subassembly




TABLE-47**Liftomatic Control Subassembly**

Fig. No.	Part No.	Description	Qty
1	D10582620.9	LEVER AND HUB ASSEMBLY LIFTOMATIC	1
2	D10582650.9	BRACKET ASSEMBLY SPOOL VALVE AND SWITCH LIFTOMATIC CONTROL	1
3	D10532800.9	SWITCH ASSEMBLY LIFTOMATIC CONTROL	1
4	D10582640.9	LINK LIFTOMATIC CONTROL	1
5	D10393640.9	CIRCLIP 10X1 N IS:3075 (PART 1)	1
6	D85500140.9	WASHER M10 FLAT	1
7	D10152630.9	SCREW M8X1.25X20 COUNTERSUNK SOCKET HEAD	2
8	D10589860.9	CONSOLE LIFTOMATIC CONTROL ASSEMBLY	1

TABLE-48
BATTERY SUBASSEMBLY




TABLE-48
BATTERY SUBASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10480920.9	ISOLATOR ASSEMBLY BATTERY	1
2	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	2
3	D10585370.9	BRACKET BATTERY CUT OFF SWITCH MOUNTING	1
4	D10498910.9	CABLE ASSEMBLY BATTERY POSITIVE TO ISOLATOR	1
5	D10498920.9	CABLE ASSEMBLY ISOLATOR TO STARTER SOLENOID	1
6	D10498930.9	CABLE ASSEMBLY BATTERY TO GROUND	1
7	D83500240.9	NUT M10X1.50-6 HEX	1
8	D10082850.9	BATTERY ASSEMBLY MAINTENANCE FREE TYPE 12V 88AH	1
9	D10440030.9	TRAY BATTERY AND BRACKET ASSEMBLY	3
10	D10034220.9	STRIP FELT BATTERY REST	1
11	D10407010.9	COVER ASSEMBLY BATTERY	1

TABLE-49
Harness Subassembly




TABLE-49**Harness Subassembly**

Fig. No.	Part No.	Description	Qty
1	D10508130.9	HARNESS ASSEMBLY REAR FENDER RH	1
2	D10508140.9	HARNESS ASSEMBLY REAR FENDER LH	1
3	D10508160.9	HARNESS ASSEMBLY INSTRUMENT PANEL TO RUNNING BOARD	1
4	D10508120.9	HARNESS ASSEMBLY ELECTRICAL MAIN	1
5	D10508150.9	HARNESS ASSEMBLY INSTRUMENT PANEL	1
6	D10508170.9	HARNESS ASSEMBLY PROJECTOR LAMP	1
7	D10401250.9	HARNESS ASSEMBLY GLOW PLUG	1
8	D10509150.9	HARNESS ASSEMBLY TRAILER SOCKET	1
9	D10510390.9	HARNESS ASSEMBLY BEACON LAMP	1
10	D10549930.9	HARNESS ASSEMBLY CANOPY WITH RELAY	1
11	D10558930.9	HARNESS ASSEMBLY BEACON LAMP	1
12	D10492030.9	BEACON LAMP	1
13	D10198970.9	ALTERNATOR ASSEMBLY 35 AMPERE (B TYPE PULLEY)	1
13-1	D10197190.9	ALTERNATOR ASSEMBLY 55 AMPERE (B TYPE PULLEY)	1
14	D10376720.9	STARTER MOTOR ASSEMBLY GEAR REDUCTION TYPE (2.5KW)	1
15	D10498400.9	SWITCH ASSEMBLY STOP LAMP	1
16	D10371230.9	FLASHER ASSEMBLY INDICATOR LIGHT	1
17	D10497550.9	SWITCH ASSEMBLY NEUTRAL PTO	2
18	D10656110.9	UNIT ENGINE SHUT OFF CONTROLLER RELAY (SEAT OCCUPANCY)	1
19	D10522130.9	SWITCH ASSEMBLY ECO MODE (NO TYPE)	1
20	D10656100.9	BUZZER ASSEMBLY (LED TYPE)	1
21	D10001920.9	HARNESS ASSEMBLY TRANSMISSION	1
22	D10135490.9	SOCKET ASSEMBLY TRAILER ELECTRICAL	1
23	D10028490.9	HARNESS SAFETY START SWITCH TO DASH BOARD	1

TABLE-50
Lamp Beacon Subassembly




TABLE-50**Lamp Beacon Subassembly**

Fig. No.	Part No.	Description	Qty
1	D10492030.9	BEACON LAMP	1
2	D10523390.9	BRACKET ASSEMBLY BEACON	1
3	D10510910.9	BRACKET BEACON LAMP MOUNTING	1
4	D85500060.9	WASHER M12 FLAT	4
5	D81501250.9	BOLT M12X1.25X80-10.9P HEX HEAD	2
6	D83500180.9	NUT M12X1.75 NYLOCK HEX	2
7	D85500190.9	WASHER M4.0 FLAT	4
8	D81502010.9	BOLT M4X20-6.8 HEX HEAD	4

TABLE-51
Fender Assembly With Electrical Rear Rh




TABLE-51**Fender Assembly With Electrical Rear Rh**

Fig. No.	Part No.	Description	Qty
1	D85500130.9	WASHER M8 FLAT	2
2	D83500060.9	NUT M8X1.25-6 HEX	2
3	D81500590.9	BOLT M8X1.25X25-6.6 HEX HEAD	2
4	D10388510.9	LAMP ASSEMBLY PARKING RH	1
5	D10388520.9	LAMP ASSEMBLY FENDER REAR RH	1
6	D10501470.9	LAMP ASSEMBLY PLOUGH	1
7	D10508480.9	FENDER ASSEMBLY REAR RH	1
8	D83500350.9	NUT M6X1.00 NYLOCK HEX	4
9	D10508130.9	HARNESS ASSEMBLY REAR FENDER RH	1
10	D10430200.9	PLUG FENDER DIA 13 (ANTIQUE SILVER)	2
11	D85500110.9	WASHER M6 FLAT	2
12	D81500360.9	BOLT M6X1.00X16-9.8 HEX HEAD	2
13	D10554130.9	REFLECTOR REAR	1
14	D10554080.9	BRACKET REAR REFLECTOR	1
15	D10216680.9	SCREW M5X0.80X20 CROSS RECESSED PAN HEAD	2

TABLE-52
Fender Assembly With Electrical Rear Lh




TABLE-52**Fender Assembly With Electrical Rear Lh**

Fig. No.	Part No.	Description	Qty
1	D85500110.9	WASHER M6 FLAT	4
2	D10345870.9	LAMP ASSEMBLY VEHICLE REGISTRATION PLATE	1
3	D81500360.9	BOLT M6X1.00X16-9.8 HEX HEAD	4
4	D10508540.9	BRACKET ASSEMBLY REGISTRATION PLATE MOUNTAING	1
5	D81000330.9	BOLT 5/16"-18X1.00" HEX HEAD	2
6	D86000040.9	WASHER 5/16" SPRING LOCK	2
7	D10306410.9	HOLD DOWN REAR FENDER	1
8	D10388490.9	LAMP ASSEMBLY PARKING LH	1
9	D10508380.9	FENDER ASSEMBLY REAR LH	1
10	D83500350.9	NUT M6X1.00 NYLOCK HEX	4
11	D10430200.9	PLUG FENDER DIA 13 (ANTIQUE SILVER)	2
12	D10554130.9	REFLECTOR REAR	1
13	D10554080.9	BRACKET REAR REFLECTOR	1
14	D10216680.9	SCREW M5X0.80X20 CROSS RECESSED PAN HEAD	2
15	D10339690.9	RIVET 4X6.0MM (CLINCH TYPE)	4
16	D10508140.9	HARNESS ASSEMBLY REAR FENDER LH	1
17	D10388500.9	LAMP ASSEMBLY FENDER REAR LH	1
18	D10534070.9	PLATE DATA STATUTORY	1

TABLE-54
Hood Front And Panel Top Assembly




TABLE-54**Hood Front And Panel Top Assembly**

Fig. No.	Part No.	Description	Qty
1	D10321410.9	FOAM SEALING FRAME UPPER LH	1
2	D10321420.9	FOAM SEALING FRAME UPPER RH	1
3	D82500120.9	SCREW M6X1.00X20-6.6P HEX HEAD	2
4	D83500190.9	NUT M5X0.80 NYLOCK HEX	2
5	D10314430.9	SCREW M5X0.80X16 COUNTERSUNK HEAD	2
6	D85500110.9	WASHER M6 FLAT	8
7	D85500090.9	WASHER M5 FLAT	2
8	D81500270.9	BOLT M6X1.00X25-9.8 HEX HEAD	2
9	D10283490.9	HOOD ASSEMBLY FRONT (PLASTIC)	1
10	D10347140.9	PANEL ASSEMBLY HOOD TOP FRONT	1
11	D10311250.9	END ASSEMBLY GAS STRUT	4
12	D10316670.9	HINGE ASSEMBLY WITH LEVER AND BRACKET PANEL HOOD TOP FRONT LH	1
13	D10316680.9	HINGE ASSEMBLY WITH LEVER AND BRACKET PANEL HOOD TOP FRONT RH	1
14	D85000090.9	WASHER 7/16" FLAT	4
15	D81500280.9	BOLT M10X1.50X25-9.8 HEX HEAD	4
16	D10194500.9	STRUT BONNET OPENING	2
17	D86500090.9	WASHER M10 SPRING LOCK	4
18	D10017930.9	NUT M6X1.00 HEX NYLOCK	4
19	D10298460.9	PLATE ASSEMBLY HOOD REAR	1
20	D10223190.9	SUPPORT AND BRACKET ASSEMBLY HOOD REAR	1
21	D10281430.9	BAFFLE ASSEMBLY HOT AIR	1
22	D10561460.9	TAPE HEAT REFLECTIVE BONNET UPPER	1
23	D10561470.9	TAPE HEAT REFLECTIVE BONNET SIDE	1
24	D10557380.9	BRACKET ASSEMBLY WIRE HARNESS MOUNTING RH	1
25	D10555810.9	BRACKET ASSEMBLY WIRE HARNESS MOUNTING LH	1

TABLE-55
Grill Front And Bezel Assembly




TABLE-55**Grill Front And Bezel Assembly**

Fig. No.	Part No.	Description	Qty
1	D10340330.9	GRILL ASSEMBLY FRONT	1
2	D81500300.9	BOLT M5X0.80X8-9.8 HEX HEAD	2
3	D10017000.9	NUT M4X0.70 NYLOCK	24
4	D10016990.9	SCREW M4X0.70X10 CROSS RECESSED PAN HEAD	4
5	D10016980.9	LATCH ASSEMBLY HOOD	2
6	D10340410.9	BEZEL HEAD LAMP LOW BEAM	2
7	D10340420.9	BEZEL HEAD LAMP HIGH BEAM	2
8	D10340430.9	BEZEL LH FRONT GRILL	1
9	D10340440.9	BEZEL RH FRONT GRILL	1
10	D10402900.9	BADGE 2X2	2
11	D10338500.9	HEAD LAMP ASSEMBLY (LOW BEAM PROJECTOR)	2
12	D10338490.9	HEAD LAMP ASSEMBLY (HIGH BEAM PROJECTOR)	2
13	D10377130.9	FOAM SEALING HEAD LAMP	4

TABLE-56
Hood Rear And Instrument Cluster Assembly




TABLE-56**Hood Rear And Instrument Cluster Assembly**

Fig. No.	Part No.	Description	Qty
1	D10016490.9	GROMMET HOOD SUPPORT	4
2	D10016820.9	NUT INSTRUMENT CLUSTER RETAINING	4
3	D10508150.9	HARNESS ASSEMBLY INSTRUMENT PANEL	1
4	D10017350.9	CLAMP FUEL SHUT OFF CABLE	1
5	D10017400.9	BOLT 1/4"-20X0.50" HEX HEAD FLANGED (GENERATOR TERMINAL)	1
6	D10659180.9	HOOD REAR AND INSTRUMENT CLUSTER ASSEMBLY	1
7	D10039900.9	SCREW 1/4"-28X1.50" PAN HEAD	4
8	D10018680.9	BOLT 5/16"-24X0.56 HEX HEAD	2
9	D10410390.9	SWITCH AND KEY ASSEMBLY IGNITION	1
10	D10367380.9	SWITCH ASSEMBLY HEATER AND STARTER	1
11	D10206690.9	KEY IGNITION LOCK FARMTRAC	2
12	D10633700.9	SWITCH ASSEMBLY LIGHTING	1
13	D10630640.9	CLUSTER ASSEMBLY INSTRUMENT 4WD (POLAND)	1
14	D81000420.9	BOLT 5/16"-18X0.88" HEX HEAD	4
15	D81000710.9	BOLT 1/4"-20X0.62" HEX HEAD	4
16	D83000060.9	NUT 5/16"-18 HEX	4
17	D85000030.9	WASHER 1/4" FLAT	4
18	D86000110.9	WASHER 5/16" LOCK EXTERNAL TOOTH	3
19	D10016460.9	SWITCH ASSEMBLY HORN BLOWING	1
20	D10291530.9	SWITCH ASSEMBLY TURN SIGNAL	1
21	D10017940.9	GROMMET 0.53X0.75 ROUND FLANGE	1
22	D10016630.9	SCREW M5X0.80X25 CROSS RECESSED PAN HEAD	4
23	D10015940.9	KNOB FUEL SHUT OFF ROD	1
24	D10026540.9	GROMMET HAND THROTTLE CONTROL LEVER	1
25	D83500190.9	NUT M5X0.80 NYLOCK HEX	4
26	D10532790.9	STEERING COVER TURKEY	1
27	D10495450.9	SWITCH ASSEMBLY BEACON LAMP	1

TABLE-57
Seat Driver Subassembly




TABLE-57**Seat Driver Subassembly**

Fig. No.	Part No.	Description	Qty
1	D10536390.9	SEAT DRIVER SUBASSEMBLY	1
2	D81000100.9	BOLT 7/16"-14X1.00" HEX HEAD	5
3	D85500060.9	WASHER M12 FLAT	8
4	D10651830.9	PLATE ASSEMBLY DRIVER SEAT AT MOUNTING	1
5	D83000040.9	NUT 7/16"-14HEX	2
6	D83000180.9	NUT 7/16"-20 HEX	1

TABLE-58
Hitch Rear Subassembly




TABLE-58**Hitch Rear Subassembly**

Fig. No.	Part No.	Description	Qty
1	D87500390.9	PIN 5X105 SPRING R TYPE (IS:6483)	2
2	D10081260.9	PIN AND RING ASSEMBLY	1
3	D10498150.9	SWINGING DRAWBAR ASSEMBLY	1
4	D83500220.9	NUT M6X1.00-5 HEX	6
5	D81500270.9	BOLT M6X1.00X25-9.8 HEX HEAD	6
6	D81500070.9	BOLT M16X2.00X40-8.8 HEX HEAD	10
7	D10500720.9	PIN SWINGING DRAWBAR MOUNTING FRONT	2
8	D10513310.9	PIN SWINGING DRAWBAR MOUNTING REAR	1
9	D10510500.9	PLATE TOW HOOK MOUNTING RH (L TYPE)	1
10	D10510490.9	PLATE TOW HOOK MOUNTING LH (L TYPE)	1
11	D10510480.9	GUARD PTO REAR	1
12	D81503140.9	BOLT M20X2.5X60-12.9 HEX HEAD	8
12-1	D81503410.9	BOLT M20X2.5X65-12.9 HEX HEAD	8
13	D83500640.9	NUT M20X2.5 LOCK	8
13-1	D83500670.9	NUT M20X2.50 HEX NYLOCK	8
14	D10510510.9	BRACKET ASSEMBLY SWINGING DRAWBAR	1
15	D86500060.9	WASHER M16 SPRING LOCK	10
16	D10580420.9	DECAL SWINGING DRAWBAR	1
17	D86500040.9	WASHER M6 SPRING LOCK	6

TABLE-59
Rops Foldable Assembly




TABLE-59**Rops Foldable Assembly**

Fig. No.	Part No.	Description	Qty
1	D10473410.9	BASE ASSEMBLY ROPS FOLDABLE LH	1
2	D10473500.9	BASE ASSEMBLY ROPS FOLDABLE RH	1
3	D10504970.9	FRAME ASSEMBLY ROPS FOLDABLE	1
4	D10333900.9	PIN ROPS MOUNTING	2
5	D10014880.9	PIN AND RING ASSEMBLY LOWER LIFT LINK LYNCH	2
6	D81502340.9	BOLT M20X2.5 ROPS MOUNTING	2
7	D83500670.9	NUT M20X2.50 HEX NYLOCK	2
8	D86000120.9	WASHER 5/8" SPRING LOCK	14
9	D81000920.9	BOLT 5/8"-18X8.00" HEX HEAD	8
10	D83000160.9	NUT 5/8"-18 HEX	2
11	D83500290.9	NUT M12X1.75 HEX	2
12	D81500170.9	BOLT M12X1.75X55-10.9 HEX HEAD	2
13	D10477350.9	PAD RUBBER FENDER AND ROPS	4
14	D10505030.9	PAD RUBBER FENDER AND ROPS	4
15	D83000490.9	NUT 5/8" SQUARE	4
16	D10549880.9	BUSH COLLAR ROPS FRAME	2

TABLE-60
Canopy Assembly




TABLE-60**Canopy Assembly**

Fig. No.	Part No.	Description	Qty
1	D10490990.9	FRAME ASSEMBLY CANOPY	1
2	D10491020.9	BRACKET FRAME ASSEMBLY CANOPY RH	1
3	D10491010.9	BRACKET FRAME ASSEMBLY CANOPY LH	1
4	D10497010.9	SPACER CANOPY MOUNTING BRACKET	6
5	D10473920.9	BRACKET WORK LAMP MOUNTING	2
6	D10474740.9	CANOPY	1
7	D10326280.9	PAD CANOPY FRAME (RUBBER)	6
8	D81500160.9	BOLT M10X1.50X45-10.9 HEX HEAD	6
9	D85500060.9	WASHER M12 FLAT	32
10	D81500170.9	BOLT M12X1.75X55-10.9 HEX HEAD	6
11	D83500180.9	NUT M12X1.75 NYLOCK HEX	5
12	D10007160.9	BOLT M12X1.75X105-10.9 HEX HEAD	8
13	D83500170.9	NUT M10X1.50 NYLOCK HEX	6
14	D85500140.9	WASHER M10 FLAT	12
15	D81500540.9	BOLT M12X1.75X40-9.8 HEX HEAD	2
16	D10522330.9	LAMP ASSEMBLY WORK	4

TABLE-61
Ballast Front Subassembly




TABLE-61**Ballast Front Subassembly**

Fig. No.	Part No.	Description	Qty
1	D86500080.9	WASHER M20 SPRING LOCK	1
2	D85500210.9	WASHER M20 FLAT	1
3	D81000410.9	BOLT 3/4"-10X4.00" HEX HEAD	4
4	D83500670.9	NUT M20X2.50 HEX NYLOCK	1
5	D81501570.9	BOLT M20X2.5X170 HEX HEAD	1
6	D83500030.9	NUT M16X2.00-8 HEX	4
7	D85500030.9	WASHER M16 FLAT MACHINED	8
8	D81501590.9	BOLT M16X2.0X200-8.8 HEX HEAD	4
9	D10042830.9	SPACER BATTERY TRAY	4
10	D10042800.9	PLATE FRONT END WEIGHT	2
11	D10324240.9	WEIGHT FRONT END	2
12	D10193130.9	WEIGHT TOWING HOOK FRONT	1
13	D10193120.9	CARRIER FRONT END WEIGHT	1
14	D10546550.9	PIN ASSEMBLY TOW HOOK FRONT	1

TABLE-62
Ballast Rear Subassembly




TABLE-62**Ballast Rear Subassembly**

Fig. No.	Part No.	Description	Qty
1	D10087690.9	WEIGHT REAR WHEEL MAIN	2
2	D81000980.9	BOLT 5/8"-18X2.28" HEX HEAD	8
3	D86000120.9	WASHER 5/8" SPRING LOCK	8
4	D83000160.9	NUT 5/8"-18 HEX	8

TABLE-63
Deflector Subassembly




TABLE-63**Deflector Subassembly**

Fig. No.	Part No.	Description	Qty
1	D10554090.9	DEFLECTOR AIR FAN ASSEMBLY LH	1
2	D10550530.9	DEFLECTOR AIR FAN ASSEMBLY RH	1
3	D82500760.9	SCREW M8X1.25X25-12.9 COUNTERSUNK HEAD	2
4	D83500060.9	NUT M8X1.25-6 HEX	2

TABLE-64
Rear View Mirror




TABLE-64**Rear View Mirror**

Fig. No.	Part No.	Description	Qty
1	D10151990.9	MIRROR AND ROD ASSEMBLY REAR VIEW	1
2	D10016680.9	BUSH REAR VIEW MIRROR	2
3	D10016490.9	GROMMET HOOD SUPPORT	8
4	D10018100.9	NUT M5X0.80 NYLOCK	8
5	D85500090.9	WASHER M5 FLAT	8
6	D10016660.9	PLATE REAR VIEW MIRROR	2
7	D10016690.9	BRACKET ASSEMBLY REAR VIEW MIRROR	2
8	D85500110.9	WASHER M6 FLAT	2
9	D10017930.9	NUT M6X1.00 HEX NYLOCK	2
10	D10216680.9	SCREW M5X0.80X20 CROSS RECESSED PAN HEAD	8
11	D10397280.9	MIRROR AND ROD ASSEMBLY REAR VIEW LH (E MARKED)	1

TABLE-65
Tool Box Subassembly




TABLE-65**Tool Box Subassembly**

Fig. No.	Part No.	Description	Qty
1	D86000150.9	WASHER 3/4" SPRING LOCK	2
2	D81001520.9	BOLT 3/4"-10X1.25" HEX HEAD	2
3	D10477810.9	BOX ASSEMBLY TOOL (PLASTIC)	1
4	D81500590.9	BOLT M8X1.25X25-6.6 HEX HEAD	2
5	D10648580.9	BRACKET ASSEMBLY TOOL BOX MOUNTING	1

TABLE-66
Decal




TABLE-66**Decal**

Fig. No.	Part No.	Description	Qty
1	D10512430.9	DECAL TRANSMISSION SHIFT PATTERN (12.4X28 REAR TYRE)	1
1-1	D10646130.9	DECAL TRANSMISSION SHIFT PATTERN (13.6X28 REAR TYRE)	1
2	D10625400.9	DECAL TYRE PRESSURE	1
3	D10510090.9	DECAL AUXILLARY VALVE USE WARNING	1
4	D10509470.9	DECAL ROPS E-MARKED	1
5	D10019110.9	DECAL TRACTOR MAINTENANCE SERVICE	1
6	D10570020.9	DECAL DIFFERENTIAL LOCK	1
7	D10510000.9	DECAL SLOPE DESCEND CAUTION	1
8	D10510110.9	DECAL VEHICLE FLUID AND AIR CLEANER CAUTION	1
9	D10510140.9	DECAL VEHICLE OPERATIONAL SAFETY INSTRUCTION CAUTION AND WARNING	1
10	D10510060.9	DECAL PERSONAL INJURY CAUTION	1
11	D10510150.9	DECAL MOVING PARTS SAFETY WARNING	1
12	D10625420.9	DECAL TRACTOR HOOD OPENING	1
13	D10534070.9	PLATE DATA STATUTORY	1
14	D10510040.9	DECAL ROPS INSTRUCTION DANGER	1
15	D10510030.9	DECAL ROLL OVER SAFETY WARNING	1
16	D10511760.9	DECAL PREMATURE CLUTCH FAILURE INSTRUCTION	1
17	D10510160.9	DECAL PTO OPERATIONAL WARNING	1
18	D10509980.9	DECAL DRAWBAR AND PTO SAFETY WARNING	1
19	D10511810.9	DECAL GENERAL INSTRUCTION CAUTION	1
20	D10510180.9	DECAL DISMOUNTING TRACTOR WARNING	1
21	D10511790.9	DECAL TRACTOR START AND FENDER SAFETY WARNING	1
22	D10537290.9	PLATE QUADRANT HYDRAULIC DEPTH AND DRAFT SELECTION	1
23	D10625410.9	DECAL HYDRAULIC COUPLING PRESSURE AND RETURN SIGN	1
24	D10625390.9	DECAL TRACTOR JACKING POINT	1
25	D10580420.9	DECAL SWINGING DRAWBAR	1
26	D10529560.9	DECAL ISOLATOR ASSEMBLY BATTERY	1
27	D10537300.9	DECAL CONTINUOUSLY VARIABLE ROTATION	1
28	D10570070.9	DECAL STARTING SWITCH BLUE	1
29	D10511730.9	DECAL HIGH VOLTAGE AND BATTERY REPAIR INSTRUCTION WARNING	1
30	D10510010.9	DECAL DISMOUNTING TRACTOR DANGER	1
31	D10511700.9	DECAL HOT SURFACE WARNING	1
32	D10398190.9	DECAL FT6045	1
33	D10570890.9	DECAL HOT SURFACE WARNING	1
34	D10589690.9	DECAL GREASE GUN	1
35	D10511720.9	DECAL SAFETY	1

TABLE-66A

Decal




TABLE-66A**Decal**

Fig. No.	Part No.	Description	Qty
36	D10570050.9	DECAL PARKING BRAKE	1
37	D10294790.9	DECAL PTO CONTROL	1
38	D10580680.9	DECAL HOT SURFACE WARNING VERTICAL	1
39	D10017640.9	DECAL FILTER CLEANER	2
40	D10017890.9	DECAL OPERATING INSTRUCTION	1
41	D10018580.9	DECAL VEHICLE WARNING	1
42	D10018620.9	DECAL BATTERY WARNING	1
43	D10019210.9	DECAL TRACTOR SAFETY INSTRUCTIONS	1
44	D10302540.9	DECAL FARMTRAC BONNET CENTER LH	1
45	D10302550.9	DECAL FARMTRAC BONNET CENTER RH	1
46	D10108040.9	DECAL CAUTION ALTERNATOR	1
47	D10185450.9	DECAL WARNING TRANSPORT LOCK	1
48	D10301160.9	DECAL CENTRE PANEL LH (FT6050)	1
49	D10301170.9	DECAL CENTRE PANEL RH (FT6050)	1
50	D10537310.9	DECAL START SWITCH MECHANISM	1
51	D10308830.9	DECAL REAR HOOD WAVES RH	1
52	D10308840.9	DECAL REAR HOOD WAVESLH	1
53	D10294820.9	DECAL SPOOL VALVE	1
54	D10473600.9	DECAL SIDE GUARD RH (FT6045)	1
55	D10473590.9	DECAL SIDE GUARD LH (FT6045)	1
56	D10303010.9	BADGE FRONT FARMTRAC (BLUE)	1

TABLE-67
Accessories Ft Engine (Power Steering)




TABLE-67**Accessories Ft Engine (Power Steering)**

Fig. No.	Part No.	Description	Qty
1	D10193240.9	HOSE CRANK CASE VENTILATION	1
2	D10193290.9	TUBE ASSEMBLY CRANK CASE VENTILATION AVL (POWER STEERING)	1
3	D10293010.9	CLAMP ASSEMBLY HOSE 40MM	2
4	D10045210.9	LINKAGE ASSEMBLY THROTTLE CONTROL	1
6	D10011810.9	WASHER FIP SHUT OFF LEVER	2
7	D10000640.9	PIN 1/16"X0.50" COTTER	2
8	D81000720.9	BOLT 3/8"-16X0.875" HEX HEAD	2
9	D10010960.9	ARM ALTERNATOR BELT	1
10	D85000010.9	WASHER 3/8" FLAT	2
11	D10010940.9	BRACKET ALTERNATOR MOUNTING	1
12	D10405550.9	INSERT OIL FILTER MOUNTING	1
13	D81000220.9	BOLT 3/8"-16X0.875" HEX HEAD LOCK (GRADE-8)	2
14	D10045150.9	WASHER FUEL INJECTOR TUBE	2
15	D10289930.9	SEAL TRANSPORT LOCK WITH BLACK COLOR	1
16	D10289920.9	WIRE LOCKING GALVANIZED IRON 0.8MM	AR
17	D95000130.9	LOCTITE CAT - 577	AR
18	D95000410.9	LOCTITE 574	AR
19	D95000430.9	LOCTITE RETAINING 609	AR
20	D95000420.9	LOCTITE 262	AR
21	D95010830.9	LOCTITE 5060	AR
22	D95010840.9	LOCTITE ANAEROBIC L-5182	AR
23	D95013580.9	LIQUID IPA CLEANER INDUSTRIAL GRADE	AR
24	D10114280.9	TUBE ASSEMBLY THERMO START (AVL EXPORT)	AR

TABLE-47
CRANKSHAFT AND GEAR ASSEMBLY




TABLE-47
CRANKSHAFT AND GEAR ASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10010350.9	CRANKSHAFT AND GEAR ASSEMBLY	1
2	D10344460.9	CRANKSHAFT	1
3	D10010380.9	GEAR CRANKSHAFT	1

TABLE-48
KIT ENGINE MAIN AND CONNECTING ROD BEARING SET SIZE STANDARD




TABLE-48**KIT ENGINE MAIN AND CONNECTING ROD BEARING SET SIZE STANDARD**

Fig. No.	Part No.	Description	Qty
1	D10074770.9	KIT ENGINE MAIN AND CONNECTING ROD BEARING SET SIZE STANDARD (FT-60)	1
2	D10076960.9	KIT ENGINE MAIN BEARING SET SIZE STANDARD (FT-45/60)	1
3	D10010200.9	BEARING CRANKSHAFT MAIN THRUST UPPER	1
4	D10010210.9	BEARING CRANKSHAFT MAIN THRUST LOWER	1
5	D10010220.9	BEARING CRANKSHAFT MAIN UPPER	3
6	D10010230.9	BEARING CRANKSHAFT MAIN LOWER	3
7	D10076970.9	KIT ENGINE CONNECTING ROD BEARING SET SIZE STANDARD (FT-45/60)	1
8	D10045000.9	BEARING CONNECTING ROD	6

TABLE-44
KIT ROCKER ARM WITH SCREW




TABLE-44
KIT ROCKER ARM WITH SCREW

Fig. No.	Part No.	Description	Qty
1	D10075030.9	KIT ROCKER ARM WITH SCREW	1
2	D10196470.9	ARM ROCKER VALVE	1
3	D10196000.9	SCREW ROCKER ARM ADJUSTING	1

TABLE-50
KIT ENGINE MAIN BEARING SET SIZE STANDARD




TABLE-50
KIT ENGINE MAIN BEARING SET SIZE STANDARD

Fig. No.	Part No.	Description	Qty
1	D10076960.9	KIT ENGINE MAIN BEARING SET SIZE STANDARD (FT-45/60)	1
2	D10010200.9	BEARING CRANKSHAFT MAIN THRUST UPPER	1
3	D10010210.9	BEARING CRANKSHAFT MAIN THRUST LOWER	1
4	D10010220.9	BEARING CRANKSHAFT MAIN UPPER	3
5	D10010230.9	BEARING CRANKSHAFT MAIN LOWER	3

TABLE-45
KIT PISTON RING SET




TABLE-45
KIT PISTON RING SET

Fig. No.	Part No.	Description	Qty
1	D10116310.9	KIT PISTON RING SET (FT60 AVL)	1
2	D10010670.9	RING PISTON COMPRESSION UPPER	3
3	D10010680.9	RING PISTON COMPRESSION LOWER	3
4	D10044670.9	CONFORMABLE OIL RING ASSEMBLY AVL-70	3

TABLE-47
KIT ENGINE INLET AND EXHAUST VALVES




TABLE-47
KIT ENGINE INLET AND EXHAUST VALVES

Fig. No.	Part No.	Description	Qty
1	D10137900.9	KIT ENGINE INLET AND EXHAUST VALVES (AVL)	1
2	D10044490.9	VALVE EXHAUST	3
3	D10044500.9	VALVE AIR INTAKE	3

TABLE-74
HOOTER & RELAY




TABLE-74
HOOTER & RELAY

Fig. No.	Part No.	Description	Qty
1	D10645940.9	BUZZER ASSEMBLY	1
2	D10647990.9	BRACKET ASSEMBLY HOOTER MOUNTING	1
3	D10656110.9	UNIT ENGINE SHUT OFF CONTROLLER RELAY (SEAT OCCUPANCY)	1
4	D10656410.9	BRACKET ASSEMBLY OPS RELAY MOUNTING	1

TABLE-1
KIT GEAR BOX BALL AND SPRING




TABLE-1
KIT GEAR BOX BALL AND SPRING

Fig. No.	Part No.	Description	Qty
1	D10112880.9	KIT GEAR BOX BALL AND SPRING (FARMTRAC)	1
2	D10000490.9	BALL 3/8" DIAMETER	4
3	D10195960.9	SPRING TRANSMISSION PTO SHIFTER PLATE	4

TABLE-46
KIT OIL PUMP REPAIR




TABLE-46**KIT OIL PUMP REPAIR**

Fig. No.	Part No.	Description	Qty
1	D10112890.9	KIT OIL PUMP REPAIR (FARMTRAC)	1
2	D10010990.9	PLUG LUBE OIL PUMP RELIEF VALVE	1
3	D10011010.9	SPRING LUBE OIL PUMP RELIEF VALVE	1
4	D10011050.9	VALVE LUBE OIL PRESSURE RELIEF	1

TABLE-103
KIT BUSHING HYDRAULIC LIFT SHAFT




TABLE-103**KIT BUSHING HYDRAULIC LIFT SHAFT**

Fig. No.	Part No.	Description	Qty
1	D10145860.9	KIT BUSHING HYDRAULIC LIFT SHAFT	1
2	D10095230.9	BUSHING HYDRAULIC LIFT SHAFT	2
3	D10095240.9	BUSHING HYDRAULIC LIFT SHAFT	2

TABLE-47
KIT SLEEVE PTO




TABLE-47
KIT SLEEVE PTO

Fig. No.	Part No.	Description	Qty
1	D10207110.9	KIT SLEEVE PTO (FT-30/35/45/50/3600)	1
2	D10001050.9	SLEEVE PTO COUNTERSHAFT (MACHINED)	1
3	D10002230.9	SLEEVE SHAFT PTO REAR AXLE	1

TABLE-50
KIT MIRROR AND BRACKET REAR VIEW




TABLE-50**KIT MIRROR AND BRACKET REAR VIEW**

Fig. No.	Part No.	Description	Qty
1	D10207230.9	KIT MIRROR AND BRACKET REAR VIEW (PT/FT ALL)	1
2	D10216680.9	SCREW M5X0.80X20 CROSS RECESSED PAN HEAD	4
3	D10016660.9	PLATE REAR VIEW MIRROR	1
4	D10016680.9	BUSH REAR VIEW MIRROR	1
5	D10016690.9	BRACKET ASSEMBLY REAR VIEW MIRROR	1
6	D10151990.9	MIRROR AND ROD ASSEMBLY REAR VIEW	1
7	D10018100.9	NUT M5X0.80 NYLOCK	4
8	D10017930.9	NUT M6X1.00 HEX NYLOCK	1

TABLE-104
KIT CUP AND CONE ROLLER BEARING REAR AXLE




TABLE-104**KIT CUP AND CONE ROLLER BEARING REAR AXLE**

Fig. No.	Part No.	Description	Qty
1	D10249530.9	KIT CUP AND CONE ROLLER BEARING REAR AXLE	1
2	D10002620.9	CONE AND ROLLER ASSEMBLY REAR AXLE	1
3	D10002610.9	CUP BEVEL PINION SHAFT REAR AXLE	1

TABLE-51
KIT PINION AND GEAR REAR AXLE DIFFERENTIAL SIDE LH/RH




TABLE-51**KIT PINION AND GEAR REAR AXLE DIFFERENTIAL SIDE LH/RH**

Fig. No.	Part No.	Description	Qty
1	D10306680.9	KIT PINION AND GEAR REAR AXLE DIFFERENTIAL SIDE LH/RH (FARMTRAC)	1
2	D10003030.9	GEAR REAR AXLE DIFFERENTIAL SIDE LH (Z-16)	1
3	D10003040.9	GEAR REAR AXLE DIFFERENTIAL SIDE RH (Z-16)	1
4	D10003080.9	SPIDER SHAFT REAR AXLE DIFFERENTIAL	1
5	D10003090.9	PINION REAR AXLE DIFFERENTIAL (Z-9)	4

TABLE-52
KIT LEVER HYDRAULIC LIFT DRAFT CONTROLWITH LEVER AND LINK




TABLE-52**KIT LEVER HYDRAULIC LIFT DRAFT CONTROLWITH LEVER AND LINK**

Fig. No.	Part No.	Description	Qty
1	D10306670.9	KIT LEVER HYDRAULIC LIFT DRAFT CONTROLWITH LEVER AND LINK(FARMTRAC)	1
2	D10077850.9	LEVER HYDRAULIC LIFT DRAFT CONTROL	1
3	D10077860.9	LINK HYDRAULIC LIFT DRAFT CONTROL CONNECTER	1
4	D10077960.9	PIN PIVOT ACUATOR HYDRAULIC LIFT	1

TABLE-105
KIT REAR WHEEL BOLT AND NUT




TABLE-105**KIT REAR WHEEL BOLT AND NUT**

Fig. No.	Part No.	Description	Qty
1	D10226520.9	KIT REAR WHEEL BOLT AND NUT (FT NEW MODELS)	1
2	D10241500.9	BOLT REAR WHEEL	8
3	D10241480.9	NUT REAR WHEEL	8

TABLE-59
KIT WASHER SET CENTRE PIN




TABLE-59**KIT WASHER SET CENTRE PIN**

Fig. No.	Part No.	Description	Qty
1	D10311280.9	KIT WASHER SET CENTRE PIN	1
2	D10012880.9	WASHER FRONT AXLE CENTRE PIN THRUST	1
3	D10013000.9	WASHER FRONT AXLE THRUST REAR	1
4	D10013010.9	WASHER FRONT AXLE CENTRE REAR	1

TABLE-53
KIT SHAFT AND BOLT ASSEMBLY REAR AXLE




TABLE-53**KIT SHAFT AND BOLT ASSEMBLY REAR AXLE**

Fig. No.	Part No.	Description	Qty
1	D10311330.9	KIT SHAFT AND BOLT ASSEMBLY REAR AXLE (FARMTRAC)	1
2	D10296950.9	SHAFT REAR AXLE (MACHINED)	1
3	D10003440.9	RETAINER REAR AXLE SEAL	1

TABLE-54
KIT CUP AND CONE ROLLER BEARIN




TABLE-54
KIT CUP AND CONE ROLLER BEARIN

Fig. No.	Part No.	Description	Qty
1	D10252730.9	KIT CUP AND CONE ROLLER BEARING ASSEMBLY DIFFERENTIAL (FT)	1
2	D10003070.9	CONE AND ROLLER ASSEMBLY REAR AXLE DIFFERENTIAL RH	1
3	D10002740.9	CUP REAR AXLE HOUSING RH	1

TABLE-85
KIT CONVERSION À REAR AXLEÀ HOUSING LH




TABLE-85**KIT CONVERSION Â REAR AXLEÂ HOUSING LH**

Fig. No.	Part No.	Description	Qty
1	D10419160.9	KIT CONVERSION REAR AXLE HOUSING LH	1
2	D10249320.9	HOUSING ASSEMBLY REAR AXLE LH	1
3	D10307430.9	SHAFT LOWER LINK HYDRAULIC LH	1
4	D81001300.9	BOLT 9/16"-12X1.75" HEX HEAD	16
5	D10087270.9	BEARING ASSEMBLY TAPER ROLLER (REAR AXLE)	1